

**Apollo®**  
**CNX80**  
**Installation Manual**

*TSO PENDING*  
*TSO APPLIED FOR*

April 2003  
560-0982-00 Rev --



**UPS Aviation Technologies**

# ***TSO PENDING***

This document and the information disclosed herein are proprietary information of UPSAT. Neither this document nor the information contained herein shall be transmitted, reproduced, copied, or disclosed in any form or by any means without the written authorization of UPSAT.

The information disclosed herein includes trade secrets and confidential business and/or financial information and falls within exemption (b) (4) of 5 USC 552 (FOIA) and the prohibitions of 18 USC 1905.

UPS Aviation Technologies® is a registered trademark of United Parcel Service of America, Inc.

©2003 by UPS Aviation Technologies, Inc. All rights reserved.  
Printed in the USA

Cage Code: 0XCJ6

UPS Aviation Technologies  
PO Box 13549  
Salem, OR 97309

2345 Turner Rd., SE  
Salem, OR 97302  
USA

Phone: 503.581.8101  
800.525.6726  
In Canada: 800.654.3415  
Fax: 503.364.2138  
Website: <http://www.upsat.com>

**TSO PENDING**

## HISTORY OF REVISIONS

Revision	Date	Description
--	04/7/03	Initial release

## ORDERING INFORMATION

To receive additional copies of Apollo® CNX80 publications, order the following part numbers:

CNX80 Installation Manual	560-0982-xx
CNX80 Pilot Guide	560-0984-xx
CNX80 Reference Guide	560-0989-xx
CNX80 Quick Reference Guide	561-0281-xx
CNX80 Computer-Based Training	560-0990-xx
A-33 GPS Antenna Installation Guide	560-0949-xx
A-34 GPS Antenna Installation Guide	560-5047-xx

# TSO PENDING

List of Effective Pages									
Page	Rev	Page	Rev	Page	Rev	Page	Rev	Page	Rev
Cover	0	2-10	0	3-5	0	A-1	0	D-8	0
Copyright	0	2-11	0	3-6	0	A-2	0	D-9	0
i	0	2-12	0	3-7	0			D-10	0
ii	0	2-13	0	3-8	0	B-1	0	D-11	0
iii	0	2-14	0	3-9	0	B-2	0	D-12	0
iv	0	2-15	0	3-10	0	B-3	0	D-13	0
v	0	2-16	0	3-11	0	B-4	0	D-14	0
vi	0	2-17	0	3-12	0	B-5	0	D-15	0
1-1	0	2-18	0	3-13	0	B-6	0	D-16	0
1-2	0	2-19	0	3-14	0	B-7	0	D-17	0
1-3	0	2-20	0	3-15	0	B-8	0	D-18	0
1-4	0	2-21	0	3-16	0	B-9	0	D-19	0
1-5	0	2-22	0	3-17	0	B-10	0	D-20	0
1-6	0	2-23	0	3-18	0	B-11	0	D-21	0
1-7	0	2-24	0	3-19	0	B-12	0	D-22	0
1-8	0	2-25	0	3-20	0	B-13	0	D-23	0
1-9	0	2-26	0	3-21	0	B-14	0	D-24	0
1-10	0	2-27	0	3-22	0	B-15	0	D-25	0
1-11	0	2-28	0	3-23	0	B-16	0	D-26	0
1-12	0	2-29	0	3-24	0			D-27	0
1-13	0	2-30	0	3-25	0			D-28	0
1-14	0	2-31	0	3-26	0				
1-15	0	2-32	0	3-27	0				
1-16	0	2-33	0	3-28	0	C-1	0		
1-17	0	2-34	0	3-29	0	C-2	0		
1-18	0	2-35	0	3-30	0				
		2-36	0	4-1	0				
		2-37	0	4-2	0	D-1	0		
2-1	0	2-38	0	4-3	0	D-2	0		
2-2	0	2-39	0	4-4	0	D-3	0		
2-3	0	2-40	0	5-1	0	D-4	0		
2-4	0			5-2	0	D-5	0		
2-5	0					D-3	0		
2-6	0	3-1	0			D-4	0		
2-7	0	3-2	0	6-1	0	D-5	0		
2-8	0	3-3	0	6-2	0	D-6	0		
2-9	0	3-4	0			D-7	0		

**TSO PENDING****TABLE OF CONTENTS**

<b>1</b>	<b>GENERAL INFORMATION.....</b>	<b>1-1</b>
1.1	ABOUT THIS MANUAL .....	1-1
1.2	EQUIPMENT DESCRIPTION .....	1-2
1.2.1	FEATURES .....	1-2
1.2.2	SYSTEM INTERFACES .....	1-3
1.3	SPECIFICATIONS.....	1-6
1.3.1	ELECTRICAL.....	1-6
1.3.2	PHYSICAL.....	1-6
1.3.3	ENVIRONMENTAL.....	1-6
1.3.4	DISPLAY.....	1-7
1.3.5	GPS/WAAS RECEIVER PERFORMANCE.....	1-7
1.3.6	COMM RECEIVER PERFORMANCE .....	1-8
1.3.7	COMM TRANSMITTER PERFORMANCE .....	1-8
1.3.8	NAV RECEIVER PERFORMANCE .....	1-9
1.3.9	AVIONICS INTERFACES.....	1-10
1.3.10	ANTENNA REQUIREMENTS.....	1-12
1.3.11	SERIAL INTERFACE.....	1-14
1.4	REGULATORY COMPLIANCE .....	1-14
1.4.1	TSO AND ADVISORY CIRCULAR REFERENCES .....	1-14
1.4.2	TSO AUTHORIZATION.....	1-15
1.4.3	FCC GRANT OF EQUIPMENT AUTHORIZATION .....	1-15
1.4.4	CNX80 STC AUTHORIZATION.....	1-15
1.5	DATABASE UPDATES .....	1-15
1.6	UNPACKING THE EQUIPMENT .....	1-16
1.7	PACKAGE CONTENTS.....	1-17
1.8	LICENSE REQUIREMENTS.....	1-18
1.9	DEFINITIONS & ACRONYMS.....	1-19
<b>2</b>	<b>INSTALLATION .....</b>	<b>2-1</b>
2.1	PRE-INSTALLATION INFORMATION .....	2-1
2.2	INSTALLATION OVERVIEW .....	2-1
2.3	MATERIALS REQUIRED AND NOT SUPPLIED .....	2-1
2.4	SPECIAL TOOLS REQUIRED .....	2-2
2.5	INSTALLATION CONSIDERATIONS.....	2-2
2.5.1	MINIMUM SYSTEM CONFIGURATION .....	2-2
2.5.2	EXISTING SENSORS .....	2-3
2.5.3	MOUNTING CONSIDERATIONS .....	2-4
2.5.4	CABLING AND WIRING .....	2-4
2.5.5	AIR CIRCULATION AND COOLING .....	2-5
2.5.6	COMPASS SAFE DISTANCE .....	2-5
2.5.7	VIEWING ANGLE .....	2-5
2.5.8	HELICOPTER INSTALLATION .....	2-5
2.6	EQUIPMENT MOUNTING.....	2-5
2.6.1	MOUNTING LOCATION .....	2-6
2.6.2	MOUNTING TUBE INSTALLATION .....	2-6
2.6.3	UNIT INSERTION.....	2-9
2.6.4	UNIT REMOVAL.....	2-10
2.6.5	UNIT REPLACEMENT .....	2-10
2.7	ELECTRICAL CONNECTIONS .....	2-12
2.7.1	INTERFACE CONNECTOR DEFINITION .....	2-13
2.8	FUNCTIONAL DESCRIPTIONS .....	2-20
2.8.1	POWER .....	2-20
2.8.2	MAIN COURSE DEVIATION INDICATOR .....	2-20
2.8.3	AUXILIARY COURSE DEVIATION INDICATOR .....	2-21
2.8.4	COMPOSITE INDICATOR.....	2-22

2.8.5	ALTIMETER.....	2-23
2.8.6	SYNCHRO HEADING.....	2-23
2.8.7	ANNUNCIATOR OUTPUTS.....	2-24
2.8.8	DISCRETE OUTPUTS.....	2-26
2.8.9	SWITCHES / DISCRETE INPUTS .....	2-27
2.8.10	SERIAL INTERFACES .....	2-28
2.8.11	TIME MARK OUTPUT.....	2-32
2.8.12	VHF COM .....	2-32
2.8.13	VHF NAV.....	2-33
2.8.14	MESSAGE AUDIO.....	2-34
2.8.15	RMI / OBI .....	2-34
2.8.16	DME TUNING.....	2-35
2.9	ANTENNA INSTALLATION AND CONNECTIONS.....	2-36
2.9.1	COMM ANTENNA.....	2-36
2.9.2	GPS ANTENNA.....	2-36
2.9.3	NAV ANTENNA.....	2-38
2.10	WEIGHT AND BALANCE.....	2-38
2.11	ELECTRICAL LOAD ANALYSIS .....	2-38
<b>3</b>	<b>POST INSTALLATION CONFIGURATION &amp; CHECKOUT PROCEDURES .....</b>	<b>3-1</b>
3.1	MOUNTING AND WIRING CHECK.....	3-1
3.2	EQUIPMENT SETUP AND CONFIGURATION .....	3-1
3.2.1	SETUP FUNCTION.....	3-2
3.3	EQUIPMENT OPERATIONAL/FUNCTIONAL TEST .....	3-8
3.3.1	CNX80 CHECKOUT UTILITIES .....	3-8
3.3.2	SYSTEM CHECKOUT – GROUND CHECKS.....	3-17
3.3.3	SYSTEM CHECKOUT – FLIGHT CHECKS .....	3-26
3.4	DATABASE CHECK.....	3-27
3.4.1	DATA CARD REPLACEMENT .....	3-27
<b>4</b>	<b>TROUBLESHOOTING.....</b>	<b>4-1</b>
4.1	TROUBLESHOOTING PROCEDURE .....	4-1
4.2	CONTACTING THE FACTORY FOR ASSISTANCE .....	4-4
<b>5</b>	<b>LIMITATIONS.....</b>	<b>5-1</b>
5.1	OPERATION .....	5-1
5.2	INSTALLATION .....	5-1
5.2.1	GPS ANTENNA.....	5-1
5.3	AIRCRAFT RADIO STATION LICENSE .....	5-1
<b>6</b>	<b>PERIODIC MAINTENANCE.....</b>	<b>6-1</b>
6.1	EQUIPMENT CALIBRATION .....	6-1
6.2	VOR CHECKS .....	6-1
6.3	CLEANING .....	6-1
6.4	BATTERY REPLACEMENT .....	6-1
6.5	DISPLAY BACKLIGHT .....	6-1
<b>APPENDIX A - CERTIFICATION DATA .....</b>	<b>1</b>	
A.1	ENVIRONMENTAL QUALIFICATION .....	1
A.2	CNX80 STC DATA.....	2
<b>APPENDIX B - SERIAL INTERFACE SPECIFICATIONS .....</b>	<b>1</b>	
B.1	SERIAL INPUT SPECIFICATIONS.....	1
B.1.1	ALTITUDE ENCODER/CONVERTER INPUT.....	1
B.1.2	FUEL/AIR DATA COMPUTER INPUT.....	3
B.2	SERIAL OUTPUT SPECIFICATIONS .....	6
B.2.1	MAPCOM OUTPUT .....	6
<b>APPENDIX C - EQUIPMENT COMPATIBILITY .....</b>	<b>1</b>	
C.1	ALTITUDE SOURCES .....	1

**TSO PENDING**

C.2	FUEL/AIR DATA COMPUTERS .....	1
C.3	HEADING SOURCES.....	1
C.4	ALTIMETERS FOR BARO CORRECTION .....	2
C.5	AUTOPILOTS .....	2
C.6	ELECTRONIC HSI'S.....	2
<b>APPENDIX D - INTERCONNECT DIAGRAMS.....</b>		<b>1</b>

**LIST OF TABLES**

TABLE 1-1 - TSO AUTHORIZATION .....	1-15
TABLE 1-2 - PACKAGE CONTENTS .....	1-17
TABLE 1-3 - INSTALLATION KIT CONTENTS (PN 424-2014-800) .....	1-18
TABLE 1-4 - OPTIONAL EQUIPMENT AVAILABLE FROM UPSAT .....	1-18
TABLE 2-1 - CRIMP TOOL FOR P/N 162-0082 .....	2-2
TABLE 2-2 - CRIMP TOOL FOR P/N 245-0027 .....	2-2
TABLE 2-3 - INTERFACE CONNECTORS .....	2-12
TABLE 2-4 - CRIMP CONTACT SPECIFICATIONS.....	2-12
TABLE 2-5 MAIN SYSTEM CONNECTOR PIN-OUT (P1) .....	2-14
TABLE 2-6 COM I/O CONNECTOR PIN-OUT (P4).....	2-15
TABLE 2-7 I/O EXPANSION CONNECTOR PIN-OUT (P5) .....	2-16
TABLE 2-8 NAV I/O CONNECTOR PIN-OUT (P7) .....	2-19
TABLE 2-9 - ARINC 429 INPUT LABELS .....	2-30
TABLE 2-10 - ARINC 429 OUTPUT LABELS.....	2-31
TABLE 2-11 - UNIT WEIGHTS.....	2-38
TABLE 2-12 - UNIT POWER LOADS .....	2-38
TABLE 3-1 - SERIAL PORT SETUP CONFIGURATIONS.....	3-3
TABLE 3-2 - ARINC 429 INPUT AND OUTPUT PORT SETTINGS .....	3-4
TABLE 3-3 – LAMP OUTPUT TEST ITEMS.....	3-12
TABLE 3-4 – DESCRIPTION OF INPUT MONITOR ITEMS .....	3-16
TABLE 3-5 - CNX80 POST-INSTALLATION CHECKOUT LOG .....	3-28
TABLE 4-1. TROUBLESHOOTING GUIDE.....	4-1
 TABLE B- 1 - RS-232 SERIAL INPUT (RX) SELECTIONS.....	1
TABLE B- 2 - ALTITUDE INPUT DATA.....	2
TABLE B- 3 - FUEL/AIR DATA MESSAGE DATA (S FORMAT).....	3
TABLE B- 4 - FUEL/AIR DATA MESSAGE DATA (Z FORMAT).....	5
TABLE B- 5 - RS-232 SERIAL OUTPUT (TX) SELECTIONS .....	6
TABLE B- 6 - MOVING MAP ASCII NAVIGATION DATA .....	7
TABLE B- 7 - MOVING MAP BINARY ROUTE DATA.....	9
TABLE B- 8 - NEAREST WAYPOINT LIST DATA .....	10
TABLE B- 9 - FLIGHT PLAN WAYPOINT TYPE .....	11

**LIST OF ILLUSTRATIONS**

FIGURE 1-1 - CNX80 COLOR GPS/NAV/COM .....	1-2
FIGURE 1-2 - SAMPLE SINGLE CNX-80 SYSTEM DIAGRAM .....	1-3
FIGURE 1-3 - SAMPLE DUAL CNX-80 SYSTEM DIAGRAM .....	1-4
FIGURE 2-1 - CNX80 DIMENSIONS.....	2-7
FIGURE 2-2 - TYPICAL MOUNTING RACK .....	2-8
FIGURE 2-3 - CAM LOCK POSITIONING .....	2-9
FIGURE 2-4 - MOUNTING FRAME ASSEMBLY .....	2-11
FIGURE 2-5 - REAR MOUNTING TUBE CONNECTOR LAYOUT .....	2-13

FIGURE 2-6 - 37-PIN CONNECTOR .....	2-14
FIGURE 2-7 - 15-PIN CONNECTOR .....	2-15
FIGURE 2-8 - 78-PIN CONNECTOR DETAIL .....	2-18
FIGURE 2-9 - REAR COAX CONNECTOR ASSEMBLY .....	2-37
FIGURE 2-10 - CNX80 CENTER OF GRAVITY .....	2-39
FIGURE 3-1 - GROUND MAINTENANCE MODE DISPLAY .....	3-1
FIGURE 3-2 - SERIAL PORT SETUP PAGE .....	3-2
FIGURE 3-3 - ARINC 429 PORTS SETUP PAGE .....	3-4
FIGURE 3-4 - RESOLVER INTERFACE SETUP PAGE .....	3-5
FIGURE 3-5 - RESOLVER CALIBRATION PAGE .....	3-6
FIGURE 3-6 - ALTIMETER INTERFACE .....	3-7
FIGURE 3-7 - BARO-ALTIMETER CALIBRATION .....	3-7
FIGURE 3-8 - COM RADIO SETUP .....	3-8
FIGURE 3-9 - TEST MAIN MENU PAGE .....	3-9
FIGURE 3-10 - MAIN CDI FLAG TEST .....	3-9
FIGURE 3-11 - AUXILIARY CDI FLAG TEST .....	3-10
FIGURE 3-12 - MAIN CDI TEST PAGE .....	3-10
FIGURE 3-13 - AUXILIARY VDI TEST PAGE .....	3-11
FIGURE 3-14 - LAMP OUTPUT TEST .....	3-12
FIGURE 3-15 - DISPLAY TEST INITIAL SCREEN .....	3-13
FIGURE 3-16 - BEZEL KEY TEST .....	3-14
FIGURE 3-17 - INTERFACE MONITOR FUNCTION DISPLAY - PAGE 1 .....	3-14
FIGURE 3-18 - INTERFACE MONITOR FUNCTION DISPLAY - PAGE 2 .....	3-15
FIGURE 3-19 - GPS INFORMATION START-UP SCREEN .....	3-18
FIGURE 3-20 - GPS STATUS PAGE .....	3-19
FIGURE B- 1 - ALTITUDE DATA INPUT .....	2
FIGURE B- 2 - FUEL / AIRDATA DATA INPUT (S FORMAT) .....	4
FIGURE B- 3 - MOVING MAP DATA OUTPUT .....	11
FIGURE D- 1 - MAIN POWER AND ANTENNA INTERCONNECT DIAGRAM .....	3
FIGURE D- 2 - MAIN COURSE DEVIATION INDICATOR INTERCONNECT DIAGRAM .....	5
FIGURE D- 3 - AUXILIARY CDI INTERCONNECT DIAGRAM .....	7
FIGURE D- 4 - BARO POTENTIOMETER/SYNCRHO HEADING/RMI INTERCONNECT DIAGRAM .....	9
FIGURE D- 5 - RS232 SERIAL INTERFACES INTERCONNECT DIAGRAM .....	11
FIGURE D- 6 - CNX80 TO SL10/15 AUDIO PANEL INTERCONNECT DIAGRAM .....	13
FIGURE D- 7 - DME TUNING INTERCONNECT DIAGRAM .....	15
FIGURE D- 8 - S-TEC AUTOPILOT INTERCONNECT DIAGRAM .....	17
FIGURE D- 9 - CENTURY AUTOPILOT INTERCONNECT DIAGRAM .....	19
FIGURE D- 10 - BENDIX/KING AUTOPILOT INTERCONNECT DIAGRAM .....	21
FIGURE D- 11 - SINGLE CNX80 FULL STACK INTERCONNECT DIAGRAM .....	23
FIGURE D- 12 - FULL STACK WITH DUAL CNX80s INTERCONNECT DIAGRAM .....	25
FIGURE D- 13 - CNX80 TO SANDEL SN3308 NAV DISPLAY INTERCONNECT DIAGRAM .....	27

# 1 GENERAL INFORMATION

## 1.1 ABOUT THIS MANUAL

This manual describes the installation and checkout procedures for the Apollo CNX80 Color GPS/Nav/Com. It is intended for use by persons certified by the Federal Aviation Administration (FAA) to install avionics devices.

**SECTION 1** Provides **GENERAL INFORMATION** to the Apollo CNX80 unit. TSO certification information is also included in this section.

**SECTION 2** Includes **INSTALLATION PROCEDURES**.

**SECTION 3** Includes **POST-INSTALLATION CONFIGURATION AND CHECKOUT**.

**SECTION 4** Includes **TROUBLESHOOTING** information.

**SECTION 5** Includes **LIMITATIONS** for the equipment and installation.

**SECTION 6** Includes **PERIODIC MAINTENANCE** requirements.

**APPENDIX A** Includes **CERTIFICATION DATA**.

**APPENDIX B** Includes **SERIAL INTERFACE SPECIFICATIONS**.

**APPENDIX C** Includes **EQUIPMENT COMPATIBILITY** information.

**APPENDIX D** Includes **INTERCONNECT DIAGRAMS**.

## 1.2 EQUIPMENT DESCRIPTION

The Apollo CNX80 Color GPS/Nav/Com is a panel-mounted product that contains a GPS/WAAS engine, VHF Comm, and VHF Nav in an integrated unit with a moving map and color display. The CNX80 will also control a remote transponder.




Figure 1-1 - CNX80 Color GPS/Nav/Com


### 1.2.1 FEATURES

The features of the CNX80 Color GPS/Nav/Com include:


- 10-36 VDC Power Capability
- Sunlight-readable 256-color 3.8" diagonal LCD display
- GPS/WAAS engine for state-of-the-art fast, accurate navigation and precision approach (15-channel, 3 WAAS decoders, 5 Hz update of position, time, and velocity, 1 pps output)
- VHF engine for VOR/LOC/GS navigation
- VHF Com with 760 channels and 8 watts transmit power
- Flexible I/O support for RS232, RS422, and ARINC 429
- Control of a remote transponder
- Audio Messages
- Front panel-accessible data card

## 1.2.2 SYSTEM INTERFACES

The interfaces for a typical single CNX80 avionics stack are shown in Figure 1-2, while the interfaces for a typical dual CNX80 avionics stack are shown in Figure 1-3. The available interfaces are further described in the following sections.



**Figure 1-2 - Sample Single CNX-80 System Diagram**

**Figure 1-3 - Sample Dual CNX-80 System Diagram****1.2.2.1 CDI**

The CNX80 is capable of driving one external course deviation indicator (CDI) with information based upon VHF Nav or GPS data. The CNX80 also accepts a resolver input from this CDI. The CNX80 is capable of driving a second external CDI with information based upon GPS data.

**1.2.2.2 Composite Indicator**

The CNX80 is capable of driving an external composite indicator with information based upon VHF Nav data.

**1.2.2.3 RMI**

The CNX80 is capable of driving an external RMI (or OBI) navigation indicator with a digital clock / data / sync interface.

#### **1.2.2.4 DME**

The CNX80 can channel a DME based upon the tuned VOR frequency. Currently, the CNX80 only supports the King Serial DME channeling format.

#### **1.2.2.5 Announcer Outputs and Switch Inputs**

The CNX80 can drive various external annunciation lamps and receive inputs from various switches to control the CNX80 operation. This allows for remote operation of the CNX80 if desired for a specific installation.

#### **1.2.2.6 RS232 Interfaces**

The CNX80 has seven external, user-configurable RS232 serial ports (five are bi-directional, and two are receive-only). The serial ports can be configured to receive RS232 serial data from various sources, including another CNX80, an SL30, an SL70/SL70R, an MX20, a FADC, or an Altitude Encoder. These ports can also be configured to transmit RS232 serial data in various formats, including MAPCOM. These outputs allow the CNX80 to transmit data to the MX20, SL30 and SL70/SL70R. In addition, the CNX80 can transmit data to any unit that accepts the standard UPSAT MAPCOM data.

#### **1.2.2.7 RS422 Interfaces**

The CNX80 has one user-configurable, bi-directional RS422 input port. This port is not currently used.

#### **1.2.2.8 ARINC 429 Interfaces**

The CNX80 has three ARINC 429 input ports and two ARINC 429 output ports. Each port is user-configurable for low or high speed operation. The CNX80 can be set up to receive air data, heading data or wind data from suitable equipment. The outputs can be set up to output ARINC 429 data in various formats.

#### **1.2.2.9 Baro Correction Input**

The CNX80 has one interface that allows a baro correction potentiometer to be connected directly to the CNX80. This input can be calibrated at installation, allowing a wide variety of altimeters to be connected to the CNX80.

#### **1.2.2.10 Synchro Input**

The CNX80 has one XYZ synchro input that allows synchro heading to be supplied directly to the CNX80.

#### **1.2.2.11 Message Audio Output**

The CNX80 has one  $500\ \Omega$  audio output that can be connected to an audio panel to provide audible messages to the pilot. This output can be automatically inhibited by other equipment if required.

#### **1.2.2.12 Infrared Interface**

The CNX80 has one user-configurable bi-directional infrared port. This port is not currently used but in the future will be used to send and receive flight plan, TFR, and user waypoint information through a PDA that has infrared capabilities.

## 1.3 SPECIFICATIONS

This section includes detailed electrical, physical, environmental and performance specifications for the Apollo CNX80.

### 1.3.1 ELECTRICAL

Input voltage .....	10 VDC to 36 VDC
Input current (Main input – P1) .....	1.4 A typical, 2.2 A max (heater off) at 14 VDC 2.4 A typical, 3.2 A max (heater on) at 14 VDC 700 mA typical, 1.1 A max (heater off) at 28 VDC 1.2 A typical, 1.6 A max (heater on) at 28 VDC <i>Note: backlight heater element turns on when internal temperature is below approx. 42 °C</i>
Input current (VHF Nav input – P7) .....	450 mA typical, 700 mA max at 14 VDC 200 mA typical, 350 mA max at 28 VDC
Input current (Comm input – P4) .....	270 mA typical, 1.8 A max at 14 VDC, receive 130 mA typical, 900 mA max at 28 VDC, receive 2.1 A typical, 3.2 A max at 14 VDC, transmit 1.0 A typical, 1.6 A max at 28 VDC, transmit <i>Note: receive max at full receive audio, transmit max at 90% modulation at 1000 Hz.</i>
Internal fuses .....	Main input: 3 amp fast-blow, socketed on board (2) Nav input: 3 amp fast-blow, socketed on board Comm input : 7 amp fast-blow, soldered in board
Memory backup .....	Internal flash memory

### 1.3.2 PHYSICAL

Height.....	3.3 inches (84 mm)
Width.....	6.25 inches (159 mm)
Depth.....	11.7 inches (297 mm) (behind panel, including mounting frame and connectors)
Weight.....	5.8 lbs. (2.6 kg) unit only 0.7 lbs. (0.3 kg) mounting tube

### 1.3.3 ENVIRONMENTAL

The Apollo CNX80 unit is designed and tested to meet appropriate categories as shown in the Environmental Qualification Form included in Appendix A.

Operating temperature .....	-20°C to +55°C
Storage temperature .....	-55°C to +85°C
Temperature variation.....	2°C per minute
Humidity .....	95% at 50°C
Maximum continuous altitude .....	35,000 feet

---

Decompression .....	55,000 feet (operation for up to 30 minutes at 55,000 feet supported)
Cooling .....	Not required

#### **1.3.4 DISPLAY**

TSO Compliance .....	TSO-C113 (SAE/AS8034)
Active Display Size .....	3.8" Diagonal (3.1" (W) x 2.1"(H))
Display Format .....	320 pixels (W) x 240 pixels (H)
Viewing Angle (with 5:1 contrast ratio min.)	
Left/Right .....	60° from perpendicular
Up .....	60° from perpendicular
Down .....	35° from perpendicular
Brightness	
Maximum.....	130 fL
Minimum .....	0.2 fL (at zero ambient light)

\* Minimum brightness can be adjusted by the user to a value > 0.2 fL

#### **1.3.5 GPS/WAAS RECEIVER PERFORMANCE**

TSO Compliance .....	TSO-C146a (RTCA/DO-229C)
Number of channels.....	15 (12 GPS and 3 GPS/WAAS/SBAS)
Frequency .....	1575.42 MHz L1, C/A code
Sensitivity (acquisition).....	-116 dBm to -134.5 dBm GPS -116 dBm to -135.5 dBm WAAS
Sensitivity (drop lock) .....	-144 dBm
Dynamic range.....	> 20 dB
Lat/Long position accuracy .....	<1 meter RMS typical with WAAS (horizontal/vertical)
Velocity .....	1000 knots maximum (above 60,000 ft)
TTFF (time to first fix).....	1:45 min. typical with current almanac, position, and time
Reacquisition .....	10 seconds typical
Position update interval .....	0.2 sec (5 Hz)
1 pps (pulse per second) .....	±275 nsec of UTC second
Datum .....	WGS-84
SATCOM compatibility .....	Compatible on aircraft equipped with SATCOM
Antenna power supply.....	35 mA typical, 40 mA max at 4.7 VDC

**1.3.6 COMM RECEIVER PERFORMANCE**

TSO Compliance.....	TSO-C38d (RTCA/DO-186, DO-186a)
Class .....	D
Frequency range .....	118.000 to 136.975 MHz, 760 channels
Sensitivity .....	1µV (2µV hard) for 6dB S+N/N with 30% modulation at 1000Hz
Selectivity .....	< 6dB variation at ± 7 kHz, > 60dB at ± 22 kHz
Speaker audio output level.....	12 watts into 4Ω, 8 watts into 8Ω
Headphone audio output level .....	280 mW into 100Ω, 120mW into 500Ω
Distortion .....	< 5% at rated output at 1000 Hz
AGC characteristics .....	< 3 dB variation in audio output from 5µV to 100mV input, 15% to 90% modulation
Squelch control .....	Automatic squelch with manual override

**1.3.7 COMM TRANSMITTER PERFORMANCE**

TSO Compliance.....	TSO-C37d (RTCA/DO-186, DO-186a), TSO-C128 (RTCA/DO-207)
Class .....	4
Output power .....	8 watts minimum carrier at >12 VDC input, 6 watts minimum at 10 VDC input (transmit is locked out below 9 volts input)
Frequency range.....	118.000 to 136.975 MHz, 760 channels
Frequency tolerance .....	±15 ppm from -20°C to +70°C
Microphone input.....	Two inputs, standard carbon or dynamic mic with integrated preamp providing minimum 70mV rms into 1000Ω load
Modulation capability .....	85% with 100mV to 1000mV rms microphone input at 1000 Hz
Audio frequency distortion .....	< 10% at 85% modulation at 350 to 2500 Hz
Audio frequency response.....	< 4 dB variation with 350 to 2500 Hz, 85% modulation
Carrier noise level.....	> 35 dB down
Sidetone output .....	up to 280 mW into 100Ω, 120 mW into 500Ω
Duty cycle: .....	100%
Stuck mic time-out .....	35 second time-out, reverts to receive

### 1.3.8 NAV RECEIVER PERFORMANCE

#### 1.3.8.1 VOR

TSO compliance .....	TSO-C40c (RTCA/DO-196)
Operational class .....	N/A
Accuracy category .....	B {-46°C to + 55°C }
Frequency range .....	108.00 to 117.95 MHz in 50 kHz increments
Frequency tolerance.....	0.0008%
Cross modulation products .....	At least 60 dB down
Receiver sensitivity .....	108 MHz –115 dBm typical 117 MHz –117 dBm typical
Course accuracy.....	RTCA DO-196 two sigma limit: 3° SL30 performance: less than 0.5° typical
Audio output.....	With a 1 kHz tone 30% modulation at least 100 mW output into 500 ohm loads
Ident/voice .....	With 100 mV input, 30% modulation at 1020 Hz, the ident/voice tone ratio shall not be less than 15 dB
Audio response .....	Less than 6 dB variation from 350 Hz to 2500 Hz

#### 1.3.8.2 Localizer

TSO compliance .....	TSO-C36e (RTCA/DO-195)
Operational class .....	A {manual landing systems}
Accuracy category .....	B {-46°C to + 55°C }
Frequency range .....	108.00 to 111.95 MHz
Frequency tolerance.....	0.0008%
Cross modulation products .....	At least 60 dB down
Receiver sensitivity .....	-115 dBm typical
Centering error.....	RTCA DO-195 two sigma limit: 6.6% of full scale SL30 performance: less than 1.0% typical (1.5 mV)
Audio output.....	With a 1 kHz tone 30% modulation at least 100 mW output into 500 ohm loads
Ident/voice .....	With 100 mV input, 30% modulation at 1020 Hz, the ident/voice tone ratio shall not be less than 15 dB
Audio response .....	Less than 6 dB variation from 350 Hz to 2500 Hz

#### 1.3.8.3 Glideslope

TSO compliance .....	TSO-C34e (RTCA/DO-192)
Operational class .....	N/A
Accuracy category .....	B {-46°C to + 55°C }
Frequency range .....	329.150 to 335.00 MHz

Frequency tolerance .....	0.0008%
Cross modulation products .....	At least 60 dB down
Receiver sensitivity .....	-95 dBm typical
Centering error .....	RTCA DO-195 two sigma limit: 6.7% of full scale SL30 performance: less than 2.0% typical (3.0 mV)

#### 1.3.8.4 Computation Rates

The tuned active frequency is computed 10 times per second. If the VOR monitor function is activated, 20% of each second is allocated to the monitored frequency, slightly decreasing the active to frequency computation rate. It is important to note that the monitored frequency is only updated once per second.

### 1.3.9 AVIONICS INTERFACES

#### 1.3.9.1 Main CDI (GPS or VHF Nav)

##### 1.3.9.1.1 Deviations / Flags / Annunciators

CDI L/R deviation.....	±150 mv full scale (200 Ω load max)
TO/OFF/FROM flag .....	±250 mv, TO/FROM (200 Ω load max)
Nav valid flag.....	+300 mv for valid indication (200 Ω load max)
Nav superflag .....	Vin - 2 volts (minimum) for valid, source capability of 400 mA
VDI up/down.....	±150 mv full scale (200 Ω load max)
VDI valid flag .....	+300 mv for valid indication (200 Ω load max)
VDI superflag.....	Vin - 2 volts (minimum) for valid, source capability of 400 mA
GPS/Nav Annunciators .....	Open collector outputs capable of sinking up to 400 mA for turning ON annunciator lamps

##### 1.3.9.1.2 OBS Resolver

TSO compliance.....	TSO-C40c (DO-196)
Applicable documents.....	RTCA DO-196
Operational class.....	N/A
Accuracy category.....	B {-46°C to + 55°C}
Output signal .....	300 Hz ± 2 Hz (rounded square wave)
Output voltage (automatically adjusted during calibration) .....	5 Vpp to 10 Vpp
Input voltage max (calibrated) .....	5 Vpp (when OBS is set to maximum)
Resolver voltage gain (loss).....	1:1 maximum, 2:1 minimum
Output loading at max voltage .....	100 ohms impedance
Accuracy/Resolution.....	0.25° rounded to 1° steps

**1.3.9.2 Auxiliary CDI (GPS Only)**

CDI L/R deviation .....	±150 mv full scale (200 Ω load max)
TO/OFF/FROM flag.....	±250 mv, TO/FROM (200 Ω load max)
Nav valid flag .....	+300 mv for valid indication (200 Ω load max)
VDI up/down .....	±150 mv full scale (200 Ω load max)
VDI valid flag.....	+300 mv for valid indication (200 Ω load max)

**1.3.9.3 Composite Output****1.3.9.3.1 VOR Mode**

Band pass frequency .....	0 Hz to 15 kHz
Variation over frequency range .....	Less than 2 dB
Output signal voltage.....	0.500 VRMS
Output loading .....	1,000 ohms (max)

**1.3.9.3.2 LOC Mode**

Band pass frequency .....	0 Hz to 15 kHz
Variation over frequency range .....	Less than 2 dB
Output signal voltage.....	0.390 VRMS (0.275 VRMS @ 90 Hz, 0.275 VRMS @ 150 Hz)
Output loading .....	1,000 ohms (max)
ILS energize signal .....	Sinks up to 400 mA (max)

**1.3.9.4 Annunciator Outputs**

Annunciators.....	Open collector outputs capable of sinking up to 400 mA for turning ON annunciator lamps
-------------------	---

## **1.3.10 ANTENNA REQUIREMENTS**

### **1.3.10.1 GPS Antennas**

#### **1.3.10.1A-33 (590-1104)**

Early production runs of PN 590-1104 were marked with TSO-C129a. This antenna was re-qualified to TSO-C144 with no changes to the antenna. P/N 590-1104 antennas marked with TSO-C129a identification are identical to those marked with TSO-C144.

Applicable TSO:	TSO-C144 (RTCA/DO-229C)	
Frequency:	1575 MHz	
Polarization:	Right Hand Circular	
Axial Ratio:	3 dB Max at bore site	
Radiation Coverage:	Elevation Angle	Minimum Gain
	>15°	-2.0 dBic
	10°	-3.0 dBic
	5°	-4.5 dBic
	0°	-7.5 dBic
Finish:	Polyurethane Enamel	
Weight:	3.9 oz. (0.11 kg)	
Height:	0.61 inches (1.55 cm)	
Operating Temperature:	-55°C to +85°C	
Operating Altitude:	55,000 feet (16,764m) max.	
Amplifier:		
Gain	26 dB ±2 dB	
Noise Figure:	2.5 dB Max	
Impedance:	50 ohms	
VSWR (Dry):	≤ 1.5:1	
VSWR (Rain):	≤ 2.0:1	
Band Rejection:	35 dB	
Power Handling:	1 Watt	
Voltage:	5 VDC ±10%	
Current:	35 mA nominal, 40 mA max.	
L1 Filter Bandwidth	1575 ± 2 MHz	

#### **1.3.10.1.2A-34 (590-1112)**

Early production runs of PN 590-1112 were marked with TSO-C129a. This antenna was re-qualified to TSO-C144 with no changes to the antenna. P/N 590-1112 antennas marked with TSO-C129a identification are identical to those marked with TSO-C144.

Applicable TSO:	TSO-C144 (RTCA/DO-229C)
-----------------	-------------------------

Frequency:	1575 MHz
Polarization:	Right Hand Circular
Axial Ratio:	3 dB Max at bore site
Radiation Coverage:	Elevation Angle      Minimum Gain
	>15°              -2.0 dBiC
	10°              -3.0 dBiC
	5°              -4.5 dBiC
	0°              -7.5 dBiC
Finish:	Polyurethane Enamel
Weight:	7.0 oz. (0.2 kg)
Height:	0.66 inches (1.76 cm)
Operating Temperature:	-55°C to +85°C
Operating Altitude:	55,000 feet (16,764m) max.
Amplifier:	
Gain:	26 dB ±2 dB
Noise Figure:	2.5 dB Max
Impedance:	50 ohms
VSWR (Dry):	≤ 1.5:1
VSWR (Rain):	≤ 2.0:1
Band Rejection:	35 dB
Power Handling:	1 Watt
Voltage:	5 VDC ±10%
Current:	35 mA nominal, 40 mA max.
L1 Filter Bandwidth:	1575 ± 2 MHz

### 1.3.10.2 Comm Antenna

The Apollo CNX80 requires a VHF comm antenna meeting the following specifications:

- Standard 50Ω vertically polarized antenna with a VSWR < 2.5:1
- TSO C37d, and TSO C38d

### 1.3.10.3 VHF Antenna

The Apollo CNX80 requires a VHF NAV antenna meeting the following specifications:

- Standard 50 Ω horizontally polarized antenna with a VSWR < 3:1
- Capable of receiving VOR/LOC/GS (Such as: Comant Industries P/N CI 157P)
- 108.00 – 117.95 MHz (VOR/LOC)
- 328.60 – 335.4 MHz (GS)
- TSO C34e, TSO C36e, and TSO C40c

### **1.3.11 SERIAL INTERFACE**

RS-232      Defined in Appendix B- Serial Interface Specifications

## **1.4 REGULATORY COMPLIANCE**

### **1.4.1 TSO AND ADVISORY CIRCULAR REFERENCES**

- TSO-C34e, ILS Glide Slope Receiving Equipment Operating Within the Radio Frequency Range of 328.6-335.4 Megahertz (MHz)
- TSO-C36e, Airborne ILS Localizer Receiving Equipment Operating Within the Radio Frequency Range of 108-112 Megahertz (MHz)
- TSO-C37d, VHF Radio Communications Receiving Equipment Operating Within the Radio Frequency Range 117.975 to 137.000 Megahertz
- TSO-C38d, VHF Radio Communications Transmitting Equipment Operating Within the Radio Frequency Range 117.975 to 137.000 Megahertz
- TSO-C40c, VOR Receiving Equipment Operating Within the Radio Frequency Range of 108-117.95 Megahertz (MHz)
- TSO-C113, Airborne Multipurpose Electronic Displays
- TSO-C128, Devices That Prevent Blocked Channels Used in Two-Way Radio Communications Due to Unintentional Transmission
- TSO-C146a, Stand-Alone Airborne Navigation Equipment using the Global Positioning System (GPS) Augmented by the Wide Area Augmentation System (WAAS)
- AC 20-67B, Airborne VHF Communications Equipment Installations
- AC43.13-1B, Acceptable Methods, Techniques and Practices - Aircraft Inspection and Repair
- AC43.13-2A, Acceptable Methods, Techniques and Practices - Aircraft Alterations

**NOTE**

Unauthorized changes or modifications to the CNX80 may void the compliance to required regulations and authorization for continued equipment usage.

The CNX80 contains additional functions beyond those defined in the TSO's. These functions have been evaluated as part of the initial STC. However, for some installation certifications additional information (drawing lists and software documentation) may be required for aircraft installation certification. Contact UPS Aviation Technologies Customer Support for assistance in providing the additional information required for installation certification.

## 1.4.2 TSO AUTHORIZATION

**Table 1-1 - TSO Authorization**

Function	TSO	Minimum Performance Standard	Software RTCA/DO-178B
Com	TSO-C37d, Transmitter, 100nm range TSO-C38d, Receiver TSO-C128, Stuck Mic	RTCA/DO-186A, Class 4, RTCA/DO-186A, Class D RTCA/DO-207	Level C
VOR/ILS	TSO-C34e, Glideslope TSO-C36e, Localizer TSO-C40c, VHF Omni Range	RTCA/DO-192, Cat B RTCA/DO-195, Cat A RTCA/DO-196, Cat B	Level C
GPS/WAAS	TSO-C146a	RTCA/DO-229C, Class 1	Level B
MFD	TSO-C113, Display	SAE AS 8034	Level B

## 1.4.3 FCC GRANT OF EQUIPMENT AUTHORIZATION

- FCC ID: EOJ52ICOM96

## 1.4.4 CNX80 STC AUTHORIZATION

Refer to UPSAT document 560-0988-00 for data regarding CNX80 STC authorization.

## 1.5 DATABASE UPDATES

The CNX80 utilizes a database stored on a Compact Flash Memory datacard for easy updating and replacement. The database is updated by simply inserting an updated database card into the slot in the front panel in the CNX80.

The CNX80 comes with a compact flash memory card reader/writer (R/W). The R/W is intended for updating the included database card using a PC. Refer to the installation manual included with the R/W for instructions on how to install and operate the compact flash R/W.

The database on the CNX80 database card is generated from current Jeppesen-Sanderson data and converted to a format that is used by the CNX80. The data conversion process is performed using software that is developed and maintained under UPS Aviation Technologies configuration management according to RTCA/DO-200A, Standards for Processing Aeronautical Data.

CNX80 users update their database card by purchasing database subscription updates from Jeppesen-Sanderson. The database card is programmed using the supplied compact flash memory card R/W and Jeppesen-provided software. Contact Jeppesen at 800-621-5377 or [www.jeppesen.com](http://www.jeppesen.com) for more information and instructions.

Contact the UPS Aviation Technologies, Inc. for information on databases available for the CNX80.

**CAUTION**

**Do not insert or remove the data card within 10 seconds after the CNX80 is turned on.**

## **1.6 UNPACKING THE EQUIPMENT**

Carefully unpack the equipment. Visually inspect the package contents for any evidence of shipping damage. Retain all shipping containers and packaging material in case reshipment is necessary.

## 1.7 PACKAGE CONTENTS

As shipped from the UPS Aviation Technologies factory, the Apollo CNX80 package includes most necessary items for installation other than supplies normally available at the installation shop, such as wire and cable ties, circuit breakers, and required input and output equipment. The items included in the package are listed in Table 1-2 and Table 1-3. Optional items available are listed in Table 1-4.

**Table 1-2 - Package Contents**

Item	Qty	Description
430-6100-8hh-sss	1	CNX80 WAAS/GPS Nav Com <i>(hh defines hardware configuration and sss defines software configuration)</i>
560-0984-xx	1	CNX80 Pilot's Guide
561-0281-xx	1	CNX80 Quick Reference Guide
140-0056-xxx	1	CNX80 Product CD ( <i>includes the following</i> ) 139-0240-xxx Mission Planning Software 560-0177-xx Mission Planning Software User's Guide 560-0940-xx A33 GPS Antenna Installation Guide 560-0982-xx CNX80 Installation Manual 560-0984-xx CNX80 Pilot's Guide 560-0988-xx CNX80 STC Data 560-0990-xx CNX80 Computer-Based Training 560-5047-xx A34 GPS Antenna Installation Guide 561-0281-xx CNX80 Quick Reference Guide
138-0329-xxx	1	CNX80 Worldwide Database Card
428-0059	1	Compact Card Reader, USB
590-1104	1	A33 GPS Antenna
424-2014-8xx	1	CNX80 Installation Kit (see Table 1-3 for detail)

**Table 1-3 - Installation Kit Contents (PN 424-2014-800)**

Item	Qty	Description
310-3071-01	1	Mounting Tube, CNX80
310-3073-00	1	Connector plate CNX80
251-9615-00	6	Standoff .250sq X .502 long X.075
310-3072-00	1	Air Deflector, CNX80
162-1575	1	15 Pin Crimp D-Sub Receptacle
162-1577	2	37 Pin Crimp D-Sub Receptacle
162-0109	1	78 Pin Crimp Hi Density D-Sub Plug
245-0027	60	20-24 AWG female crimp contact
162-0082	50	22-28 AWG male crimp contact
162-1008	3	Coax Plug, right angle mount
224-0404	22	4-40 x 1/4 82 Deg SS FHP Screw
221-0400	8	4-40 X 1/4 SS PHP screw with washer
240-0425	6	#4 SS Flat washer
204-0037	0.5 ft	.062 Black Flexible Grommet

**Table 1-4 - Optional Equipment Available from UPSAT**

Item	Description
115-0007	Splitter, 2-way, 50 ohm, BNC (NAV/VOR/Localizer/Glideslope)
162-0098	Coax Plug, straight mount with BNC female
162-1059	Notch Filter, 1575 MHz, BNC Male/Female
590-1112	A34 GPS Antenna

## 1.8 LICENSE REQUIREMENTS

An aircraft radio station license is not required when operating in U.S. airspace, but may be required when operating internationally.

## 1.9 DEFINITIONS & ACRONYMS

ADC	Air Data Computer
ALT	Altitude
APPRCH	Approach
COM	VHF Communication
DDM	Differential Depth of Modulation
DP	Departure Procedure
EN	Engineering Notice
FADC	Fuel/Air Data Computer
GPS	Global Positioning System
ILS	Instrument Landing System
LAAS	Local Area Augmentation System
LCD	Liquid Crystal Display
LNAV	Lateral Navigation
LOC	Localizer
MFD	Multi-Function Display
NAV	VHF Navigation
NDB	Non-Directional Beacon
OBS	Omni-Bearing Selector
PDA	Personal Digital Assistant
PTK	Parallel Track
SDI	Source Destination Identifier
SID	Standard Instrument Departure
STAR	Standard Terminal Arrival Route
STC	Supplementary Type Certificate
TFR	Temporary Flight Restriction
TSO	Technical Standard Order
VDI	Vertical Deviation Indicator
VNAV	Vertical Navigation
VOR	Very High Frequency Omni-Directional Range
WAAS	Wide Area Augmentation System
XPDR	Transponder



## 2 INSTALLATION

This section describes the installation of the Apollo CNX80 including mounting, wiring, and connections. Post-Installation configuration and checkout procedures are included in section 3.

### 2.1 PRE-INSTALLATION INFORMATION

Always follow acceptable avionics installation practices per FAA Advisory Circulars (AC) 43.13-1A, 43.13-2A, or later FAA approved revisions of these documents.

Follow the installation procedure in this section as it is presented for a successful installation. Read the entire section before beginning the procedure. Prior to installation, consider the structural integrity of the CNX80 installation as defined in AC 43.13.2A, Chapter 1. Perform the post installation checkout before closing the work area in case problems occur.

Complete an electrical load analysis in accordance with AC 43.13-1B, Chapter 11, on the aircraft prior to starting modification to ensure aircraft has the ability to carry the CNX80 load. Refer to Section 2.11 for the power consumption of each CNX80 mode of operation. Document the results of the electrical load analysis on FAA Form 337.

The WAAS/GPS installation instructions have been prepared to meet the guidance material defined in AC20-138A Final Draft Airworthiness Approval of Global Navigation Satellite System (GNSS) Equipment. The communications installation instructions have been prepared to meet the guidance material defined by AC 20-67B Airborne VHF Communications Equipment Installations.

### 2.2 INSTALLATION OVERVIEW

A successful installation should start with careful planning, including determination of mounting location for the CNX80, cable routing, and other required modifications. Once the mounting location has been determined, prepare the mounting tube for installation. It may be easier to complete the wiring harness and attach the connectors to rear connector plate before attaching it to the mounting tube.

Carefully plan which external devices will be connected to the CNX80 inputs.

### 2.3 MATERIALS REQUIRED AND NOT SUPPLIED

The Apollo CNX80 is intended for use with standard aviation accessories. The following items are required for the installation, but not supplied:

- Wiring
- Mounting screws (8 min. - AN507 6-32 screw with 100° countersink, 8 - washers, 8 - 6/32 screw)
- Circuit breakers
- Antennas other than the A-33
- Tie wraps or lacing cord
- Solder lug with nut and screw

## 2.4 SPECIAL TOOLS REQUIRED

Some of the connectors use crimp contacts. The tables below identify crimp tools required to ensure consistent, reliable crimp contact connections for the rear D-sub connectors. The tables define one source for the crimp tool. Alternate equivalent tools may be used.

**Table 2-1 - Crimp Tool for P/N 162-0082**

Description	ITT/Cannon P/N	Military number
Insertion/Extraction tool CIET-22D	271-7048-000	M81969/14-01
Crimp tool	995-0001-584	M22520/2-01
Positioner	N/A	M22520/2-09

**Table 2-2 - Crimp Tool for P/N 245-0027**

Description	ITT/Cannon P/N	Military number
Insertion/Extraction tool CIET-20HD	980-200-426	M81969/39-01
Crimp tool	995-0001-584	M22520/2-01
Positioner	995-0001-604	M22520/2-08

Below is the contact for ITT/Cannon crimp tools:

ITT Cannon                      Phone (714) 261-5300  
 1851 E. Deere Ave            FAX (714) 575-8324  
 Santa Ana, CA 92705-6500

## 2.5 INSTALLATION CONSIDERATIONS

### 2.5.1 MINIMUM SYSTEM CONFIGURATION

The minimum CNX80 installation requires the following additional items:

- Altitude source - only required if course to altitude (CA) and heading to altitude (VA) leg types will be used
- External CDI/HSI indicator installed in the pilot's primary field of view (i.e. within 15 degrees of the pilot's primary line of sight). This indicator must meet the following criteria:
  1. The course deviation indicator shall have an input impedance of  $1 \text{ k}\Omega \pm 10\%$  and a deflection sensitivity of  $150 \text{ mV} \pm 10\%$  for full scale deflection.
  2. The valid flag shall have an input impedance of  $1 \text{ k}\Omega \pm 10\%$ .
  3. The valid flag sensitivity shall be  $125 \text{ mV} \pm 10\%$  for the flag to leave the stop and  $260 \text{ mV} \pm 10\%$  maximum for flag to be fully concealed.
  4. The TO/FROM flag shall have an input impedance of 200 ohms  $\pm 10\%$  and a sensitivity of  $\pm 40 \text{ mV} \pm 15\%$  at  $25^\circ\text{C}$  with flag fully in view.
  5. The OBS resolver should be compatible with a standard 6-wire OBS interface:

- H.....Reference output high
- C.....Reference output low
- D.....S1 COS input high
- E.....S3 COS input low
- F.....S4 SIN input high
- G.....S2 SIN input low

Any electrical zero crossing will work because the CNX80 will calibrate out any errors.

- External non-numeric glideslope indicator installed in the pilot's primary field of view. This indicator must meet the following criteria:
  1. The glideslope deviation shall have an input impedance of  $1\text{ k}\Omega \pm 10\%$  with a deflection sensitivity of  $150\text{ mV} \pm 10\%$  for full scale deflection.
  2. The glideslope valid flag shall have an input impedance of  $1\text{ k}\Omega \pm 10\%$ .
  3. The glideslope valid flag sensitivity shall be  $125\text{ mV} \pm 10\%$  for the flag to leave the stop, and  $260\text{ mV} \pm 10\%$  maximum for flag to be fully concealed.

## 2.5.2 EXISTING SENSORS

When the CNX80 is installed with external sensors, these sensors must be installed in accordance with the manufacturer's data. This manual does not provide information for the installation of specific external sensors.

The CNX80 can accept data from multiple altitude, heading, and baro correction sources. If multiple sources are used, the CNX80 will accept data as described below.

### 2.5.2.1 Multiple Altitude Sources

The CNX80 can accept altitude from an RS232 altitude encoder, fuel/air data computer (FADC), ARINC 429 air data computer (ADC), an SL70/SL70R transponder, and another CNX80.

If multiple sources of altitude data are supplied to the CNX80, only valid data from the highest priority source is used (input priority cannot be configured). If the highest priority source becomes unavailable, data is taken from the next-highest priority source. The priorities of the altitude sources are as follows (from highest to lowest):

1. ARINC 429 ADC
2. FADC
3. RS232 Altitude Encoder

**NOTE**

Although the CNX80 can be configured to accept data from an RS232 altitude encoder on different ports, the CNX80 cannot accept data from two RS232 altitude encoders.

4. SL70/SL70R Transponder that receives Gray code altitude

**NOTE**

Altitude data received from a second CNX80 will also be derived from one of the above sources. Data received on the CNX80 cross-talk input is treated as if it is received directly from the source that is supplying altitude to the second CNX80. If the direct input and the CNX80 cross-talk input have the same priority, data from the direct input is used.

### 2.5.2.2 Multiple Heading Sources

The CNX80 can accept heading from an ARINC 429 Heading Source, an FADC or an XYZ synchro source.

If multiple sources of heading data are supplied to the CNX80, only valid data from the highest priority source is used (input priority cannot be configured). If the highest priority source becomes unavailable,

data is taken from the next-highest priority source. The priorities of the altitude sources are as follows (from highest to lowest):

1. ARINC 429 Heading Source
2. FADC
3. XYZ Synchro

### **2.5.2.3 Multiple Baro Correction Sources**

The CNX80 can accept barometric correction from an altimeter with a baro correction potentiometer output, ARINC 429 ADC, FADC, MX20 display or another CNX80.

If multiple sources of barometric correction data are supplied to the CNX80, only valid data from the highest priority source is used (input priority cannot be configured). If the highest priority source becomes unavailable, data is taken from the next-highest priority source. The priorities of the barometric correction sources are as follows (from highest to lowest):

1. Baro correction potentiometer (from altimeter)
2. FADC
3. ADC (correction derived from ARINC 429 labels 203 and 204)
4. MX20 Display
5. Manual entry into CNX80 (allowed only if no other baro correction sources are available)

#### **NOTE**

Baro correction data received from a second CNX80 will also be derived from one of the above sources. Data received on the CNX80 cross-talk input is treated as if it is received directly from the source that is supplying baro correction to the second CNX80. If the direct input and the CNX80 cross-talk input have the same priority, data from the direct input is used.

### **2.5.3 MOUNTING CONSIDERATIONS**

The CNX80 is designed to mount in the avionics stack in the aircraft instrument panel within view and reach of the pilot. The CNX80 must be located in the pilot's normal field of view where the operator will have easy access to the controls and adequate viewing of the display. The preferred location would minimize pilot head movement when transitioning between looking outside of the cockpit and viewing and operating the CNX80. Refer to 2.6.1 for additional information.

The standard package includes a mounting tube with a separate connector plate for ease of mounting, connections, and service of the unit. Allow an additional one-inch clearance to the rear of the mounting frame for connectors and cables. See Figure 2-1 for dimensions.

The CNX80 does not require external cooling; however, when mounting the CNX80, ensure that the fans at the rear of the unit are not blocked. As with all electronic equipment, avoid locating the CNX80 near sources that produce high levels of heat.

### **2.5.4 CABLING AND WIRING**

Wiring should be installed in accordance with AC 43.13-1B Chapter 11. For dual CNX80 installations, care should be taken to ensure separation between wires of redundant systems to reduce the possibility of loss of navigation due to a single event. When wire separation cannot be achieved, the following issues should be addressed:

- It should not be possible for a cable harness to be exposed to wire chafing in a manner that both GPS units fail simultaneously;
- The cable harness should not be located near flight control cables and controls, high electrical capacity lines or fuel lines;
- The cable harness should be located in a protected area of the aircraft (e.g., isolated from engine rotor burst); and
- Do not route cable near high-energy sources

Refer to the Electrical Connections in Appendix D for the appropriate wiring connections to assemble the wiring connector. Once the cable assemblies have been made, attach the cable connectors to the rear connector plate. After installing the mounting tube, attach the assembled connector. Route the wiring bundle as appropriate. Use 22 to 24 AWG wire for all connections except for power. Use 20 AWG for power/ground. Avoid sharp bends.

### **2.5.5 AIR CIRCULATION AND COOLING**

The CNX80 has internal fans for cooling. No external cooling is required. No special provisions are required during installation to accommodate the fans except to ensure the fan openings are not blocked.

### **2.5.6 COMPASS SAFE DISTANCE**

After reconfiguring the avionics in the cockpit panel, if the CNX80 is mounted less than seven inches from the compass, recalibrate the compass and make the necessary changes for noting correction data.

### **2.5.7 VIEWING ANGLE**

The CNX80 shall be located such that the operator will have easy access to the controls and have adequate view of the display. The CNX80 may be adequately viewed from the primary pilot's position when the following minimums are met:

Up:	60 degrees off pilot's eye center line
Down:	35 degrees off pilot's eye center line
Right:	60 degrees off pilot's eye center line
Left:	60 degrees off pilot's eye center line

### **2.5.8 HELICOPTER INSTALLATION**

The CNX80 is qualified for helicopter installation – no special mounting tubes or other hardware is required.

## **2.6 EQUIPMENT MOUNTING**

There are four basic steps to installing the Apollo CNX80. First, identify the location for mounting the CNX80 in the aircraft. Second, drill the holes for the mounting screws and mount the CNX80 tube. Third, fabricate the wiring harness and attach the connectors to the assembled rear connector plate. Route the appropriate wiring and attach the connector plate to the CNX80 mounting tube. Fourth, test for proper operation.

## **2.6.1 MOUNTING LOCATION**

Locate the Apollo CNX80 within the pilot's normal field of view. If the CNX80 is located in the center radio stack, the lateral normal field of view is from the center of the airspeed indicator to and including the CNX80. If the CNX80 is installed to the left of the airspeed indicator, the lateral normal field of view is the center of the altimeter to and including the CNX80. The location should be such that the CNX80 is not blocked by the glareshield on top, or by the throttles, control yoke, etc. on the bottom.

## **2.6.2 MOUNTING TUBE INSTALLATION**

Use the dimensions shown in Figure 2-1 to prepare the mounting holes for the Apollo CNX80. You may also use the CNX80 mounting tube itself as a template for drilling the mounting holes. Care must be taken when installing the mounting tube to ensure you can properly insert and secure the unit. There must be a minimum vertical spacing of 0.040 inches between units to prevent interference with the cam locking mechanisms. Mounting tubes with clearance dimples help maintain the proper clearance. The mounting tube must be installed with the clearance dimples pointing up.





Figure 2-1 - CNX80 Dimensions



**Figure 2-2 - Typical Mounting Rack**

#### 2.6.2.1 Securing the Mounting Tube

Secure the mounting tube to the instrument panel structure using AN507 6-32 screws with a 100° countersink head. It is recommended that the installer use eight screws, four on each side. The mating holes in the instrument panel structure must also be countersunk to accept the screw head so that the screw head is flush with the inside surface of the mounting tube. Take care that the mounting tube is not distorted when it is attached to the instrument panel and structural supports. Shims may be necessary to properly install the mounting tube. If the mounting tube is distorted out of square, the unit may either bind when being inserted or the cam lock may not engage.

#### CAUTION

**Failure to properly countersink the mounting holes will result in damage to the CNX80. Mounting screw heads must not protrude into the mounting tube.**

The front of the mounting tube should be flush to the instrument panel and allow sufficient clearance for the back of the bezel of the CNX80 to mount flush to the mounting tube. Sufficient clearance must exist in the instrument panel opening to allow ease of insertion and removal of the CNX80.

**CAUTION**

If the back of the CNX80 bezel does not mount flush to the mounting tube (within 0.020"), the connector may not engage fully.

### 2.6.2.2 Mounting Frame Assembly

The order of assembly of the mounting tube frame with connector plate and connectors is at the installer's preference or may be determined by how the installation is fit into the aircraft. An illustration how to assemble the mounting tube is shown in Figure 2-4.

All screws holding the connectors to the back plate and back plate to the mounting tube should be tightened to approximately to 7 – 9 in-lbs. After mounting the coax connectors to the connector plate, make sure that the coax connectors are floating or have slight movement.

**NOTE**

The washer must be installed with the smooth (rounded) surface facing the RF connector; otherwise, the RF connectors may bind when the screws are tightened.

Refer to Section 2.7 Electrical Connections for details about how to wire the connectors.


### 2.6.2.3 Mounting Tube Cable Routing

After the cable assemblies are made and wiring installed to the mounting tube back plate, route wiring bundle as appropriate.

Use tie wraps to secure the cable assemblies and coax to the holes provided in the bottom of the connector plate to provide strain relief for the cable assemblies. The cable shields should be grounded directly to a lug mounted to one of the holes on the bottom of the connector plate, keeping the ground leads to a maximum of 3 inches long.

### 2.6.3 UNIT INSERTION

Position the cam lock as shown below. The front lobe of the cam should be vertical. The cam lock mechanism should be fully unscrewed (turned counter-clockwise). Slide the unit into the frame. Turn clockwise and carefully tighten (15 in-lb max.) the cam lock mechanism using a 3/32" hex driver. The unit will be pulled into the frame, securing the unit and connectors when fully engaged. **Do NOT overtighten.** The back of the bezel must be flush to the mounting tube (within 0.020"). If the cam lock is hard to turn or the unit does not seat fully, the unit is probably binding and the mounting tube should be checked.




**Figure 2-3 - Cam Lock Positioning**

## **2.6.4    UNIT REMOVAL**

To remove the unit from the mounting frame, turn the screw counter-clockwise with the hex driver to unscrew the cam lock mechanism. The unit will begin to pull away from the mounting tube. Turn the screw until slight resistance is felt and then pull the unit from the frame. **Do not exert excessive turning force at the end of the cam lock travel or the unit may be damaged.** With the cam lock fully disengaged, pull the unit straight out while holding onto the sides of the bezel. It is not recommended that you pull the unit out by the rotary knobs. No special extraction tools are required if the mounting tube is properly installed.

## **2.6.5    UNIT REPLACEMENT**

Whenever the CNX80 is removed and replaced, accomplish the appropriate equipment operational/functional tests defined in 3.3. If the unit was serviced or a different unit is being installed, accomplish the setup and configuration procedures defined in 3.2 prior to carrying out the operational/functional tests.

**TSO PENDING****Figure 2-4 - Mounting Frame Assembly**

## 2.7 ELECTRICAL CONNECTIONS

The Apollo CNX80 installation kit includes four D-sub connectors and three coax connectors. The connector layouts are shown in Figure 2-5. The D-sub connectors use the supplied crimp contacts as specified in Table 2-3. Make the crimp connections with the crimp tool specified Section 2.4.

**Table 2-3 - Interface Connectors**


<b>Figure 2-5</b>		<b>Connector</b>		<b>Crimp Contact</b>	
<b>Ref.</b>	<b>Description</b>	<b>P/N</b>	<b>Description</b>	<b>P/N</b>	<b>Description</b>
P1	Main System	162-1577	37 Pin D-Sub Receptacle	245-0027	20-24 AWG socket contact
P2	GPS antenna	162-1008	Coax Plug, right angle mnt	N/A	N/A
P3	Com antenna	162-1008	Coax Plug, right angle mnt	N/A	N/A
P4	Com I/O	162-1575	15 Pin D-Sub Receptacle	245-0027	20-24 AWG socket contact
P5	I/O Expansion	162-0109	78 Pin D-Sub Plug	162-0082	22-28 AWG pin contact
P6	NAV antenna	162-1008	Coax Plug, right angle mnt	N/A	N/A
P7	NAV I/O	162-1577	37 Pin D-Sub Receptacle	245-0027	20-24 AWG socket contact

The following table shows the specifications for the crimp contacts. Alternate crimp contact part numbers may be used that are equivalent to those specified in the table below. See Section 2.4 for the appropriate crimp tool examples.

**Table 2-4 - Crimp Contact Specifications**

<b>UPSAT Part Number</b>	<b>162-0082</b>	<b>245-0027</b>
<b>Description</b>	22-28 AWG crimp pin contact	20-24 AWG crimp socket contact
<b>Color bands</b>	Orange/Blue/Black	Orange/Blue/Gray
<b>ITT/Cannon P/N</b>	030-2042-000	031-1007-042
<b>Military number</b>	M39029/58-360	M39029/63-368

### 2.7.1 INTERFACE CONNECTOR DEFINITION



**Figure 2-5 - Rear Mounting Tube Connector Layout**

**NOTE**


The rear connector plate is shown with right-angle RF connectors. Straight RF connectors with female BNC connections (UPSAT P/N 162-0098) are available as an option, allowing a regular male BNC connector to be used on the antenna cables.

### 2.7.1.1 Main System Connector (P1)

The interface to external equipment is made through a standard male 37-pin D-sub connector near the middle of the unit. The pin-out for the connector is defined in the following table.

**Table 2-5 Main System Connector Pin-Out (P1)**

Pin #	I/O	Name	Description	Reference
1	I	Power +	Main Aircraft Power Input (+10 to +36 VDC)	2.8.1
2	I	Power Ground	Main Aircraft Power Ground	
3	O	Serial Ground 2	RS232 signal ground	2.8.10.1
4	I	RS232 RxD1	RS232 channel 1 serial data input	
5	O	RS232 TxD1	RS232 channel 1 serial data output	
6	O	RS232 TxD3	RS232 channel 3 serial data input	
7	I	RS232 RxD3	RS232 channel 3 serial data output	
8	O	RS422 TxD4 +	RS422 channel 4 serial data output +	
9	--	RESERVED	RESERVED	
10	O	RS422 TxD4 -	RS422 channel 4 serial data output -	2.8.10.1
11	I	RS422 RxD4 +	RS422 channel 4 serial data input +	
12	--	RESERVED	RESERVED	
13	--	RESERVED	RESERVED	
14	I	Com Flip Flop In	COM Flip-Flop discrete input (active low)	2.8.9.2
15	I	UP Discrete In	Activate COM User list and scrolls up (active low)	2.8.9.5
16	I	Power +	Main Aircraft Power Input (+10 to +36 VDC)	2.8.1
17	O	Time Mark Out +	GPS 1 Pulse Per Second Output + (RS422 Level)	2.8.11
18	--	RESERVED	RESERVED	
19	O	Time Mark Out -	GPS 1 Pulse Per Second Output - (RS422 Level)	2.8.11
20	I	Power Ground	Main Aircraft Power Ground	2.8.1
21	I	RS232 RxD2	RS232 channel 2 serial data input	2.8.10.1
22	O	RS232 TxD2	RS232 channel 2 serial data output	
23	O	Serial Ground 1	RS232 signal ground	
24	--	RESERVED	RESERVED	
25	O	Serial Ground 3	RS232 signal ground	2.8.10.1
26	I	RS422 RxD4 -	RS422 channel 4 serial data input -	
27	--	RESERVED	RESERVED	
28	--	RESERVED	RESERVED	
29	--	RESERVED	RESERVED	
30	--	RESERVED	RESERVED	
31	--	RESERVED	RESERVED	
32	I	Power Ground	Main Aircraft Power Ground	2.8.1
33	I	DOWN Discrete In	Activate COM User list and scrolls down (active low)	2.8.9.5
34	I	VOR Flip Flop In	VOR Flip-Flop discrete input (active low)	2.8.9.3
35	I	Power + Out (Nav)	Main Power Output for Nav Receiver	2.8.1
36	--	RESERVED	RESERVED	
37	I	Power Gnd Out (Nav)	Main Power Ground Output for Nav Receiver	2.8.1




**Figure 2-6 - 37-pin Connector**

**TSO PENDING****2.7.1.2 Com I/O Connector (P4)**

The CNX 80 communication interface is handled via a standard density male 15-pin D-sub connector located at the top of the unit. Internally this connection is on the VHF COM board. The pinout for the connector is defined in the following table.

**Table 2-6 COM I/O Connector Pin-Out (P4)**

Pin #	I/O	Name	Description	Reference
1	I	Aircraft Power	Main Aircraft Power Input (+10 to +36 VDC)	2.8.1
2	--	RESERVED	RESERVED	
3	--	RESERVED	RESERVED	
4	I	PTT	Push To Talk, Transmit Key (active low)	2.8.9.4
5	--	RESERVED	RESERVED	
6	O	Com Speaker Out	Speaker output (high-level audio)	2.8.12.1
7	I	Com MIC In Low	Microphone input - analog ground	2.8.12.2
8	I	Com MIC In High	Microphone input - High	
9	I	Power Ground	Main Aircraft Power Ground	2.8.1
10	--	RESERVED	RESERVED	
11	--	RESERVED	RESERVED	
12	--	RESERVED	RESERVED	
13	O	Com Audio Ground	Speaker or Headphone output ground	2.8.12.1
14	O	Com Headphone Out	Headphone output (low-level audio)	
15	--	RESERVED	RESERVED	



VIEW LOOKING AT REAR OF UNIT

**Figure 2-7 - 15-Pin Connector**

### 2.7.1.3 I/O Expansion Connector (P5)


Additional I/O for the CNX80 is achieved via the I/O expansion connector, which consists of a high density female 78-pin D-sub connector near the bottom of the unit. The pinout for the connector is defined in the following table.

**Table 2-7 I/O Expansion Connector Pin-Out (P5)**

Pin #	I/O	Name	Description	Reference
1	I	RS232 RxD5	RS232 channel 5 serial data input	2.8.10.1
2	I	RS232 RxD6	RS232 channel 6 serial data input (opto-isolated)	
3	--	RESERVED	RESERVED	
4	O	429 OUT 1A	ARINC 429 Output Channel 1A	2.8.10.2
5	O	429 OUT 2A	ARINC 429 Output Channel 2A	
6	--	RESERVED	RESERVED	
7	I	429 IN 1A	ARINC 429 Input Channel 1A	2.8.10.2
8	I	429 IN 2A	ARINC 429 Input Channel 2A	
9	I	429 IN 3A	ARINC 429 Input Channel 3A	
10	I	RS232 RxD7	RS232 channel 7 serial data input (receive-only channel)	2.8.10.1
11	--	RESERVED	RESERVED	
12	--	RESERVED	RESERVED	
13	I	Baro In (W)	Baro Correction Input (wiper)	2.8.5
14	I/O	DME Clock Bus	Digital Serial DME Clock Bus	2.8.16
15	I/O	DME Data Bus	Digital Serial DME Data Bus	
16	O	OBI Clock	Digital OBI Clock	2.8.15.1
17	O	OBI Data	Digital OBI Data	
18	I	Hdg Synchro Y	Heading Synchro Input (Y)	2.8.6
19	I	Hdg Synchro X	Heading Synchro Input (X)	
20	I	Hdg Synchro Ref Hi	Heading Synchro Reference In (Hi)	
21	O	RS232 TxD5	RS232 channel 5 serial data output	2.8.10.1
22	O	RS232 TxD6	RS232 channel 6 serial data output (opto-isolated)	
23	--	RESERVED	RESERVED	
24	O	429 OUT 1B	ARINC 429 Output Channel 1B	2.8.10.2
25	O	429 OUT 2B	ARINC 429 Output Channel 2B	
26	--	RESERVED	RESERVED	
27	I	429 IN 1B	ARINC 429 Input Channel 1B	2.8.10.2
28	I	429 IN 2B	ARINC 429 Input Channel 2B	
29	I	429 IN 3B	ARINC 429 Input Channel 3B	
30	I	RS232 RxD8	RS232 channel 8 serial data input (receive-only channel)	2.8.10.1
31	--	RESERVED	RESERVED	
32	--	RESERVED	RESERVED	
33	O	Baro Hi	Baro Correction Excitation Output	2.8.5
34	I	DME Select In	Digital Serial DME Select (active low)	2.8.16
35	I	DME Channel Req	Digital Serial DME Channel Request (RNAV)	
36	I	OBI Select In	RMI Selection input (Open = GPS, GND = NAV)	2.8.15.2
37	O	OBI Sync	Digital OBI Sync Pulse	2.8.15.1
38	I	Hdg Synchro Z	Heading Synchro Input (Z)	2.8.6
39	I	Hdg Synchro Ref Lo	Heading Synchro Reference In (Lo)	
40	O	Message Audio Out	Low Level Message Audio Out (to audio panel)	2.8.14.1
41	O	Serial Ground 5	RS232 signal ground	2.8.10.1
42	O	Serial Ground 6	RS232 signal ground	
43	O	Message Audio Gnd	Message Audio ground signal (or spare ground)	2.8.14.1

**Table 2-7 I/O Expansion Connector Pin-Out (P5)**

<b>Pin #</b>	<b>I/O</b>	<b>Name</b>	<b>Description</b>	<b>Reference</b>
44	O	Serial Ground 7/8	RS232 signal ground (or spare ground)	2.8.10.1
45	O	Aux CDI +Left	GPS CDI Left	2.8.3
46	O	Aux CDI +Right	GPS CDI Right	
47	O	Aux CDI +TO	GPS TO Flag	
48	O	Aux CDI +FROM	GPS FROM Flag	
49	O	Aux CDI +Valid	GPS CDI Valid Flag	
50	O	Aux VDI +Up	GPS VDI Up	
51	O	Aux VDI +Down	GPS VDI Down	
52	O	Aux VDI +Valid	GPS VDI Valid Flag	
53	O	Baro Lo	Baro Correction Return (Ground)	2.8.5
54	O	Aux CDI -Valid	GPS CDI Valid Return	2.8.3
55	O	Aux VDI -Valid	GPS VDI Valid Return	
56	--	RESERVED	RESERVED	
57	I	Heading Valid In	Syncro Heading Valid Input	2.8.6
58	--	RESERVED	RESERVED	
59	--	RESERVED	RESERVED	
60	O	Dead Reck Annunciate	Dead Reckoning Annunciator (active low)	2.8.7.3
61	O	Approach Annunciate	Approach Active Annunciator (active low)	2.8.7.4
62	O	Parallel Track Annnc	Parallel Track Annunciator (active low)	2.8.7.5
63	O	Suspend Annunciate	Suspend Annunciator (active low)	2.8.7.6
64	O	Message Annunciate	Message Annunciator (active low)	2.8.7.7
65	O	LOI Annunciate	Loss of Integrity Annunciator (active low)	2.8.7.8
66	O	Waypoint Annunciate	Waypoint Annunciator (active low)	2.8.7.9
67	O	Term Mode Annnc	Terminal Mode Annunciator (active low)	2.8.7.10
68	O	Precision Appr	Precision Approach Output (active low)	2.8.8.2
69	O	Altitude Alert Annnc	Low Altitude Alert Annunciator (active low)	2.8.7.11
70	O	Audio Msg Active Out	Audio Message Active Annunciator (active low)	2.8.8.3
71	--	RESERVED	RESERVED	
72	--	RESERVED	RESERVED	
73	--	RESERVED	RESERVED	
74	--	RESERVED	RESERVED	
75	--	RESERVED	RESERVED	
76	I	Suspend In	Suspend, places auto sequencing on hold (active low)	2.8.9.6
77	I	Audio Inhibit In	Inhibit Audio Messages, (active low)	2.8.9.7
78	--	RESERVED	RESERVED	



*VIEW LOOKING AT REAR OF UNIT*

## **Figure 2-8 - 78-Pin Connector Detail**

**TSO PENDING****2.7.1.4 Nav I/O Connector (P7)**

A navigation I/O connector, which handles VHF NAV / GPS switching, resolver and main CDI/VDI interfaces, is located vertically on the left side of the rear panel. The NAV I/O hooks internally to the VHF NAV board and consists a standard 37-pin D-sub connector, and has a pinout similar to the SL30 VHF NAV unit for simpler field upgrading. The pinout for the connector is defined in the following table.

**Table 2-8 NAV I/O Connector Pin-Out (P7)**

<b>Pin #</b>	<b>I/O</b>	<b>Name</b>	<b>Description</b>	<b>Reference</b>
1	I	Power +	Main Aircraft Power Input (+10 to +36 VDC)	2.8.1
2	I	Power ground	Main Aircraft Power Ground	
3	O	Spare ground	No current assignment	
4	--	RESERVED	RESERVED	
5	--	RESERVED	RESERVED	
6	--	RESERVED	RESERVED	
7	I	OBS_D {S1}	OBS Resolver input pin from channel D (COS)	2.8.2
8	I	Main CDI Select In	Selects between GPS & VHF NAV on Main CDI Output	2.8.9.1
9	O	Main GS Superflag	Glideslope Indicator Valid flag output (high-level )	2.8.2
10	O	Main CDI + Valid	Nav Valid flag output (low-level)	
11	O	Main CDI + FROM	+ From flag output	
12	O	Main CDI + TO	+ To flag output	
13	O	Main CDI + Right	CDI + Right output	
14	O	Main CDI + Left	CDI + Left output	
15	O	Back Course Out	active low output when reverse sensing is engaged	2.8.7.2
16	O	OBS_F {S4}	OBS OBS Resolver input pin from channel F (SIN)	2.8.2
17	O	GPS Indicator Out	active low output when GPS selected on Main CDI output	2.8.7.1
18	O	NAV Indicator Out	active low output when VHF NAV selected on Main CDI out	
19	O	Composite Out	VOR/LOC composite signal	2.8.4
20	O	NAV Audio Ground	audio signal ground pin	2.8.13.1
21	--	RESERVED	RESERVED	
22	--	RESERVED	RESERVED	
23	O	NAV Audio Out	low-level nav audio output	2.8.13.1
24	O	OBS_H {R HI}	OBS Resolver output pin to channel H	2.8.2
25	O	OBS_C {R LO}	OBS Resolver return signals C	
26	I	OBS_E {S3}	OBS Resolver return signals E	
27	O	Main CDI Superflag	CDI high-level Valid flag output	
28	O	Main GS + Valid	Nav Valid flag output (low-level )	
29	O	Main CDI - Valid	Nav Valid flag signal ground	
30	O	Main GS + Up	Glideslope + Up output	
31	O	Main GS + Down	Glideslope + Down output	
32	O	Main GS - Valid	Glideslope Valid flag signal ground	
33	O	ILS Energize	active low output when a localizer frequency is tuned	2.8.8.1
34	O	OBS_G {S2}	OBS Resolver return signals G	2.8.2
35	--	RESERVED	RESERVED	
36	O	Power Control Out	power control output sinks up to 50ma when unit is on	2.8.8.4
37	O	Composite Ground	return path for the composite signal	2.8.4

(see Figure 2-6 for a diagram of a 37-pin connector)

## 2.8 FUNCTIONAL DESCRIPTIONS

### 2.8.1 POWER

Aircraft power is provided to the CNX80 on several connectors. The CNX will accept input power from 10 to 36 VDC.

P1-1	Power + (Primary)
P1-16	Power + (Primary)
P1-35	Power + Out (Nav)
P4-1	Power + (Com transceiver)
P7-1	Power + (Nav receiver)
P1-2	Power Ground (Primary)
P1-20	Power Ground (Primary)
P1-37	Power Gnd Out (Nav)
P4-9	Power Ground (Com transceiver)
P7-2	Power Ground (Nav functions)

**CAUTION**

**Two sets of primary power and ground pins are provided on P1. Both sets MUST be connected to the aircraft power source or damage to the unit may occur.**

Refer to Appendix D for recommended power connections.

### 2.8.2 MAIN COURSE DEVIATION INDICATOR

The Main CDI output displays both lateral and vertical deviation from selected course, lateral and vertical flags and superflags, and TO/FROM indications.

The CDI key on the bezel of the CNX80 is used to toggle between the display of GPS and VOR/ILS information on the CDI window and remote CDI. The navigation source is displayed in the CDI window. The navigation source can optionally be annunciated externally by connecting the GPS Indicator output (P7-17) and NAV Indicator output (P7-18). The selection of GPS or VOR/ILS navigation sources may be toggled remotely by momentarily grounding the CDI Select input (P7-8) is (refer to section 2.8.4 for additional information on the external annunciators and switches).

Refer to Appendix D for interconnect information.

#### 2.8.2.1 Deviation Outputs

P7-13	Main CDI + Right
P7-14	Main CDI + Left
P7-30	Main GS + Up
P7-31	Main GS + Down

Each deviation output provides  $\pm 150$  mV full scale and is capable of driving up to a  $200\Omega$  load.

**TSO-PENDING****2.8.2.2 TO / FROM Output**

- P7-11 Main CDI + FROM
- P7-12 Main CDI + TO

The TO / FROM output provides  $\pm 250$  mV and is capable of driving up to a  $200\Omega$  load.

**2.8.2.3 Flags**

- P7-10 Main CDI + Valid
- P7-29 Main CDI - Valid
- P7-28 Main GS + Valid
- P7-32 Main GS - Valid

Each flag output provides  $+300$  mV when valid information is present and is capable of driving up to a  $200\Omega$  load.

**2.8.2.4 Superflags**

- P7-9 Main GS Superflag
- P7-27 Main CDI Superflag

Each flag output provides  $(V_{in} - 2)$  volts relative to ground when valid information is present, where  $V_{in}$  represents the aircraft power supplied to the CNX80. Each output is capable of supplying up to 400 mA.

**2.8.2.5 OBS Resolver**

The OBS resolver input should be compatible with a standard 6-wire OBS interface: Any electrical zero crossing will work because the SL30 will calibrate out any errors.

- P7-7 OBS\_D {S1} (COS input high)
- P7-16 OBS\_F {S4} (SIN input high)
- P7-24 OBS\_H {R HI} (Reference output high)
- P7-25 OBS\_C {R LO} (Reference output low)
- P7-26 OBS\_E {S3} (COS input low)
- P7-34 OBS\_G {S2} (SIN input low)

**NOTE**

The CNX80 cannot drive multiple resolvers at the same time. It is not recommended that external resolvers be switched through a relay or other means because the resolver must be calibrated to the radio. If multiple resolvers are desired in the installation, the primary unit must be installed and calibrated as described here. The secondary unit should use the composite output.

Refer to section 3.2.1.3 for information on calibrating the resolver input.

**2.8.3 AUXILIARY COURSE DEVIATION INDICATOR**

The Auxiliary CDI output displays both lateral and vertical deviation from selected course, lateral and vertical flags, and TO/FROM indications. This output is always based upon GPS information, regardless of the navigation source that is selected for the Main CDI output using the CDI bezel key. Since the

Main CDI output can be switched between GPS and VOR/ILS, it is not necessary to use these outputs to drive an indicator. It is only necessary if it is desired to have a separate indicator display GPS deviation information full-time. This output does not provide superflag outputs, so if superflags are required a converter box must be used to generate the required signals using the low-level valid flags.

Refer to Appendix D for interconnect information.

#### **2.8.3.1 Deviation Outputs**

- P5-45 Aux CDI + Left
- P5-46 Aux CDI + Right
- P5-50 Aux GS + Up
- P5-51 Aux GS + Down

Each deviation output provides  $\pm 150$  mV full scale and is capable of driving up to a  $200\Omega$  load.

#### **2.8.3.2 TO / FROM Output**

- P5-47 Aux CDI + TO
- P5-48 Aux CDI + FROM

The TO / FROM output provides  $\pm 250$  mV and is capable of driving up to a  $200\Omega$  load.

#### **2.8.3.3 Flags**

- P5-49 Aux CDI + Valid
- P5-54 Aux CDI - Valid
- P5-52 Aux VDI + Valid
- P5-55 Aux VDI - Valid

Each flag output provides  $+300$  mV when valid information is present and is capable of driving up to a  $200\Omega$  load.

### **2.8.4 COMPOSITE INDICATOR**

The CNX80 provides a standard VOR/localizer composite output signal that may be used to drive the left/right deviation, TO / FROM and valid flag indications of certain navigation indicators that contain an internal converter. If an external converter is driven from the composite output, the composite output will be disabled whenever the VOR monitor mode is active or back course localizer mode is enabled. This will cause the external converter to flag.

- P7-19 Composite Out
- P7-37 Composite Ground

In the VOR mode, the composite signal output is  $0.500$  V<sub>RMS</sub>. In the localizer mode, the composite signal output is  $0.390$  V<sub>RMS</sub>. This output is capable of driving up to a  $1000\Omega$  load.

Refer to Appendix D for interconnect information.

**TSO PENDING****2.8.5 ALTIMETER**

The CNX80 accepts altitude data serially, using either RS232 or ARINC 429 inputs. Refer to section 2.8.10 for additional information on the serial interfaces. In addition, the CNX80 can accept the baro-correction using the potentiometer output from a suitable altimeter. If baro-correction and uncorrected pressure altitude are provided to the CNX80, baro-corrected altitude will be output by the CNX80.

- P5-13 Baro In (W)
- P5-33 Baro Hi
- P5-53 Baro Lo

**CAUTION**

**The CNX80 must not be connected in parallel with other equipment using the baro pot. Damage to the CNX80 or other the equipment may occur if this is done.**

Refer to Appendix D for altimeter baro potentiometer connections to several altimeters.

Refer to section 3.2.1.4 for information on calibrating the baro potentiometer input.

**2.8.6 SYNCHRO HEADING**

The CNX80 accepts heading information using either a synchro input or an ARINC 429 input. Refer to section 2.8.10.2 for additional information on the ARINC 429 interfaces. If synchro heading is provided, refer to the paragraphs below.

Refer to Appendix D for interconnect information.

**2.8.6.1 Heading Synchro**

- P5-19 Hdg Synchro X
- P5-18 Hdg Synchro Y
- P5-38 Hdg Synchro Z

Connect these pins to an XYZ type directional gyro.

**2.8.6.2 Heading Synchro Reference Voltage**

- P5-20 Hdg Synchro Ref Hi
- P5-39 Hdg Synchro Ref Lo

A reference voltage must be provided if the synchro heading input is used. This input should be 26 VAC 400 Hz (nominal) and provided by the same source that provides the excitation voltage to the synchro heading source.

**2.8.6.3 Heading Synchro Valid Input**

- P5-57 Heading Valid In

This input is an active high discrete input that provides synchro heading validity information to the CNX80. If the voltage on this input is > 9 VDC the synchro heading is considered valid, and if the voltage is < 9 VDC (or the input is open-circuit) the synchro heading is considered invalid.

## 2.8.7 ANNUNCIATOR OUTPUTS

### NOTE

Installations in conformance with the requirements specified in this installation manual do not require the use of any external annunciators or switches, since all annunciations and switches are provided on the CNX80 front panel.

All of the annunciator outputs duplicate annunciations available on the front of the CNX80. These can be used to drive annunciator lamps to make the annunciation available remotely (such as in the pilot's primary field of view). All of these outputs are active low (i.e. grounded when active, and open otherwise). Each is an open collector output capable of sinking up to 400 mA. These outputs are normally open and are only grounded under the conditions described herein.

### 2.8.7.1 GPS / Nav Annunciations

P7-17 GPS Indicator Out

P7-18 NAV Indicator Out

The GPS Indicator Out (P7-17) will be grounded when GPS is being used as the navigation source to drive the Main CDI, and open otherwise. The NAV Indicator Out (P7-18) will be grounded when VOR/ILS is being used as the navigation source to drive the Main CDI, and open otherwise.

If external annunciators are used for the GPS/Nav annunciation, it is recommended that the GPS annunciator is labeled "GPS" in white text, and the Nav annunciator is labeled "NAV" in green text.

### 2.8.7.2 Back Course Annunciation

P7-15 Back Course Out

The Back Course Out will be grounded when the back course localizer mode is enabled.

If an external annunciator is used for back course annunciation, it is recommended that the back course annunciator be labeled "BC" in amber text.

### 2.8.7.3 Dead Reckoning Annunciation

P5-60 Dead Reck Anncc

The Dead Reck Anncc output is grounded whenever the CNX80 is in dead reckoning mode (i.e. whenever the GPS position is lost and the last-known groundspeed is > 3kts).

If an external annunciator is used for dead reckoning annunciation, it is recommended that the dead reckoning annunciator be labeled "DR" in amber text.

### 2.8.7.4 Approach Annunciation

P5-61 Approach Annunciate

The Approach Annunciate output is grounded when performing approach navigation and approach is active.

If an external annunciator is used for approach annunciation, it is recommended that the approach annunciator be labeled “APPR” in green text.

#### **2.8.7.5 Parallel Track Annunciation**

P5-62 Parallel Track Annnc

The Parallel Track Annnc output is grounded whenever the parallel track mode has been selected.

If an external annunciator is used for parallel track annunciation, it is recommended that the parallel track annunciator be labeled “PTK” in white text.

#### **2.8.7.6 Suspend Annunciation**

P5-63 Suspend Annunciate

The Suspend Annunciate output is grounded when automatic sequencing of waypoints in the active flight plan has been suspended by the user.

If an external annunciator is used for suspend annunciation, it is recommended that the suspend annunciator be labeled “SUSP” in white text.

#### **2.8.7.7 Message Annunciation**

P5-64 Message Annunciate

The Message annunciator flashes when a new status message is available. If a status message has been acknowledged but is still effective, the Message annunciator illuminates continuously.

If an external annunciator is used for message annunciation, it is recommended that the message annunciator be labeled “MSG” in white or amber text.

#### **2.8.7.8 LOI (Loss of Integrity) Annunciation**

P5-65 LOI Annunciate

The LOI Annunciate output is grounded when the WAAS / GPS detects a position error, or is unable to calculate the integrity of the position (RAIM unavailable).

If an external annunciator is used for loss of integrity annunciation, the loss of integrity annunciator should be labeled “LOI” in amber text.

#### **2.8.7.9 Waypoint Annunciation**

P5-66 Waypoint Annunciate

The Waypoint annunciator functions as follows:

- When the aircraft is within 10 to 20 seconds of reaching a turning point for a course change, the waypoint annunciator flashes.
- When the aircraft is in a turn, the waypoint annunciator illuminates continuously and remains illuminated until the turn is completed.

- When the turn is complete and deviation information is being provided relative to the next leg, the waypoint annunciator will extinguish.

If an external annunciator is used for waypoint annunciation, it is recommended that the waypoint annunciator be labeled “WPT” in white text.

### **2.8.7.10 Terminal Mode Annunciation**

P5-67 Terminal Mode Annnc

The Terminal Mode Annnc output is grounded when navigating within 30 nmi of the departure or arrival airport, or on a SID or STAR.

If an external annunciator is used for terminal mode annunciation, it is recommended that the terminal mode annunciator be labeled “TERM” in green text.

### **2.8.7.11 Altitude Alert Annunciation**

P5-69 Altitude Alert Annnc

The Altitude Alert Annnc output is not implemented in the current version of the CNX80 (this output is always ‘open’). In future versions, this output will be grounded when performing a WAAS GPS approach and (i) ownship WAAS altitude is too low, or (ii) the WAAS altitude is not within specification.

If an external annunciator is used for altitude alert annunciation, it is recommended that the altitude alert annunciator be labeled “ALT” in amber text.

## **2.8.8 DISCRETE OUTPUTS**

### **2.8.8.1 ILS Energize**

P7-33 ILS Energize

The ILS Energize output is grounded whenever a localizer frequency is tuned on the CNX80 nav radio, regardless of which navigation source (GPS or VOR/ILS ) is currently selected to drive the CDI.

### **2.8.8.2 Precision Approach**

P5-68 Precision Appr

The Precision Appr output is grounded when a precision approach is active. Currently, the precision approach output will be active when the CNX80 nav radio is tuned to a localizer and the VOR/ILS radio navigation data is selected for display on the CDI. This output may be connected to the ILS Energize input of an autopilot or flight director to provide higher autopilot gain when the CNX80 is operating in precision approach mode.

**TSO PENDING****2.8.8.3 Audio Message Active Out**

P5-70    Audio Msg Active Out

The Audio Msg Active Out is grounded whenever the CNX80 is playing an audio message or audio tone. This output is grounded 200 msec prior to playing the message / tone, and remains grounded for 200 msec following completion of the message / tone.

**2.8.8.4 Power Control Out**

P7-36    Power Control Out

The Power Control Out is grounded whenever power is applied to the CNX80, and open otherwise.

**2.8.9 SWITCHES / DISCRETE INPUTS****NOTE**

Installations in conformance with the requirements specified in this installation manual do not require the use of any external annunciators or switches, since all annunciations and switches are provided on the CNX80 front panel.

All of the switch inputs duplicate functions available on the front of the CNX80. These can be used to make the function available remotely.

**2.8.9.1 CDI Select Switch**

P7-8    Main CDI Select In

The Main CDI Select In is used to toggle between the display of GPS and VOR/ILS information on the CDI window and remote CDI connected to the Main CDI outputs. A momentary ground on this input performs the same function as pressing the **CDI** key on the CNX80 bezel.

**2.8.9.2 Com Flip-Flop Switch**

P1-14    Com Flip Flop In

The Com Flip Flop In is used to toggle the active and standby Com frequencies. A momentary ground on this input performs the same function as pressing the COM flip-flop soft key ( $\leftrightarrow$ ) on the bezel.

**2.8.9.3 VOR Flip-Flop Switch**

P1-34    VOR Flip Flop In

The VOR Flip Flop In is used to toggle the active and standby VOR/LOC frequencies. A momentary ground on this input performs the same function as pressing the VOR flip-flop soft key ( $\leftrightarrow$ ) on the bezel.

#### 2.8.9.4 Push to Talk (PTT)

P4-4 PTT

The PTT is used to transmit on the COM radio. A ground on this input enables the Com MIC audio and causes the Com transceiver to transmit on the active frequency.

#### 2.8.9.5 Com User List Switch

P1-15 UP Discrete In  
P1-33 DOWN Discrete In

The Com User List inputs are momentary, active-low discrete inputs and are used to display the Com User List and select a frequency. When not displayed, a momentary grounding on either of these inputs causes the Com User List window to be displayed. When the Com User List window is displayed, a momentary ground on the UP Discrete In (P1-15) causes the highlighted frequency to move up to the next frequency in the list. A momentary ground on the DOWN Discrete In (P1-33) causes the highlighted frequency to move down to the next frequency in the list. Once selected, the frequency can be made active by pressing the Com Flip-Flop button.

#### 2.8.9.6 Suspend Switch

P5-76 Suspend In

The Suspend In input suspends automatic sequencing of waypoints in the active flight plan. A momentary ground on this input performs the same function as pressing the **SUSP** key on the CNX80 bezel.

#### 2.8.9.7 Audio Inhibit In

P5-76 Audio Inhibit In

The Audio Inhibit In is used to inhibit the CNX80 audio messages. A ground on this input causes CNX80 audio messages not to be played; if this input is open CNX80 audio messages will be played. Any audio messages that are inhibited because of this input will not be played when the audio inhibit condition is removed.

**NOTE**

The Audio Inhibit input will not inhibit the momentary tone that is played by the CNX80 whenever a status message is available. This tone can be disabled by the user via the system configuration page.

### 2.8.10 SERIAL INTERFACES

#### 2.8.10.1 RS232 / RS422

The CNX80 provides five bi-directional RS232 serial interfaces, two receive-only RS232 serial interfaces and one bi-directional RS422 serial interface for making optional connections. The serial port can be used for connecting to:

- Resolvers, indicators, or electronic flight instruments that accept serial data
- SL30 for Comm/NAV frequency transfers and DME distance from the database

- MX20 to display VOR data on a map and database interface
- A second CNX80

Serial interface specifications are included in Appendix B.

P1-4	RS232 RxD1	P5-1	RS232 RxD5
P1-5	RS232 TxD1	P5-21	RS232 TxD5
P1-23	Serial Ground 1	P5-41	Serial Ground 5
P1-21	RS232 RxD2	P5-2	RS232 RxD6
P1-22	RS232 TxD2	P5-22	RS232 TxD6
P1-3	Serial Ground 2	P5-42	Serial Ground 6
P1-6	RS232 RxD3	P5-10	RS232 RxD7
P1-7	RS232 TxD3	P5-30	RS232 RxD8
P1-25	Serial Ground 3	P5-44	Serial Ground 7/8
P1-11	RS422 RxD4 +		
P1-26	RS422 RxD4 -		
P1-8	RS422 TxD4 +		
P1-10	RS422 TxD4 -		

**NOTE**

In order for a serial port to function correctly, the baud rate of the Rx and Tx channels on a given RS232 or RS422 port must be the same. This must be considered when assigning serial ports to interfacing equipment.

The CNX80 can communicate with an SL30 radio using RS232 RxD1 and TxD1. This interface allows the SL30 to provide DME station information to the CNX80, which will provide the range to the DME station back to the SL30 for display on its front panel.

The CNX80 can communicate with a PDA using the infrared sensor on the front bezel. If this feature is used it must be set up on RxD3 and TxD3, not allowing these lines to be used for communication with other devices.

The CNX80 can receive air data and fuel data from certain systems on RS232 RxD5, although it is recommended that if a dedicated altitude encoder is used, it be connected to RS232 RxD8.

If two CNX80's are installed in an aircraft, the RS232 RxD2 and TxD2 lines may be cross connected to cross-fill flight plans and user-defined waypoints from one CNX80 to the other (this feature is not implemented in the initial version of the CNX80). Altitude data and master/slave control is coordinated between two CNX80's.

The CNX80 can communicate with an SL70 or SL70R transponder using the RS232 RxD6 and TxD6 lines, allowing the CNX80 to control the operation of the transponder. This interface will also allow altitude to be provided from the SL70/70R to the CNX80. RS232 channel 6 is opto-isolated, allowing the transmit lines of two CNX80's to be connected together to either CNX80 to control an SL70 transponder.

A dedicated altitude encoder may be used to provide altitude data to the CNX80 using RS232 RxD8.

Refer to section 3.2.1.1 for a list of available serial port configurations, and information on configuring the serial ports.

### **2.8.10.2 ARINC 429**

The CNX80 provides three ARINC 429 inputs and two ARINC 429 outputs. Each of these may be configured for low-speed or high-speed operation.

#### **2.8.10.2.1 ARINC 429 Inputs**

P5-7	429 IN 1A
P5-27	429 IN 1B
P5-8	429 IN 2A
P5-28	429 IN 2B
P5-9	429 IN 3A
P5-29	429 IN 3B

The CNX80 can receive air data, heading data and wind data from suitable equipment. The labels that are used by the CNX80 are listed in the table below.

**Table 2-9 - ARINC 429 Input Labels**

Label No.	Parameter Name	Typical Source
203	Pressure Altitude	ADC
204	Baro Corrected Altitude	ADC
210	True Airspeed	ADC
212	Pressure Altitude Rate	ADC
314	Heading (True)	AHRS/IRU/NMC
315	Wind Speed	FADC/NMC
316	Wind Direction (True)	FADC/NMC
320	Heading (Magnetic)	AHRS/IRU/NMC

Refer to section 3.2.1.2 for information on configuring the ARINC 429 inputs.

#### **2.8.10.2.2 ARINC 429 Outputs**

P5-4	429 OUT 1A
P5-24	429 OUT 1B
P5-5	429 OUT 2A
P5-25	429 OUT 2B

The data output on the ARINC 429 output port depends upon the configuration (refer Table 2-10). Below is a list of the possible configurations and the labels output for each one.

1. EFIS 429
2. GAMA 429
3. GAMA Graphics 429

**NOTE**

For the initial version of the CNX80 only configuration 1 (EFIS 429) is supported.

**TSO PENDING****Table 2-10 - ARINC 429 Output Labels**

<b>Label No.</b>	<b>Parameter Name</b>	<b>1</b>	<b>2</b>	<b>3</b>
001	Distance To Go (BCD)	•	•	•
002	Time To Go (BCD)	•	•	•
012	Ground Speed (BCD)	•	•	•
041	Set Latitude (BCD)		•	•
042	Set Longitude (BCD)		•	•
074G	Data Record Header		•	•
075G	Active Wpt From/To Data		•	•
100	Selected Course 1	•		
100G	Selected Course 1		•	•
113G	Message Checksum		•	•
114	Desired Track (True)	•	•	•
115	Waypoint Bearing (True)	•	•	•
116	Cross Track Distance	•		
116G	Cross Track Distance		•	•
117	Vertical Deviation		•	•
121	Horizontal Command (To Autopilot)	•	•	•
125	Greenwich Mean Time (BCD)	•	•	•
147G	Magnetic Variation		•	•
150	UTC (Binary)		•	•
204	Baro Corrected Altitude	•	•	•
251	Distance To Go	•		
251G	Distance To Go		•	•
252	Time To Go		•	•
260G	Date (BCD)		•	•
261G	GPS Discrete Word 1		•	•
275G	LRN Status Word 1		•	•
300G	Station Declination, Type, and Class		•	•
301G	Message Characters 7-9		•	•
303	Message Length/Type/Number		•	•
304G	Message Characters 1-3		•	•
305G	Message Characters 4-6		•	•
306G	NAV/Waypoint/Airport Latitude		•	•
307G	NAV/Waypoint/Airport Longitude		•	•
310	Present Position Latitude	•	•	•
311	Present Position Longitude	•	•	•
312	Ground Speed	•	•	•
313	Track Angle (True)	•	•	•
314	True Heading	•	•	•
315	Wind Speed	•	•	•
316	Wind Angle (True)	•	•	•
320	Magnetic Heading	•	•	•
321	Drift Angle	•	•	•
326G	Lateral Scale Factor	•	•	•
330	Conic Arc Inbound Course			•
331	Conic Arc Radius			•
332	Conic Arc Course Change Angle			•
333	Airport Runway Azimuth			•

Label No.	Parameter Name	1	2	3
334	Airport Runway Length In Feet			•
335	Left/Right Hand Holding Pattern Azimuth			•
340	Left/Right Hand Procedure Turn Azimuth			•
351G	Distance To Destination (Via Flight Plan)		•	•
352G	Estimated Time To Destination (Via Flight Plan)		•	•
371G	Specific Equipment ID		•	•
377	Equipment Hex ID Code	•	•	•

Refer to section 3.2.1.2 for information on configuring the ARINC 429 outputs.

## 2.8.11 TIME MARK OUTPUT

- P1-17 Time Mark Out +
- P1-19 Time Mark Out -

The Time Mark Out is a differential output that provides a 1 msec pulse once each second. This time reference is derived from GPS satellites.

## 2.8.12 VHF COM

The CNX80 provides an internal COM transceiver that can be interfaced to an audio panel or connected directly to a speaker. The PTT input is used to enable the Com MIC audio and cause the Com transceiver to transmit on the active frequency. Optional external inputs are available to allow the user to toggle the active and standby Com frequencies, and select Com frequencies from a user-defined frequency list.

Refer to Appendix D for interconnect information.

Refer to section 3.2.1.5 for information on setting the RF squelch and mic gain values.

### 2.8.12.1 Com Headphone and Speaker Audio Out

- P4-14 Com Headphone Out
- P4-6 Com Speaker Out
- P4-13 Com Audio Ground

The Com Headphone Out is a low-level audio output that is intended to drive a headset or audio panel. This output will provide 280 mW into a 100 Ω load, or 120 mW into a 500 Ω load.

The Com Speaker Out is a high-level audio output that is available to drive a speaker. This output will provide 12 watts into a 4 Ω load, or 8 watts into an 8 Ω load.

Both the Headphone and Speaker outputs use the same Com Audio Ground. For normal installations, it is recommended that the Headphone output be used, and the Com Speaker output be left unconnected.

### **2.8.12.2 Com MIC Audio In**

P4-8      Com MIC In High  
P4-7      Com MIC In Low

The Com MIC input is designed for a standard carbon or dynamic mic with integrated pre-amp providing minimum 70 mv rms into 1000  $\Omega$  load. The CNX80 provides a bias voltage to the microphone.

### **2.8.12.3 Push to Talk (PTT)**

P4-4      PTT

The PTT is used to enable the Com MIC audio and cause the Com transceiver to transmit on the active frequency. Refer to section 2.8.9.4 for additional details.

### **2.8.12.4 Com Flip-Flop Switch**

P1-14      Com Flip Flop In

The Com Flip-Flop In can be used to toggle the active and standby Com frequencies. Refer to section 2.8.9.2 for additional details.

### **2.8.12.5 Com User List Switch**

P1-15      UP Discrete In  
P1-33      DOWN Discrete In

The Com User List inputs can be used to display the Com User List and select a frequency. Refer to section 2.8.9.5 for additional details.

## **2.8.13 VHF NAV**

The CNX80 provides an internal NAV receiver that can be interfaced to an audio panel. An optional external input is also available to allow the user to toggle the active and standby Nav frequencies.

Refer to Appendix D for interconnect information.

### **2.8.13.1 Nav Audio Out**

P7-23      NAV Audio Out  
P7-20      NAV Audio Ground

The NAV Audio Out is a low-level audio output that is intended to drive a headset or audio panel. This output will provide 100 mW into a 500  $\Omega$  load.

### **2.8.13.2 VOR Flip-Flop Switch**

P1-34      VOR Flip Flop In

The VOR Flip Flop In is used to toggle the active and standby VOR/LOC frequencies. Refer to section 2.8.9.3 for additional details.

## 2.8.14 MESSAGE AUDIO

The CNX80 provides a message audio output for aural advisory messages. This output also provides an optional tone to alert the user when a new status message is available. A discrete input is also provided to allow these audio messages to be inhibited by higher priority systems.

Refer to Appendix D for interconnect information.

### 2.8.14.1 Message Audio Out

- P5-40 Message Audio Out
- P5-43 Message Audio Gnd

The Message Audio Out is a low-level audio output that is intended to drive a headset or audio panel. It is recommended that this input be provided to an auxiliary input in the audio panel that will allow the user to switch off the message audio if desired. This output will provide 100 mW into a  $500\ \Omega$  load.

### 2.8.14.2 Audio Inhibit In

- P5-76 Audio Inhibit In

The Audio Inhibit In may be used by higher priority systems to inhibit the CNX80 audio messages. Refer to section 2.8.9.7 for additional details.

## 2.8.15 RMI / OBI

The CNX80 RMI/OBI output can be used to drive an RMI (or OBI) navigation indicator. The OBI Select input is used to select the source (GPS or Nav radio) used to provide the bearing.

Refer to Appendix D for interconnect information.

### 2.8.15.1 RMI / OBI Interface

- P5-16 OBI Clock
- P5-17 OBI Data
- P5-37 OBI Sync

The CNX80 provides bearing from a waypoint for Bendix / King Serial OBI devices. The source used to provide the bearing information is selected by the OBI Select input.

### 2.8.15.2 RMI / OBI Source Select

- P5-36 OBI Select In

When the OBI Select input is open, the bearing data transmitted on the RMI / OBI output is bearing from the currently active GPS waypoint. When the OBI Select input is grounded, the bearing data transmitted on the RMI / OBI output is bearing from the currently tuned VOR station. If a localizer channel is tuned on the CNX80 Nav receiver, the bearing data is flagged as invalid.

**TSO PENDING****2.8.16 DME TUNING**

The CNX80 can channel a DME based upon the tuned VOR frequency. The CNX80 outputs the King Serial DME channeling format. When the DME Select input is grounded, the CNX80 will actively tune the DME.

Refer to Appendix D for interconnect information.

**2.8.16.1 Serial DME Tuning**

- P5-14 DME Clock Bus
- P5-15 DME Data Bus
- P5-35 DME Channel Req

When the DME Channel Request line is high, the CNX80 provides serial DME channeling data on the DME Clock / Data Buses. Data is provided in the King Serial DME channeling format.

**2.8.16.2 DME Select In**

- P5-34 DME Select In

When grounded, the CNX80 will acknowledge a DME channel request and output data on the DME Serial Tuning interface. When open, the CNX80 will not provide tuning information.

## 2.9 ANTENNA INSTALLATION AND CONNECTIONS

The CNX80 requires three antennas: Com antenna, GPS antenna, and Nav antenna. Follow the manufacturer's installation instructions for mounting the antennas.

### 2.9.1 COMM ANTENNA

The CNX80 requires a standard  $50\Omega$  vertically polarized antenna. Follow the antenna manufacturer's installation instructions for mounting the antenna.

The antenna should be mounted on a metal surface or a ground plane with a minimum area of 18 x 18 inches. The antenna should be mounted a minimum of two feet away from GPS antennas.

The comm antenna should also be mounted as far apart as practical from the ELT antenna, preferably one on top and the other on the bottom of the aircraft fuselage. Some ELTs have exhibited re-radiation problems generating harmonics that may interfere with GPS signals. This can happen when the comm (CNX80 or any other comm) is transmitting on certain frequencies such as 121.15 or 121.175 MHz, which may cause the ELT output circuit to oscillate from the signal coming in on the ELT antenna coax. The antenna coax cable should be made of RG-142B or a comparable quality  $50\Omega$  coax. Assembly instructions for the rear coax connector are included in Figure 2-9.

### 2.9.2 GPS ANTENNA

The mounting location and cable connections for the GPS antenna are very important. The antenna should be mounted no closer than two feet from VHF comm transmitter antennas, six inches from other antennas emitting less than 25 watts, and two feet from higher power antennas. See A-33 GPS Antenna Installation Manual, p/n 560-0949-xx for more information on GPS antenna installation. Special care should be taken to ensure that the GPS antenna is not mounted in close proximity to antennas that may emit harmonic interference at the L1 frequency of 1575.42 MHz. Refer to AC 20-138A Airworthiness Approval of Global Navigation Satellite System (GNSS) Equipment for additional information and guidelines.

#### NOTE

The internal CNX80 Com does not interfere with its own GPS receiver. However, placement of the CNX80 GPS antenna relative to other com transceivers and antennas (including the CNX80 Com antenna) is critical.

The connectors are included in the installation kit, and are intended for use with RG-142B size coax cable. If using a different diameter coax, alternative connectors may be required. Assembly instructions for the connectors are included in Figure 2-9. RG-142B cable can be used as long as the length is less than 35 feet. For longer lengths, use low-loss  $50\Omega$  coax.

**Suggestion:** Temporarily locate the GPS antenna with coax connected to the CNX80 and check the GPS performance as described in the GPS Operation and Position test in the Post Installation Checkout in section 3.3.2.1.2. Once a suitable location has been verified, then permanently mount the antenna.

**NOTE**

If using a GPS antenna that was already on the aircraft, or if mounting the antenna closer than two feet from a comm antenna, conduct the GPS Operation and Position test in the Post Installation Checkout on page 3-18. If the CNX80 passes the test, then further measures are not necessary.


Once the antenna mounting position has been prepared, route the coax cable from the antenna to the CNX80. Proper selection of coax cable and assembly of connectors is critical to GPS signal performance. The cable loss from the GPS antenna shall not be greater than 7 dB. If SatCom is installed on the aircraft, the cable loss shall be 3 dB minimum to ensure proper interference rejection from SatCom. The coaxial connectors and adapters, such as TNC to BNC, add additional loss to the cable and should be considered when computing the cable loss. A typical loss of 0.2 dB can be used for each connection. The typical cable loss for 20 feet of RG-142B coax with a connector one each end is 4 dB.

During the post-installation checkout, susceptibility to harmonics of VHF comm transmitters will be evaluated. If problems arise, then better isolation, or distance, may be required between the GPS and comm antennas, or a 1575.42 MHz notch filter may be installed in series with the antenna coax of the VHF comm transceiver to reduce or eliminate the harmonic interference. A notch filter for this use (part #162-1059) is available from UPS Aviation Technologies.

**NOTE**

CNX80 performance has been verified in typical installations and has not shown problems of the built-in comm interfering with the GPS when installed according to the recommended installation guidelines.

If a VHF comm transmitter causes problems with the GPS on the selected frequencies as listed in the post-installation checkout, the problem may be due to the ELT. This can be verified by disconnecting the ELT antenna coax at the ELT unit. If the ELT is found to cause the problem, then contact the ELT manufacturer or replace the ELT.



Assembly instructions for right angle connector part #162-1008

**Figure 2-9 - Rear Coax Connector Assembly**

### 2.9.3 NAV ANTENNA

The NAV antenna is a standard  $50\Omega$  horizontally polarized NAV/VOR/Localizer/Glideslope antenna that receives VOR frequencies between 108 and 117.95 MHz, and localizer frequencies between 108 and 112 MHz, and glideslope information between 328.6 and 335.4 MHz. Follow the antenna manufacturer's installation instructions for mounting antennas. The Nav antenna should be mounted as far apart as practical from the ELT antenna. It is recommended that the installer use RG-142B or equivalent  $50\Omega$  coax for the NAV antenna.

The CNX80 incorporates an internal diplexor circuit. This means that the input VHF signal must not strip the glideslope (330 MHz) signal from the NAV (108 MHz) signal. **Do not install an external diplexor.** It is recommended that a single VOR/Localizer/Glideslope antenna be used for the installation. Most VOR/LOC-only antennas will still provide an adequate glideslope signal for the Apollo CNX80 to operate normally.

If two nav receivers (e.g. one CNX80 and one SL30) are installed in the aircraft, a splitter must be used. Installations should use an appropriate splitter, such as the Mini-Circuits ZFSC-2-1B BNC, available as an option under the UPS Aviation Technologies part number 115-0007.

### 2.10 WEIGHT AND BALANCE

Weight and balance computation is required after the installation of the CNX80. Follow the guidelines as established in AC 43.13-1B, Chapter 10, section 2. Make appropriate entries in the equipment list indicating items added, removed, or relocated along with the date accomplished. Include your name and certificate number in the aircraft records. Table 2-11 identifies the weight of the new CNX80 equipment and Figure 2-10 shows the center of gravity.

**Table 2-11 - Unit Weights**

Item	Weight
CNX80 only	5.8 lbs. (2.6 kg)
CNX80 mounting tube only	0.7 lbs. (0.3 kg)

### 2.11 ELECTRICAL LOAD ANALYSIS

An electrical load analysis should be completed on each aircraft prior to installation in accordance with AC 43.13-1B, Chapter 11. Use the following values for computation:


**Table 2-12 - Unit Power Loads**

CNX80 Input	14 VDC		28 VDC	
	Typical	Max	Typical	Max
CNX80 Main Power (P1 connector) with heater off <sup>(1)</sup>	1.4 A	2.2 A	700 mA	1.1 A
	2.4 A	3.2 A	1.2 A	1.6 A
CNX80 Nav Power (P7 connector)	450 mA	700 mA	200 mA	350 mA
CNX80 Com Power (P4 connector) receive	270 mA	1.8 A	130 mA	900 mA
	2.1 A	3.2 A	1.0	1.6

**Table 2-12 - Unit Power Loads**

<b>CNX80 Input</b>	<b>14 VDC</b>		<b>28 VDC</b>	
	<b>Typical</b>	<b>Max</b>	<b>Typical</b>	<b>Max</b>
Notes:				
(1) Backlight heater element turns on when internal temperature is below approximately 42°C.				

**Note:** Circuits should be protected in accordance with guidelines in AC 43.13-1B, chapter 11, section 2, paragraph 429. Power inputs should be across a minimum of all four specified input pins.

**Figure 2-10 - CNX80 Center of Gravity**

**NOTES**

---

## 3 POST INSTALLATION CONFIGURATION & CHECKOUT PROCEDURES

Once the CNX80 unit has been installed, configure the unit for the particular installation and then complete the checkout procedures herein to verify proper operation. The steps that are not applicable to a particular installation may be skipped. A checkout log sheet is included in Table 3-5 on page 3-28, to be filled out during the checkout procedure. The completed checkout log sheet should be maintained with the aircraft permanent records.

### 3.1 MOUNTING AND WIRING CHECK

Verify that all cables are properly secured and shields are connected as the install drawings indicate. Installation may require that you check the movement of the aircraft controls to verify that there is no interference.

### 3.2 EQUIPMENT SETUP AND CONFIGURATION

Prior to system operation, the CNX80 must be configured for the particular installation using the setup functions provided.

The system setup and checkout functions are reached in the Ground Maintenance mode of the CNX80. This mode cannot be accessed during flight. The Ground Maintenance mode is reached by pressing the line select keys 1, 4, and **MENU/ENTER** in sequence immediately after the CNX80 initialization is complete and before any other bezel keys on the CNX80 are pressed. Line select key 1 is the top line select key, line select key 4 is the fourth key down, and **MENU/ENTER** is the lower most key below the line select keys. After pressing the keys, wait for the CNX80 to restart into Ground Maintenance mode. The Ground Maintenance mode default menu display (SETUP) is shown in Figure 3-1. Pressing the **SETUP**, **TEST** or **INPUT** smart keys along the bottom allows selection of that function. Pressing the **EXIT** smart key will return the CNX80 to the Airborne mode.




Figure 3-1 - Ground Maintenance Mode Display

### 3.2.1 SETUP FUNCTION

The SETUP function allows the custom configuration of the CNX80 for each individual installation. The SETUP function allows the installer to configure the serial and ARINC 429 ports, calibrate the resolver head (if installed), calibrate the baro potentiometer (if installed), and set COM parameters.

#### 3.2.1.1 Serial Ports

While on the Ground Maintenance SETUP menu page, press the **SERIAL PORTS** line select key to change the serial port settings. The serial port setup page is shown in Figure 3-2.

CNX80 GND MAINT SERIAL SETUP				
CH	RX	BAUD	TX	BAUD
1	SL30	9600	MAPCOM	9600
2	NONE	0	NONE	0
3	IRDA	9600	IRDA	9600
4	NONE	0	NONE	0
5	ALT ENC	1200	NONE	0
6	SL70	9600	SL70	9600
7	NONE	0	NONE	0
8	NONE	0	NONE	0

**SETUP**   **TEST**   **INPUT**   **BACK**

Figure 3-2 - Serial Port Setup Page

Push the small, inner knob in to enter the editing mode. The first editable item will be highlighted. Use the large, outer knob to select the next or previous editable data field and turn the small, inner knob to change the current setting. Set each serial port according to the installation, and leave unused ports set to NONE. Either press the small, inner knob in again or press the **MENU/ENTER** key to save the settings. Press the **SETUP** or **BACK** smart key to return to the Ground Maintenance SETUP menu. The configuration options for the serial input ports and output ports are shown in Table 3-1.

#### NOTE

In order for a serial port to function correctly, the baud rate of the RX and TX channels on a given RS232 or RS422 port must be the same (or the unused channel must be set to NONE). This must be considered when assigning serial ports to interfacing equipment.

**Table 3-1 - Serial Port Setup Configurations**

Serial Port	Default Configuration		Other Available Configurations					
	Rx	Tx	Rx	Tx	Rx	Tx	Rx	Tx
1	MAPMX (38400)	MAPMX (38400)	FADC (9600)	MAPCOM (9600)	SL30 (9600)	MAPCOM (9600)	None	None
2	FADC (9600)	MAPCOM (9600)	CNX80 (38400)	CNX80 (38400)	None	None	None	None
3	IrDA (9600- 115200)	IrDA (9600- 115200)	None	None				
4	None	None						
5	SL30 (9600)	MAPCOM (9600)	FADC (9600)	MAPCOM (9600)	Alt Enc. (1200, 9600)	None	None	None
6	SL70 (9600)	SL70 (9600)	None	None				
7	None	---						
8	Alt Enc. (1200, 9600)	---	None	---				

Note 1: MAPMX is a special format for use with the MX20 Version 5 (or later). MAPCOM refers to the standard UPSAT serial output.

Note 2: Although the IrDA option is shown for port 3, this interface is currently not supported.

### 3.2.1.2 ARINC 429 Ports

While on the Ground Maintenance SETUP menu page, press the **429 PORTS** line select key to configure the ARINC 429 ports. The ARINC 429 ports setup page is shown in Figure 3-3.



**Figure 3-3 - ARINC 429 Ports Setup Page**

Push in the Cursor knob to allow editing of the settings. Turn the large, outer knob to select the next or previous item and the Cursor knob to change currently selected setting. Set each ARINC 429 port according to the installation, and leave unused ports set to NONE. Either press the Cursor knob in again or press the **MENU/ENTER** key to save the settings. Press the **SETUP** or **BACK** smart key to return to the Ground Maintenance SETUP menu. The available ARINC 429 input and output port settings are shown in Table 3-2. The Source Destination Identifier (SDI) field on the ARINC 429 outputs can be configured as SYS 1, SYS 2, or ALL. For dual CNX80 installations, each CNX80 must have a unique source name (SYS 1 or SYS 2). For a single CNX80 installation, select ALL.

**Table 3-2 - ARINC 429 Input and Output Port Settings**

Channel	Speed	Input Bus Nomenclature
429_IN_1	Low	ADC (Air Data Computer) / NONE
429_IN_2	High / Low	AHRS (Altitude Heading Reference System) / NONE
429_IN_3	High / Low	---
429_OUT_1	High / Low	EFIS 429 / NONE
429_OUT_2	High / Low	EFIS 429 / NONE

### 3.2.1.3 Resolver Interface Selection and Calibration

The Resolver Interface function lets you to select whether or not a resolver is installed, and allows an installed resolver to be calibrated. While on the Ground Maintenance SETUP menu page, press the **RESOLVER** line select key. Then press the top line select key to toggle between INSTALLED (for installations with a resolver) or NOT INSTALLED (for installations without a resolver). The resolver interface setup page is shown in Figure 3-4.



Figure 3-4 - Resolver Interface Setup Page

When a resolver is installed, calibrate it as follows:

1. Press the **CAL** line select key. The calibration page shown in Figure 3-5 will then be displayed. If the **CAL** line select key is pressed when the resolver is set to NOT INSTALLED, it will automatically be changed to INSTALLED.
2. Press the **10/30** line select key to toggle between 10 and 30 degrees for the calibration increment.

**NOTE**

An increment of 30 degrees should be acceptable for most installations. However, if resolver errors of more than two degrees are present following the calibration, the calibration procedure should be repeated using the 10 degree increment (this will create a more accurate calibration table but will require more time to perform the calibration).

3. Follow the instructions on the display for calibrating the resolver. If the CNX80 will not accept the calibration or advances to the next prompt when the **MENU/ENTER** key is pressed, there may be a problem with the resolver interface.

**NOTE**

The accuracy of the system is dependent on this calibration. Do not rush this step.

4. After successfully calibrating the resolver a green CALIBRATION PASSED message will be displayed. After this message appears, rotate the resolver and ensure that the CURRENT RESOLVER VALUE being displayed is within two degrees of the actual resolver setting.



Figure 3-5 - Resolver Calibration Page

The CNX80 cannot drive multiple resolvers at the same time. It is not recommended that external resolvers be switched through a relay or other means because the resolver must be calibrated to the radio as described in this procedure. If multiple resolvers are desired in the installation, the primary unit must be installed and calibrated as described here. The secondary unit should use the composite output.

**NOTE**

The composite output is limited to the VHF Nav signal and will not be switched to GPS when the **CDI** bezel key is pressed.

**3.2.1.4 Altimeter Interface**

The Altimeter Interface function lets you to select whether or not a baro-correction potentiometer is installed, and allows an installed potentiometer to be calibrated. While on the Ground Maintenance SETUP menu page, press the **BARO** line select key. Then press the top line select key to toggle between INSTALLED (for installations with a baro pot) or NOT INSTALLED (for installations without a baro pot). The Altimeter Interface setup page is shown in Figure 3-6.

The units that are used may be set using the **UNITS** line select key to toggle the units between inches Hg and millibars.

**NOTE**

Changing the units will only affect the units displayed during calibration. The user can change the units that are displayed during normal operation via the system configuration page.

**Figure 3-6 - Altimeter Interface**

When a baro potentiometer is installed, calibrate it as follows:

1. Press the **CAL** line select key. The calibration page shown in Figure 3-7 will then be displayed. If the **CAL** line select key is pressed when the baro pot is set to NOT INSTALLED, it will automatically be changed to INSTALLED.
2. Follow the instructions on the display for calibrating the baro potentiometer. If the CNX80 will not accept the calibration when the **MENU/ENTER** key is pressed, there may be a problem with the baro potentiometer interface.

**NOTE**

The accuracy of the system is dependent on this calibration. Do not rush this step.

3. After successfully calibrating the baro potentiometer a green CALIBRATION PASSED message will be displayed. After this message appears, rotate the resolver and ensure that the CURRENT BARO value being displayed is within  $\pm 0.03$  "Hg ( $\pm 1$  mB) of the actual altimeter setting.

**Figure 3-7 - Baro-Altimeter Calibration**

### 3.2.1.5 Com Radio

The Com Radio Setup function is used to modify the RF Squelch and Mic Gain levels. Typical values from the factory are RF Squelch = 56 and Mic Gain = 255, which are satisfactory for most installations.

The RF Squelch value is used by the Com function to control its squelch level. The larger the value that is set the stronger the signal must be in order for the radio to break squelch. To edit the RF Squelch value, press the **EDIT RF SQUELCH** line select key. Turn the small, inner knob to adjust the squelch value (the RF Squelch value is restricted to a number from 25 to 100). When the desired value is selected, press the **MENU/ENTER** key or the **SAVE RF SQUELCH** line select key to save the setting.

The microphone gain is used by the Com function to control the microphone pre-amplifier gain. The larger the value that is set the higher the pre-amplifier gain is. To edit the Mic Gain value press the **EDIT MIC GAIN** line select key. Turn the small, inner knob to adjust the gain value (the Mic Gain value is restricted to a number from 0 to 255). When the desired value is selected, press the **MENU/ENTER** key or the **SAVE MIC GAIN** line select key to save the setting.



Figure 3-8 - Com Radio Setup

## 3.3 EQUIPMENT OPERATIONAL/FUNCTIONAL TEST

Following equipment configuration, use the CNX80 Test Function (3.3.1.1) and Interface Monitor Function (3.3.1.2) as necessary to verify that the interfaces are wired correctly. Once the wiring is verified, perform the System Checkout (3.3.2).

### 3.3.1 CNX80 CHECKOUT UTILITIES

#### 3.3.1.1 Test Function

The Test function allows the checkout of the display, controls, and I/O of the CNX80. While in the Ground Maintenance mode, press the **TEST** smart key to enter the Test menu, which is shown in Figure 3-9. Additional items on the TEST menu are available by pressing the **NEXT PAGE** line select key.




Figure 3-9 - TEST Main Menu Page

### 3.3.1.1.1 Flag Test

The FLAG TEST page allows testing of the TO/FROM, CDI Valid, and VDI Valid flags for both the Main and Auxiliary CDI outputs. The Nav Superflag, GSI Superflag, and Localizer (ILS Energize) can also be tested for the Main CDI. While on the TEST menu page, press the **FLAGS** line select key to display the FLAG test page. Press the **SELECT** line select key to toggle between MAIN and AUX CDI flag tests, as shown in Figure 3-10 and Figure 3-11, respectively.





Figure 3-10 - Main CDI Flag Test


**Figure 3-11 – Auxiliary CDI Flag Test**

When on the appropriate page turn the large, outer knob to select the flag to be tested. Then turn the small, inner knob to change the setting of that flag. Test each setting for every flag of each CDI connected to the CNX80.

Press the **TEST** or **BACK** smart key to return to the Ground Maintenance Test menu.

### 3.3.1.1.2 CDI Deviation Test

The CDI TEST page allows testing of the CDI deviation outputs for both the Main and Auxiliary CDI outputs. While on the TEST menu page, press the **CDI TEST** line select key to display the CDI TEST Page. Press the **SELECT** line select key to toggle between MAIN and AUX CDI deviation tests. The MAIN CDI test screen is shown in Figure 3-12, and the AUX CDI test screen is identical.

**Figure 3-12 – Main CDI Test Page**

When on the appropriate page turn the large, outer knob to select the desired CDI deviation test. The test is initiated as soon as it is selected. There are five CDI tests in the following order:

- CDI TRIANGLE TEST: gradually drives the CDI needle left and then right
- CDI LEFT TEST: drives the external CDI needle full scale left

- CDI MID TEST: drives the external CDI needle to the center
- CDI RIGHT TEST: drives the external CDI needle full scale right
- CDI MANUAL TEST: allows manual input of CDI outputs (from 10L to 10R)

As a minimum, perform the LEFT, MID and RIGHT tests for the lateral deviation needle of each CDI connected to the CNX80.

Press the **TEST** or **BACK** smart key to return to the Ground Maintenance Test menu.

### 3.3.1.1.3 VDI Test

The VDI TEST page allows testing of the VDI deviation outputs for both the Main and Auxiliary CDI outputs. While on the TEST menu page, press the **VDI TEST** line select key to display the VDI TEST Page. Press the **SELECT** line select key to toggle between MAIN and AUX VDI deviation tests. The AUX VDI test screen is shown in Figure 3-13, and the MAIN VDI test screen is identical.




Figure 3-13 – Auxiliary VDI Test Page

When on the appropriate page turn the large, outer knob to select the desired VDI deviation test. The test is initiated as soon as it is selected. There are five VDI tests in the following order:

- VDI Triangle Test: gradually drives the VDI needle up and then down
- VDI Down Test: drives the external VDI needle full scale down
- VDI Mid Test: drives the external VDI needle to center
- VDI Up Test: drives the external VDI needle full scale up
- VDI Manual Test: allows manual input of VDI outputs

As a minimum, perform the DOWN, MID and UP tests for the vertical deviation needle of each CDI connected to the CNX80.

**NOTE**

For some HSI's the glideslope indicator may not be visible unless it is receiving a valid signal from the localizer (ILS Energize is present). If this is the case, leave these signals set to VALID following completion of the FLAG TEST in order to see the glideslope indicator.

Press the **TEST** or **BACK** smart key to return to the Ground Maintenance Test menu.

### 3.3.1.1.4 Annunciator Lamp Output Test

The LAMP OUTPUT TEST page allows testing of each of the annunciator outputs. While on the TEST menu page, press the **LAMP OUTPUT TEST** line select key to display the LAMP OUTPUT Page. The LAMP OUTPUT page is shown in Figure 3-14.



**Figure 3-14 - Lamp Output Test**

Turn the large, outer knob to select the annunciator output to be tested. The currently selected lamp output is indicated with a white box around it. Turn the small, inner knob to change the setting of the selected annunciator lamp output – a green background indicates that the annunciator output is ON (grounded), and a black background indicates that the annunciator output is OFF (open). Details for each annunciator lamp output that can be tested are found in Table 3-3.

**Table 3-3 – Lamp Output Test Items**

Display Label	Signal Name	Connector - Pin	Notes
MSG	Message Annunciate	P5-64	
PTK	Parallel Track Annnc	P5-62	
SUSP	Suspend Annunciate	P5-63	
APR	Approach Annunciate	P5-61	
LOI	LOI Annunciate	P5-65	
ALT	Altitude Alert Annnc	P5-69	
PAA	Precision Appr	P5-68	
TRM	Term Mode Annnc	P5-67	
WPT	Waypoint Annunciate	P5-66	
BCKCRS	Back Course Out	P7-15	
GPSIND	GPS Indicator Out	P7-17	The GPSIND and NAVIND toggle, so one is always ON
NAVIND	NAV Indicator Out	P7-18	The GPSIND and NAVIND toggle, so one is always ON
DR	Dead Reck Annunciate	P5-60	

For each annunciator that is used, verify proper operation by turning the annunciator ON and OFF.

Press the **TEST** or **BACK** smart key to return to the Ground Maintenance Test menu.

### 3.3.1.1.5 Display Test

The Display Test function displays various test patterns and can be used to verify the CNX80 display operation. While on the Ground Maintenance main TEST menu page, press the **NEXT PAGE** line select key, followed by the **DISPLAY** line select key to go to the Display Test page. Turn the outer knob while on any Test Pattern page to display the next Test Pattern Page in the sequence. The order of test pages is Fonts 1, Fonts 2, Fonts 3, Bitmaps, Red, Green, Blue, White, Black, White on Black, and Black on White. The first available display test screen is shown in Figure 3-15.



**Figure 3-15 - Display Test Initial Screen**

Press the **TEST** or **BACK** smart key to return to the Ground Maintenance Test menu.

### 3.3.1.1.6 Bezel Key Test

The Bezel Key Test function verifies the operation of the bezel keys and knobs. While on the Ground Maintenance TEST menu page, press the **BEZEL KEYS** line select key to go to the Bezel Key Test page. Follow the on-screen directions to press each one of the bezel keys and actuate the knobs. After completing the bezel key test the results will be shown on the display. If a key / knob is not actuated for ten seconds (30 seconds for the first key in the test sequence), the test will automatically advance to the next key / knob and will show a FAIL message upon completion of the test. Repeat the test carefully to ensure that the keys and knobs are actuated within the required time.

**NOTE**


Once the Bezel Key Test is initiated it cannot be exited until every key and knob is actuated or times out.

**Figure 3-16 - Bezel Key Test**

The bezel key test should be run upon initial installation or any time a problem is suspected with one of the CNX80 bezel keys or knobs.

### 3.3.1.2 Input Monitor Function

The Input Monitor Function monitors the external inputs to the CNX80 and displays the data currently being received. Press the **INPUT** smart key in the Ground Maintenance mode to reach the Interface Monitor Function, as shown in Figure 3-17. The display will show the status of the connected interfaces.

**Figure 3-17 - Interface Monitor Function Display - Page 1**

Press the **MORE** line select key to show the next page, which is shown in Figure 3-18. Press the **BACK** line select key to return to the previous page.



**Figure 3-18 - Interface Monitor Function Display - Page 2**

Details for each of the inputs that can be monitored are shown in Table 3-4.

**Table 3-4 – Description of Input Monitor Items**

Display Label (cyan)	Signal Name	Connector – Pin(s)	Expected Display (white)
429 IN 1: 429 IN 2: 429 IN 3:	ARINC 429 IN 1 ARINC 429 IN 2 ARINC 429 IN 3	P5-7,27 P5-8,28 P5-9,29	‘FFFFFFFFFF’ will be displayed if no data has been received. The hex value of the most recently received label will be displayed if data is being received. ‘00000000’ will be displayed if data was received, but no data has been received in the last 5 seconds.
SYNCHRO HDG:	Synchro Heading	P5-18,19,20,38,39	If the synchro valid discrete is INVALID or the 26VAC, 400Hz reference is not present, ‘---’ will be displayed; otherwise, the angle of the synchro heading input will be displayed.
BARO:	Baro Correction Pot	P5-13,33,53	The value of the baro potentiometer input will be displayed. ‘0’ will be displayed if input is open, or if the baro pot input has not been properly calibrated.
P1-14:	Com Flip Flop In	P1-14	‘0’ in input is open ‘1’ if input is grounded
P1-15:	UP Discrete In	P1-15	‘0’ in input is open ‘1’ if input is grounded
P1-33:	DOWN Discrete In	P1-33	‘0’ in input is open ‘1’ if input is grounded
P1-34:	VOR Flip Flop In	P1-34	‘0’ in input is open ‘1’ if input is grounded
P5-36:	OBI Select In	P5-36	‘0’ in input is open ‘1’ if input is grounded
P5-56:	RESERVED	P5-56	‘0’ in input is open ‘1’ if input is > 9 VDC
P5-57:	Heading Valid In	P5-57	‘0’ in input is open ‘1’ if input is > 9 VDC
P5-72:	RESERVED	P5-72	‘0’ in input is open ‘1’ if input is grounded
P5-73:	RESERVED	P5-73	‘0’ in input is open ‘1’ if input is grounded
P5-74:	RESERVED	P5-74	‘0’ in input is open ‘1’ if input is grounded
P5-75:	RESERVED	P5-75	‘0’ in input is open ‘1’ if input is grounded
P5-76:	Suspend In	P5-76	‘0’ in input is open ‘1’ if input is grounded
P5-77:	Audio Inhibit In	P5-77	‘0’ in input is open ‘1’ if input is grounded
P5-78:	RESERVED	P5-78	‘0’ in input is open ‘1’ if input is grounded
P4-4:	Com PTT	P4-4	‘0’ in input is open ‘1’ if input is grounded
CDI SEL:	Main CDI Select In	P7-8	Normally a ‘-’ is displayed. When the input is actuated a ‘T’ will be displayed for approximately 1 sec.
232-1: 232-2: 232-3: 422-4: 232-5: 232-6: 232-7: 232-8:	RS232 Port 1 In RS232 Port 2 In RS232 Port 3 In RS422 Port 4 In RS232 Port 5 In RS232 Port 6 In RS232 Port 7 In RS232 Port 8 In	P1-4,23 P1-3,21 P1-7,25 P1-11,26 P5-1,41 P5-2,42 P5-10,44 P5-30,44	‘FF’ will be displayed if no data has been received.  The hex value of the most recently received data will be displayed if data is being received.  ‘00’ will be displayed if data was received, but no data has been received in the last 5 seconds.

For each CNX80 ARINC 429 input that is used, verify that data is being received. If no data is being received, ensure that (i) the source equipment is turned on, (ii) the ARINC 429 input type and speed has been set up correctly, and (iii) the wiring is correct.

If synchro heading is supplied to the CNX80, verify that the synchro heading is displayed and agrees with the value provided by the heading source. If the synchro heading is dashed out, ensure that (i) the source equipment is turned on, (ii) the heading valid discrete is VALID (P5-57 = '1'), (iii) the 26VAC 400 Hz reference is being supplied, and (iv) the wiring is correct.

If a baro pot is connected to the CNX80, verify that the baro-correction is displayed and agrees with the altimeter baro-correction. If the baro-correction value does not vary with the altimeter value, ensure that (i) the baro-correction has been properly calibrated, and (ii) the wiring is correct.

For each discrete input that is connected to the CNX80, exercise the discrete and verify that the appropriate discrete changes from a '0' to a '1' when activated (the CDI Select input will momentarily change to a 'T' when exercised).

For each CNX80 serial input that is used, verify that data is being received. If no data is being received, ensure that (i) the source equipment is turned on, (ii) the serial port input RX type has been set up correctly, and (iii) the wiring is correct.

### 3.3.2 SYSTEM CHECKOUT – GROUND CHECKS

The CNX80 includes a self test that is executed every time the unit is turned on that checks the unit operation as well as other internal functions. Verify that the unit does not display a failure indication when turned on.

**NOTE**

The CNX80 must be properly configured prior to performing system checkouts. When configured correctly, the CNX80 will annunciate failures that are detected with interfacing systems when it is first turned on. Any annunciated failures should be corrected prior to proceeding with the ground checks.

#### 3.3.2.1 GPS Navigation Checkout

Switch on the CNX80 in the normal mode to complete this part of the checkout – this is accomplished by either exiting the Ground Maintenance Mode or by turning the CNX80 OFF and then turning it back ON.

The CNX80 requires a “seed” position, time, and date for the GPS sensor to know which satellites to look for. Once this information is entered it will be saved and updated automatically, so it will not be necessary to re-enter the information at every start-up. If the CNX80 is moved a great distance without being turned on, the seed position may have to be re-entered.

**NOTE**

This checkout must be completed with the aircraft moved away from hangars and other structures that may obstruct the view of the satellites.

##### 3.3.2.1.1 Initial Power-Up

The first time the CNX80 is used after it is installed, the GPS seed position, UTC time and date must be entered. Following the display of the main start-up screen, the screen shown in Figure 3-19 will be displayed for 10 seconds. Press the **CHG** smart key to allow the position to be edited. The latitude (degrees) will be highlighted. Use the large, outer knob to select the next or previous editable data field

and turn the small, inner knob to change the current setting. When the position, UTC time and date have been entered, press the **MENU/ENTER** key to accept the entries. The Master GPS Reset must be set to ‘No’.

**NOTE**

The latitude and longitude must be within one degree of the actual position, and the UTC time (not local time) must be within one minute. If position, time and date are not entered correctly, GPS acquisition may take up to 20 minutes.



**Figure 3-19 – GPS Information Start-up Screen**

If the exact position is not known, the CNX80 can determine its own initial position. If it is desired to let the CNX80 determine its own position, do not enter the position, time and date after the **CHG** smart key is pressed. Instead, use the use the large, outer knob to select the Master GPS Reset item and set it to ‘Yes’ using the small, inner knob. Press the **MENU/ENTER** key to accept the changes, and then press the **MENU/ENTER** key again to acknowledge the STOP! message.

**NOTE**

GPS acquisition may take up to 20 minutes after a Master GPS Reset is performed.

### 3.3.2.1.2 GPS Operation and Position

Check the GPS operation as follows:

1. Turn on the CNX80 and allow the unit to acquire a position. All other avionics should be turned off for this part of the test.
2. Check the position using the GPS Status page, which is shown in Figure 3-20. This page is accessed by pressing the **FN** key twice, causing the **SYS** smart key to be displayed. The **SYS** smart key is then pressed, followed by the **GPS** smart key, if necessary. The lat/long displayed on this page should agree with a known reference position.



Figure 3-20 – GPS Status Page

3. Check the GPS signal reception using the GPS Status page. Typical signal levels are between 60% and 80% of full scale (viewed using the bar graph), although values above and below this range are normal.
4. Turn on other avionics one at a time and check the GPS signal reception to make sure it is not affected.
5. Check for VHF com transmitter interference.

**NOTE**

The interference check must be completed on all IFR installations.

- a) Verify that at least five satellites are displayed in green boxes (with the corresponding satellite vehicle number displayed in green on the left of the bar graph). Ensure that NO POSITION FIX is not displayed.
- b) Press the **COM** bezel key and tune the CNX80 Com to 121.125 MHz. Listen on the frequency to ensure it is not in use, and then transmit for 30 seconds.

**NOTE**

When the mic has been keyed for 35 seconds, a “WARNING Stuck Microphone” message will pop-up and the com transmitter will stop transmitting. If required to transmit for an additional 15 seconds, the PTT switch must be momentarily released and then re-keyed to continue transmitting – the WARNING message does not have to be cleared to continue transmitting.

- c) While transmitting, observe the signal status of each satellite being received. If the satellite signals are significantly degraded or some satellite signals are lost during the test, continue transmitting for another 15 seconds. Verify that the GPS position remains valid (if position is lost, NO POSITION FIX will be displayed in place of the position data). If position is lost, additional isolation measures will have to be taken.

- d) If required, clear the “WARNING Stuck Microphone” message by pressing the **CLR** bezel key. Repeat steps b) and c) for additional frequencies as follows.

121.150 MHz	131.225 MHz
121.175 MHz	131.250 MHz
121.185 MHz [I]	131.275 MHz
121.190 MHz [I]	130.285 MHz [I]
121.200 MHz	131.290 MHz [I]
121.225 MHz	131.300 MHz
121.250 MHz	131.325 MHz
131.200 MHz	131.350 MHz

[I] frequency is only applicable to VHF radios with 8.33 kHz channel spacing

- e) Repeat for each com transmitter installed in the aircraft.
- f) If aircraft is TCAS-equipped, turn on the TCAS system and verify that GPS position remains valid (if position is lost, NO POSITION FIX is displayed in place of the position data).
- g) If aircraft is SATCOM-equipped, use the SATCOM system and verify that GPS position remains valid (if position is lost, NO POSITION FIX is displayed in place of the position data).
- h) If the CNX80 is susceptible to VHF com transmitter interference, then better isolation (or distance) may be required between the GPS and VHF (or other offending system) antennas. With some com transmitters, a 1575.42 MHz notch filter (such as UPSAT P/N 162-1059) may be required in series with the VHF com antenna coax at the rear of the com unit.

#### NOTE

Older VHF comm transmitters may emit higher levels of harmonic interference causing greater problems and may be more difficult to deal with.

### 3.3.2.2 VHF Nav Checkout

Press the **CDI** bezel key to select VOR CDI mode (indicated by a green VOR in the left portion of the CNX80 CDI display). To the right of the VOR indication is the current setting of the OBS. Verify that the OBS decodes properly from 0 to 360 degrees (the value displayed on the CNX80 should be within  $\pm 2^\circ$  of the OBS). Check the operation of remote VOR flip-flop switch (if installed).

Check the VOR reception with ground equipment, operating VOT or VOR, and verify audio and Morse code ID functions (if possible). Tune a Localizer frequency and verify the CDI needle and NAV flag, and VDI needle and GS flag operation.

#### NOTE

Some VOR test equipment may not be compatible with the digital signal processing of the VHF Nav receiver and will give erroneous results. Examples of equipment known to function properly are: IFR Nav 750 and Collins 479S-6.

### 3.3.2.3 VHF Com Checkout

#### 3.3.2.3.1 Antenna Check

If desired, the antenna VSWR can be checked using an inline wattmeter in the antenna coax using frequencies near both ends of the band. The VSWR should be  $< 2:1$ , and is not to exceed 3:1. A VSWR of 2:1 will cause a drop in output power of approximately 12%, and 3:1 causes approximately a 26% drop.

### 3.3.2.3.2 Receiver / Transmitter Operation

Press the **COM** bezel key to allow control of the VHF com transceiver. Tune the unit to a local frequency and verify the receiver output produces a clear and understandable audio output. Verify the transmitter functions properly by contacting another station and getting a report of reliable communications. Check the operation of remote com flip/flop switch (if installed). If necessary, adjust the RF Squelch and Mic Gain values as described in 3.2.1.5.

### 3.3.2.3.3 Sidetone Level Adjustment

The sidetone volume was preset at the factory to a typical audio level. The level can be adjusted as follows:

1. Press the **COM** bezel key to allow control of the VHF com transceiver.
2. Press the **MENU/ENTER** key to display the com menu, and press the **AUDIO** line select key to display the volume adjustment window.
3. Rotate the large, outer knob to select the **Sidtone** item.
4. Rotate the **PWR/VOL** knob or the small, inner knob to adjust the sidetone level. The sidetone level is displayed as a horizontal bar, showing the level from zero to 100%. The sidetone level can be adjusted during transmit.
5. Press the **MENU/ENTER** key when done.

### 3.3.2.4 Interface Checkout

This section describes checks that can be carried out to verify that systems interfacing to the CNX80 are communicating properly.

#### 3.3.2.4.1 CNX80 Message Audio

The CNX80 can annunciate audio messages through an audio panel. This check verifies that the audio connection from the CNX80 to the audio panel is functional. Prior to proceeding with this check, ensure that the audio panel is set to annunciate the CNX80 message audio. If the following steps do not perform correctly, check the electrical connections and AMA volume setting.

1. Go to the System Configuration page. This page is accessed by pressing the **FN** key repeatedly until the **SYS** smart key is displayed. The **SYS** smart key is then pressed, followed by the **CNFG** smart key, if necessary.
2. While on the System Configuration page, rotate the large, outer knob to scroll down to the **Msg Tone** item and verify that it is set to **ON**. If it is set to **OFF**, push the small, inner knob in to edit the setting and rotate the small, inner knob to change the setting to **ON**. Press the **MENU/ENTER** key to accept the setting.
3. Rotate the large, outer knob and scroll up to the **Mag Var** setting. Press the small, inner knob in to edit the setting and rotate the small, inner knob to change the setting to **MANUAL**. As soon as the setting is changed to **MANUAL** the CNX80 will display a “Using Manual Mag Var” message and play the message tone. Verify that this tone is heard over the audio system.
4. If necessary, adjust the Message Audio volume level as described below and replay the tone to verify the new setting.
5. Return the **Mag Var** setting to **AUTO**.

### Message Audio Volume Level Adjustment

The message audio volume was preset at the factory to a typical audio level. The level can be adjusted as follows:

1. Press the **COM** bezel key, followed by the **MENU/ENTER** key to display the com menu. Press the **AUDIO** line select key to display the volume adjustment window. The audio message (**AMA**) selection will be selected.
2. Rotate the **PWR/VOL** knob or the small, inner knob to adjust the audio message volume level. The audio message level is displayed as a horizontal bar, showing the level from zero to 100%.
3. Press the **MENU/ENTER** key when done.

### 3.3.2.4.2 Baro Correction Potentiometer

The CNX80 can receive baro correction from an external potentiometer. This check verifies that the CNX80 is receiving baro correction data from the altimeter. Ensure that the CNX80 is turned on. If the following steps do not perform correctly, check the electrical connections and configuration setup.

1. Check the baro correction using the Configuration page. This page is accessed by pressing the **FN** key twice, causing the **SYS** smart key to be displayed. The **SYS** smart key is then pressed, followed by the **CNFG** smart key, if necessary. The baro correction is the first item on the list (Baro Correct.).
2. Verify that the baro correction decodes properly from 28.10 to 31.00 "Hg (952 to 1050 mB). The value displayed on the CNX80 should be within  $\pm 0.03$  "Hg ( $\pm 1$  mB) of the altimeter setting.

### 3.3.2.4.3 Air Data Computer, Altitude Encoder and Fuel Air/Data Computer

The CNX80 can receive altitude or fuel/air data from an external source. This check verifies that the CNX80 is receiving data from these units. Ensure that the CNX80 and MX20 are turned on and in normal mode. If the following steps do not perform correctly, check the electrical connections and configuration setup.

#### NOTE

For dual CNX80 installations, this check must be performed for each CNX80. While this check is carried out, the other CNX80 must be turned off.

1. Press the **MAP** bezel key and use the large, outer knob to select MAP 2.
2. Press the **MENU/ENTER** key to display the line select key functions, and repeatedly press the **MORE** line select key until the **NAV DATA** line select key legend is displayed.
3. Press the **NAV DATA** line select key to display nav data in the window on the left.
4. The ALT field will display the baro-corrected altitude. If the ALT field is not displayed, press the **SEL DATA** line select key and use the small, inner knob to select the ALT field for display and press **MENU/ENTER** when the appropriate field is selected. Verify that this altitude value is not dashed out, and that the altitude agrees with the altimeter ( $\pm 125$  ft).

#### NOTE

The baro-correction that is set on the altimeter and CNX80 must be the same in order for the displayed altitude values to agree.

5. If fuel data is being provided to the CNX80, press the **MENU/ENTER** key to display the line select key functions, and repeatedly press the **MORE** line select key until the **NAV DATA** line select key legend is displayed.

6. Press the **SEL DATA** line select key and use the small, inner knob to select the FUEL FLOW field for display and press **MENU/ENTER** when the appropriate field is selected. Verify that this fuel flow value is not dashed out, and that the fuel flow agrees with the corresponding instrument.

### 3.3.2.4.4 Apollo MX20 Display Checkout

The CNX80 can transmit flight plan data to the MX20 (and baro-correction if the CNX80 is receiving baro-correction from an altimeter). If the MAPMX interface is used, the MX20 can transmit baro-correction to the CNX80. This check verifies that the units are communicating. Ensure that the CNX80 and MX20 are turned on and in normal mode. If the following steps do not perform correctly, check the electrical connections and configuration setup.

**NOTE**

When connecting a CNX80 to the MX20 the preferred interface protocol is bi-directional MAPMX. The MAPMX protocol is only supported in MX20 version 5.0 or later. If it is desired to use a version 4.x or earlier MX20, the interface should be set to MAPCOM (this is a uni-directional interface, and data is only provided from the CNX80 to the MX20).

**MAPCOM Interface (use only for MX20 version 4.x or earlier):**

1. Check the System Info page on the MX20 to verify that the data is available to each port and that it is being processed properly.
2. Load a flight plan into the CNX80 and verify that the flight plan is displayed on the MX20 on the FPL page.

**MAPMX Interface (use for MX20 version 5.0 or later):**

1. Check the System Info page on the MX20 to verify that the data is available to the MAPMX port and that it is being processed properly.
2. Load a flight plan into the CNX80 and verify that the flight plan is displayed on the MX20 on the FPL page.

**NOTE**

If the CNX80 is configured to receive baro correction from a baro potentiometer the CNX80 will provide baro-correction data to the MX20. If no external baro correction is supplied to the CNX80, the MX20 will supply baro correction to the CNX80.

3. If a the CNX80 is configured for BARO POT: NOT INSTALLED, verify that the baro-correction on the MX20 and CNX80 are the same. Change the baro-correction on the MX20 and verify that it changes on the CNX80. The CNX80 baro-correction can be viewed on the System Configuration page, which is accessed by pressing the **FN** key repeatedly until the **SYS** smart key is displayed. The **SYS** smart key is then pressed, followed by the **CNFG** smart key, if necessary.

### 3.3.2.4.5 Dual CNX80 Cross-Talk Checkout

If two CNX80's are installed, they will share information with each other. This check verifies that the two CNX80's are communicating. If the following steps do not perform correctly, check the electrical connections and configuration setup.

**NOTE**

If the CNX80 is configured to communicate with the MX20 using the MAPMX interface, turn the MX20 off when performing this checkout.

1. Verify that the message “Communications lost with external CNX” is not currently active on either CNX.
2. On CNX80 #1 and #2, view the baro correction using the Configuration page. This page is accessed by pressing the **FN** key twice, causing the **SYS** smart key to be displayed. The **SYS** smart key is then pressed, followed by the **CNFG** smart key, if necessary. The baro correction is the first item on the list (Baro Correct.).
3. Change the baro correction on CNX80 #1 and verify that it changes to the same value on CNX80 #2. Repeat by changing the baro correction on CNX80 #2 and verifying that it changes to the same value on CNX80 #1.

**NOTE**

If one CNX80 is configured to accept baro correction data from an altimeter, the baro correction on the altimeter must be changed and the new value must appear on both CNX80's.

### **3.3.2.4.6 Apollo SL70/SL70R Transponder Checkout**

The CNX80(s) can remotely control the SL70/SL70R. This check verifies that the units are communicating. Ensure that the CNX80(s) and SL70/SL70R are turned on and in normal mode. If the following steps do not perform correctly, check the electrical connections and configuration setup.

#### **Single CNX80 Installation:**

1. Verify that the transponder squawk code is displayed in white. Press the **XPDR** bezel key and verify that you are able to change the transponder squawk code on the CNX80 (turning the large, outer knob will allow you to edit the squawk code using the small, inner knob or line select/smart keys). If an SL70 is connected, you should see the squawk code on the SL70 change to the value set on the CNX80.
2. Turn off the SL70 or open the SL70R transponder circuit breaker and verify that the squawk code on the CNX80 changes to yellow.
3. Turn on the SL70 or close the SL70R transponder circuit breaker and verify that the squawk code on the CNX80 changes back to white.

#### **Dual CNX80 Installation:**

1. Turn on CNX80 #1 and turn off CNX80 #2.
2. Verify that the transponder squawk code is displayed in white on CNX80 #1. Press the **XPDR** bezel key on CNX80 #1 and verify that you are able to change the transponder squawk code on the CNX80 (turning the large, outer knob will allow you to edit the squawk code using the small, inner knob or line select/smart keys). If an SL70 is connected, you should see the squawk code on the SL70 change to the value set on the CNX80.
3. Turn off the SL70 or open the SL70R transponder circuit breaker and verify that the squawk code on the CNX80 changes to yellow.
4. Turn on the SL70 or close the SL70R transponder circuit breaker and verify that the squawk code on the CNX80 changes back to white.
5. Turn off CNX80 #1 and turn on CNX80 #2.

6. Verify that the transponder squawk code is displayed in white on CNX80 #2. Press the **XPDR** bezel key on CNX80 #2 and verify that you are able to change the transponder squawk code on the CNX80. If an SL70 is connected, you should see the squawk code on the SL70 change to the value set on the CNX80.

#### **3.3.2.4.7 Apollo SL30 Nav/Com Checkout**

When SL30 Nav tuning is provided to the CNX80, the CNX80 will output Distance, Speed, and Time (DST) information via the MapCom output (the CNX80 also provides Comm/NAV frequency information from its database). This check verifies that the units are communicating. Ensure that the CNX80 and SL30 are turned on and in normal mode, and that the CNX80 has a valid position. If the following steps do not perform correctly, check the electrical connections and configuration setup.

1. Operate the SL30 in NAV mode.
2. Press the SL30 **SEL** button to bring up the NAV frequency recall lists.
3. Turn the SL30 large knob clockwise until the nearest VOR list is displayed (the identifier and frequency of the nearest VOR station will be displayed).
4. Press the SL30 flip-flop ( $\leftrightarrow$ ) button to swap the listed VOR frequency to the active frequency.
5. Press the SL30 **SEL** button and turn the SL30 large knob one click counterclockwise to show the DST display prompt. If you do not see SHOW DST DATA, either the feature is disabled on the SL30 or the SL30 and CNX80 are not communicating over the serial interface.

#### **3.3.2.4.8 Compass System**

The CNX80 can receive heading from an external source (XYZ synchro, FADC, or ARINC 429 heading source). This check verifies that the CNX80 is receiving data from the compass system. Ensure that the CNX80 and compass system are turned on the heading is valid. If the following steps do not perform correctly, check the electrical connections and configuration setup.

1. Press the **MAP** bezel key and use the large, outer knob to select MAP 2.
2. Press the **MENU/ENTER** key to display the line select key functions, and repeatedly press the **MORE** line select key until the **NAV DATA** line select key legend is displayed.
3. Press the **NAV DATA** line select key to display nav data in the window on the left.
4. The HDG field will display the magnetic heading. If the HDG field is not displayed, press the **SEL DATA** line select key and use the small, inner knob to select the HDG field for display and press **MENU/ENTER** when the appropriate field is selected. Verify that this heading value is not dashed out, and that the heading agrees with the HSI ( $\pm 2^\circ$ ).

#### **3.3.2.4.9 Autopilot**

The CNX80 provides GPSS roll steering information to an appropriate autopilot. When connected properly, the autopilot will show a GPSS valid indication when the CNX has a valid GPS position and is navigating to a waypoint. This check verifies that the autopilot is receiving data from CNX80. Ensure that the CNX80 and autopilot are turned on and in normal mode. If the following steps do not perform correctly, check the electrical connections and configuration setup.

1. Apply power to the equipment and wait for the CNX80 to acquire a position.
2. In the CNX80, set a course to a destination waypoint. This can be done by pressing the **NRST** bezel key to display a list of nearby waypoints. Then use the large, outer knob to select a suitable waypoint and press the **DIRECT-TO** bezel key, followed by the **Direct** line select key.
3. Verify that GPSS is valid via the autopilot annunciation.
4. Press the CDI Select key to select Nav data on the CDI. Verify that the autopilot annunciates GPSS Fail.

5. Verify all other connections between the CNX80 and the autopilot (e.g. the deviation signals and flags). These signals can be simulated using the Ground Maintenance mode (see section 3.3.1).

### **3.3.2.4.10 RMI/OBI**

The CNX80 RMI/OBI output can be used to drive an RMI (or OBI) navigation indicator. This check verifies that the RMI/OBI is receiving data from the CNX80. If the following steps do not perform correctly, check the electrical connections and configuration setup.

1. Apply power to the equipment and wait for the CNX80 to acquire a position.
2. In the CNX80, set a course to a destination waypoint. This can be done by pressing the **NRST** bezel key to display a list of nearby waypoints. Then use the large, outer knob to select a suitable waypoint and press the **DIRECT-TO** bezel key, followed by the **Direct** line select key.
3. If an external RMI select switch is installed, set it to the GPS position (if no switch is installed, the CNX80 output automatically defaults to GPS data).
4. Verify that the RMI needle swings and points towards the GPS waypoint selected

**NOTE**

The aircraft heading system must be operating properly in order for the RMI needle to point correctly.

5. If installed, set the RMI select switch to the Nav position. Tune a local VOR station, or use a simulated signal from an approved VOR Test System.
6. Verify that the RMI needle swings and points towards the VOR station.

### **3.3.2.4.11 DME**

The CNX80 can channel a DME based upon the tuned VOR frequency. This check verifies that the CNX80 is properly tuning the DME. If the following steps do not perform correctly, check the electrical connections and configuration setup.

1. Tune a co-located VOR/DME station. Listen to the DME ident via the audio panel and ID the station to verify that it is correct.
2. Tune an invalid VOR station. Verify that the DME changes to an invalid station.

## **3.3.3 SYSTEM CHECKOUT – FLIGHT CHECKS**

A flight test is recommended as a final installation verification. Verify system operation as described in the following sections.

### **3.3.3.1 Com Flight Test Check**

1. Verify the com performance by contacting a ground station at a range of at least 50nm while maintaining an appropriate altitude, and over all normal flight attitudes. Performance should be checked using low, high, and mid band frequencies.

### **3.3.3.2 VOR Flight Test Check**

1. Tune a local VOR station within 50 miles.
2. Verify the audio ident/voice quality.
3. Verify the Morse code decoder IDs the station (95% probability).
4. Fly to and from the station.
5. Verify NAV flag, TO/FROM flag, and CDI are operational.
6. Record accuracy in System Log (see manual).

### 3.3.3.3 ILS Flight Test Check

1. Tune an ILS at the local airport.
2. Verify the audio ident/voice quality.
3. Verify the Morse code decoder IDs the station (95% probability).
4. Fly the approach.
5. Verify NAV flag, GS flag, and CDI and VDI are operational.
6. Verify BC annunciator.

### 3.3.3.4 GPS Flight Test Check

1. Verify that GPS position is not lost during normal aircraft maneuvering (e.g. bank angles of up to 30 degrees and pitch angles associated with take-off, departures, approaches, landing and missed approaches as applicable). If GPS position is lost, a “WARNING Loss of Navigation” message will be displayed.
2. Enter and activate a flight plan on the CNX80. Fly the flight plan and verify that the display of flight plan data is consistent with the CDI indication (deviation, TO/FROM...) in the pilot’s primary field of view.

### 3.3.3.5 Autopilot Flight Test Check

1. Enter and activate a flight plan on the CNX80. Engage the autopilot in the GPSS mode. Verify that the autopilot flies the course.
2. Disengage the autopilot and fly off course. Re-engage the autopilot (in GPSS mode) and verify that it correctly intercepts the course and continues to fly it.
3. Turn off the autopilot GPSS but leave the autopilot engaged in Nav mode. Verify that it maintains the current course.

## 3.4 DATABASE CHECK

Check the database to ensure it is current. The database information is displayed at startup. To check the database:

1. Turn off the CNX80 and then turn it on. The CNX80 will go through its normal start-up sequence.
2. Wait for the database page to be displayed.
3. Verify that the database is not expired (the expiration date will be displayed in green text if the database is current, and yellow text if it has expired).

If the database card has to be reprogrammed with a new revision, remove and replace the database card as described in the following section.

### 3.4.1 DATA CARD REPLACEMENT

#### CAUTION

**Handle the data card carefully. Do not touch the connector edge of the data card.  
Do not insert or remove the data card within 10 seconds after the CNX80 is turned on.**

To replace the data card do the following:

1. Ensure that the CNX80 is turned off.
2. Press the data card ejector to eject the card and remove the data card. Gently pull the card straight out of the slot.
3. With the label facing left, insert the new data card by pushing the card straight into the slot and press firmly into place. When fully inserted, the ejector button will be flush with the top of the data card.

**Table 3-5 - CNX80 Post-Installation Checkout Log**

<b>Apollo CNX80 Post-Installation Checkout Log</b>		Date: ____ / ____ / ____ By: _____
<b>CNX80 CONFIGURATION INFORMATION:</b>		430-6100-8 _____ - _____ Mod _____ Serial # _____
<b>SETUP ITEMS:</b>		
<b>Serial Interface Configuration (RX/TX):</b> _____ / _____ (Port 1) _____ / _____ (Port 2) _____ / _____ (Port 3) _____ / _____ (Port 4) _____ / _____ (Port 5) _____ / _____ (Port 6) _____ / N/A (Port 7) _____ / N/A (Port 8)		
<b>ARINC 429 Input Configuration:</b> _____ <input type="checkbox"/> Hi <input type="checkbox"/> Low (Channel 1 In) _____ <input type="checkbox"/> Hi <input type="checkbox"/> Low (Channel 2 In) _____ <input type="checkbox"/> Hi <input type="checkbox"/> Low (Channel 3 In)		
<b>ARINC 429 Output Configuration:</b> _____ <input type="checkbox"/> Hi <input type="checkbox"/> Low (Channel 1 Out) _____ <input type="checkbox"/> Hi <input type="checkbox"/> Low (Channel 2 Out)		
<b>Resolver:</b> Resolver: <input type="checkbox"/> Installed <input type="checkbox"/> Not Installed <input type="checkbox"/> [ <input type="checkbox"/> N/A ] Resolver Calibrated		
<b>Baro-Correction:</b> Baro Pot: <input type="checkbox"/> Installed <input type="checkbox"/> Not Installed <input type="checkbox"/> [ <input type="checkbox"/> N/A ] Baro Pot Calibrated		
<b>MAIN CDI CHECKOUT:</b> <input type="checkbox"/> [ <input type="checkbox"/> N/A ] CDI (left, mid, right) <input type="checkbox"/> [ <input type="checkbox"/> N/A ] VDI (down, mid, up) <input type="checkbox"/> [ <input type="checkbox"/> N/A ] TO/FROM flag (OFF, TO, FROM) <input type="checkbox"/> [ <input type="checkbox"/> N/A ] Valid flags		
<b>AUXILIARY (GPS) CDI CHECKOUT:</b> <input type="checkbox"/> [ <input type="checkbox"/> N/A ] CDI (left, mid, right) <input type="checkbox"/> [ <input type="checkbox"/> N/A ] VDI (down, mid, up) <input type="checkbox"/> [ <input type="checkbox"/> N/A ] TO/FROM flag (OFF, TO, FROM) <input type="checkbox"/> [ <input type="checkbox"/> N/A ] Valid flags		
<b>ANNUNCIATOR OUTPUTS CHECKOUT:</b> <input type="checkbox"/> [ <input type="checkbox"/> N/A ] Message (MSG) <input type="checkbox"/> [ <input type="checkbox"/> N/A ] Parallel Track (PTK) <input type="checkbox"/> [ <input type="checkbox"/> N/A ] Suspend (SUSP) <input type="checkbox"/> [ <input type="checkbox"/> N/A ] Approach (APR) <input type="checkbox"/> [ <input type="checkbox"/> N/A ] Loss of Integrity (LOI) <input type="checkbox"/> [ <input type="checkbox"/> N/A ] Altitude Alert (ALT) <input type="checkbox"/> [ <input type="checkbox"/> N/A ] Precision Approach (PAA) <input type="checkbox"/> [ <input type="checkbox"/> N/A ] Terminal Mode (TRM) <input type="checkbox"/> [ <input type="checkbox"/> N/A ] Waypoint (WPT) <input type="checkbox"/> [ <input type="checkbox"/> N/A ] Back Course (BC) <input type="checkbox"/> [ <input type="checkbox"/> N/A ] GPS Indicator (GPS) <input type="checkbox"/> [ <input type="checkbox"/> N/A ] NAV Indicator (NAV) <input type="checkbox"/> [ <input type="checkbox"/> N/A ] Dead Reckoning (DR)		
<b>DISCRETE INPUTS CHECKOUT:</b> <input type="checkbox"/> [ <input type="checkbox"/> N/A ] Com Flip-Flop <input type="checkbox"/> [ <input type="checkbox"/> N/A ] Com User List - UP <input type="checkbox"/> [ <input type="checkbox"/> N/A ] Com User List - DOWN <input type="checkbox"/> [ <input type="checkbox"/> N/A ] VOR Flip-Flop <input type="checkbox"/> [ <input type="checkbox"/> N/A ] OBI Select <input type="checkbox"/> [ <input type="checkbox"/> N/A ] Synchro Heading Valid <input type="checkbox"/> [ <input type="checkbox"/> N/A ] Remote Suspend <input type="checkbox"/> [ <input type="checkbox"/> N/A ] Audio Inhibit <input type="checkbox"/> [ <input type="checkbox"/> N/A ] Com PTT <input type="checkbox"/> [ <input type="checkbox"/> N/A ] Remote CDI Select		
<b>GPS NAVIGATION CHECKOUT</b> <input type="checkbox"/> Position checked <input type="checkbox"/> Signal reception checked		
<input type="checkbox"/> Interference from other avionics checked <input type="checkbox"/> VHF com interference checked		

**VHF NAV CHECKOUT**

- Resolver checked
- VOR reception checked
- Localizer reception checked
- Deviation needle and flag checked

**VHF COM CHECKOUT:**

- Receiver / Transmitter operation checked
- Sidetone level set / checked

**INTERFACE CHECKOUT**

- [  N/A ] CNX80 Message Audio
- [  N/A ] Altimeter Baro Correction
- [  N/A ] Altitude Encoder or ADC
- [  N/A ] FADC or Fuel Computer
- [  N/A ] MX20 Display
- [  N/A ] Dual CNX80 Cross-Talk

- [  N/A ] SL70/SL70R Transponder
- [  N/A ] SL30 Nav/Com
- [  N/A ] Compass System Heading
- [  N/A ] Autopilot
- [  N/A ] RMI/OBI
- [  N/A ] DME

**FLIGHT CHECKS:**

- Com checked
- VOR checked
- ILS checked
- Autopilot checked

**FINAL SYSTEM CHECK:**

- Database checked

**COMMENTS:**

**NOTES**

---

## 4 TROUBLESHOOTING

This section provides information to assist troubleshooting if problems occur after completing the installation. Use Table 4-1 to assist in troubleshooting. Devices connected to the CNX80, such as an SL30, SL70 or MX20 can be useful for determining whether the CNX80 is functioning properly or if there are problems with the installation.

### 4.1 TROUBLESHOOTING PROCEDURE

**Table 4-1. Troubleshooting Guide**

Problem	Possible Cause	Solution
The CNX80 does not power on.	<ul style="list-style-type: none"> <li>The unit is not getting power to the main connector P1.</li> </ul>	<ul style="list-style-type: none"> <li>Make sure power is connected to the main 37-pin connector P1-1 and 16 and ground to P1-2 and 20. Check circuit, breakers and main avionics switch.</li> </ul>
The CNX80 does not compute a position.	<ul style="list-style-type: none"> <li>Not receiving signals, or incorrect seed position, time, and date.</li> </ul>	<ul style="list-style-type: none"> <li>Make sure a correct position and time/date have been entered. Check the GPS antenna connections. Make sure the aircraft is clear of hangers, buildings, trees, etc.</li> </ul>
GPS signal levels drop when avionics are turned on.	<ul style="list-style-type: none"> <li>Noise interference from other avionics.</li> </ul>	<ul style="list-style-type: none"> <li>Turn all avionics off, then turn on each piece one at a time to isolate the source of the interference. Route GPS cable and locate GPS antenna away from sources of interference.</li> </ul>
The GPS signal levels are very low.	<ul style="list-style-type: none"> <li>Improper antenna installation or coax routing.</li> <li>Antenna shaded from satellites.</li> <li>RF interference at 1575.42 MHz from VHF com.</li> </ul>	<ul style="list-style-type: none"> <li>Check GPS antenna installation, connections, and cable routing. The GPS antenna must be mounted on the top of the aircraft.</li> <li>Make sure the aircraft is clear of hangers, buildings, trees, etc.</li> <li>Move GPS antenna further from the com antenna. Add a 1575.42 MHz notch filter in com coax. Fix or replace the com. Disconnect the ELT antenna coax to check for possible re-radiation.</li> </ul>
Unable to control Com using <b>COM</b> bezel key.	<ul style="list-style-type: none"> <li>No power to the com.</li> <li>The input voltage is too low.</li> </ul>	<ul style="list-style-type: none"> <li>Make sure power is connected to the com 15-pin connector P4-1 and ground to P4-9.</li> <li>Increase input supply voltage to &gt; 10 volts DC.</li> </ul>
The CNX80 does not transmit.	<ul style="list-style-type: none"> <li>The PTT input is not being pulled low.</li> <li>No power to the com.</li> <li>The input voltage is too low.</li> </ul>	<ul style="list-style-type: none"> <li>Check that the PTT (mic key) input is pulled low for transmit.</li> <li>Make sure power input is connected to the com 15-pin connector P4-1 and ground to P4-9.</li> <li>Increase input supply voltage to &gt; 10 volts DC.</li> </ul>

**Table 4-1. Troubleshooting Guide**

<b>Problem</b>	<b>Possible Cause</b>	<b>Solution</b>
The sidetone level is too low or too high.	<ul style="list-style-type: none"> <li>Wrong type of headsets, or level needs adjustment.</li> </ul>	<ul style="list-style-type: none"> <li>If necessary, adjust the sidetone level. Sidetone adjustment is found under the AUDIO menu in the COM function.</li> </ul>
Unable to control Nav using <b>VOR</b> bezel key.	<ul style="list-style-type: none"> <li>No power to the nav receiver.</li> </ul>	<ul style="list-style-type: none"> <li>Make sure power is connected to the nav 37-pin connector P7-1 and ground to P7-2.</li> </ul>
OBS Resolver won't calibrate.	<ul style="list-style-type: none"> <li>Incompatible resolver or improper connection.</li> </ul>	<ul style="list-style-type: none"> <li>Check the resolver specifications and wiring.</li> </ul>
OBS indication on CNX80 does not agree with OBS setting	<ul style="list-style-type: none"> <li>CNX80 resolver input not configured correctly.</li> <li>Resolver has not been calibrated.</li> </ul>	<ul style="list-style-type: none"> <li>Check resolver configuration in Ground Maintenance Mode</li> <li>Calibrate resolver</li> </ul>
CNX80 Message Audio or Tone not heard	<ul style="list-style-type: none"> <li>Message audio volume level set too low</li> <li>Message tone is turned OFF.</li> <li>Audio inhibit line grounded</li> </ul>	<ul style="list-style-type: none"> <li>Increase AMA volume level. AMA adjustment is found under the AUDIO menu in the COM function.</li> <li>Turn message tone ON via system configuration page.</li> <li>Verify that inhibit input (P5-77) is not grounded using Ground Maintenance Mode.</li> </ul>
Unable to control transponder using <b>XPDR</b> bezel key.	<ul style="list-style-type: none"> <li>SL70/SL70R transponder is not turned on.</li> <li>SL70 is not configured correctly.</li> <li>Wiring connections are incorrect.</li> </ul>	<ul style="list-style-type: none"> <li>Turn on transponder</li> <li>Go to serial port setup page and verify that RS232 port 6 has SL70 set for both CH 6 RX and CH 6 TX.</li> <li>Check wiring.</li> </ul>
CNX80 not receiving baro correction data from MX20.	<ul style="list-style-type: none"> <li>Incorrect configuration used for serial port to MX20.</li> <li>MX20 software prior to v5.x.</li> <li>Wiring connections are incorrect.</li> </ul>	<ul style="list-style-type: none"> <li>Go to serial port setup page and verify that RS232 port 1 has MAPMX set for both CH 1 RX and CH 1 TX (only MX20 version 5.x or later supports the MAPMX protocol).</li> <li>Update MX20 software.</li> <li>Check wiring</li> </ul>
DST data (Distance, Speed, Time) is not displayed on the SL30.	<ul style="list-style-type: none"> <li>The CNX80 is not configured correctly.</li> <li>The SL30 is not set up for DST display.</li> </ul>	<ul style="list-style-type: none"> <li>Go to serial port setup page and verify that RS232 port to SL30 is set to SL30 on RX and MAPCOM on TX.</li> <li>Consult SL30 users guide for setup of DST display.</li> </ul>
CNX80 is not receiving heading from compass system (ARINC 429 heading input used)	<ul style="list-style-type: none"> <li>CNX80 ARINC 429 input not configured correctly.</li> <li>ARINC 429 input port speed not correct</li> <li>Wiring connections are incorrect.</li> </ul>	<ul style="list-style-type: none"> <li>Check ARINC 429 input port setting for port that device is connected to.</li> <li>Check ARINC 429 input port speed setting for port that device is connected to and verify that the speed is correct for that device.</li> <li>Check wiring.</li> </ul>

**Table 4-1. Troubleshooting Guide**

<b>Problem</b>	<b>Possible Cause</b>	<b>Solution</b>
CNX80 is not receiving heading from compass system (synchro heading input used)	<ul style="list-style-type: none"> <li>Heading Valid input invalid.</li> <li>26VAC reference voltage is incorrect</li> <li>Wiring connections are incorrect</li> </ul>	<ul style="list-style-type: none"> <li>Check that heading valid input (P5-57) is &gt; 9 VDC. State of this input can be checked in Ground Maintenance Mode.</li> <li>Check that 26VAC, 400Hz reference is supplied to P5-20,39</li> <li>Check wiring.</li> </ul>
CNX80 heading differs greatly from compass system (synchro hdg only)	<ul style="list-style-type: none"> <li>Synchro X,Y,Z legs are crossed</li> <li>26VAC reference Hi and Lo are swapped.</li> <li>26VAC reference supplied to CNX80 is different than 26VAC reference used by compass system.</li> </ul>	<ul style="list-style-type: none"> <li>Check wiring.</li> <li>Check wiring.</li> <li>Verify that CNX80 and compass system are using the same 26VAC reference.</li> </ul>
CNX80 is not receiving baro-correction setting from altimeter	<ul style="list-style-type: none"> <li>CNX80 baro pot input not configured correctly.</li> <li>CNX80 baro pot input not calibrated</li> <li>CNX80 is not the only device tied to the altimeter baro pot</li> </ul>	<ul style="list-style-type: none"> <li>Check baro pot configuration in Ground Maintenance Mode</li> <li>Calibrate baro pot</li> <li>Ensure CNX80 is the only device connected to the altimeter baro pot</li> </ul>
Autopilot is not getting GPSS/Roll Steering data from the CNX80 (ARINC 429 Roll Steering used)	<ul style="list-style-type: none"> <li>CNX80 does not have a position or flight plan entered.</li> <li>CNX80 ARINC 429 output not configured correctly.</li> <li>ARINC 429 output port speed not correct</li> <li>Wiring connections are incorrect.</li> </ul>	<ul style="list-style-type: none"> <li>Acquire GPS position and enter a flight plan.</li> <li>Check ARINC 429 output port setting for port that autopilot is connected to.</li> <li>Check ARINC 429 output port speed setting for port that autopilot is connected to and verify that the speed is correct for autopilot.</li> <li>Check wiring.</li> </ul>
Autopilot is not getting GPSS/Roll Steering data from the CNX80 (RS232 Roll Steering used)	<ul style="list-style-type: none"> <li>CNX80 RS232 output not configured correctly.</li> <li>Wiring connections are incorrect.</li> </ul>	<ul style="list-style-type: none"> <li>Ensure output port setting is MAPCOM for port that autopilot is connected to.</li> <li>Check wiring.</li> </ul>
RMI pointer does not indicate correctly	<ul style="list-style-type: none"> <li>Desired RMI source has not been selected</li> <li>Wiring connections are incorrect.</li> </ul>	<ul style="list-style-type: none"> <li>Select desired RMI source from Nav or GPS.</li> <li>Check wiring</li> </ul>
Tuning data not updating DME	<ul style="list-style-type: none"> <li>DME Select is not low</li> <li>Wiring connections are incorrect.</li> </ul>	<ul style="list-style-type: none"> <li>Verify DME Select pulled low.</li> <li>Check wiring.</li> </ul>
ARINC 429 device is not receiving data from the CNX80.	<ul style="list-style-type: none"> <li>CNX80 ARINC 429 output not configured correctly.</li> <li>ARINC 429 output port speed not correct</li> <li>Wiring connections are incorrect.</li> </ul>	<ul style="list-style-type: none"> <li>Check ARINC 429 output port setting for port that device is connected to.</li> <li>Check ARINC 429 output port speed setting for port that device is connected to and verify that the speed is correct for that device.</li> <li>Check wiring.</li> </ul>

**Table 4-1. Troubleshooting Guide**

<b>Problem</b>	<b>Possible Cause</b>	<b>Solution</b>
RS232 device is not communicating with the CNX80.	<ul style="list-style-type: none"> <li>• CNX80 RS232 port not configured correctly.</li> <li>• Improper setup on the remote device.</li> <li>• Device not compatible, or improper connection.</li> <li>• Multiple Tx lines connected together (not applicable to dual CNX80's controlling the SL70).</li> </ul>	<ul style="list-style-type: none"> <li>• Check RS232 port setting for port that device is connected to.</li> <li>• Verify the configuration of the other device.</li> <li>• Verify CNX80 Rx is connected to remote device Tx and CNX80 Tx is connected to remote device Rx.</li> <li>• Verify that there is only one Tx source per Rx port (not applicable to dual CNX80's controlling the SL70).</li> </ul>

## 4.2 CONTACTING THE FACTORY FOR ASSISTANCE

If the Apollo CNX80 unit fails to operate despite troubleshooting efforts, contact UPS Aviation Technologies Technical Support for assistance.

UPS Aviation Technologies  
2345 Turner Rd. SE  
Salem, Oregon 97302  
USA

Phone: 503.581.8101 or 800.525.6726 (ext. 3991)  
<http://www.upsat.com>

Be prepared to offer the following information about the installation:

- Installation configuration (list of any accessories)
- Model number, part number with mod levels, and serial number
- Software Versions
- Description of problem
- Efforts made to isolate the problem

## **5 LIMITATIONS**

### **5.1 OPERATION**

There are no Part 23 aircraft type limitations. All functions of the CNX80 meets the appropriate design assurance qualifications for primary or secondary for airplane Class I, Class II, Class III, and Class IV in accordance with AC 23.1309-1C Figure 2. The TSO authorizations with the RTCA/DO178B software levels by function are listed in Table 1-1.

The CNX80 complies with paragraph 3a of TSO-C146a for Class I, II, III, and IV aircraft as defined in AC 23-1309-1C.

TSO-C146a defines loss of function of en route, terminal, nonprecision approach, or precision approach navigation data as a major failure condition. AC 23.1309-1C provides guidance for IFR airplanes that classifies total loss of function as a major failure condition, and loss of primary means of function as minor if two navigation systems are installed. One method to meet the major failure condition for loss of function is to install redundant systems. It is recommended that the aircraft be equipped with at least two independent navigation receivers and two independent communication transceivers for IFR use. This will support a System Safety Assessment of minor for IFR operations. Refer to AC 23.1309-1C.

### **5.2 INSTALLATION**

The conditions and test required for TSO approval of this article are minimum performance standards. It is the responsibility of those installing this article either on or within a specific type or class of aircraft to determine that the aircraft installation conditions are within the TSO standards. TSO articles must have separate approval for installation in an aircraft. The article may be installed only if performed under 14 CFR part 43 or the applicable airworthiness requirements.

The CNX80 WAAS/GPS receiver and antenna are compatible with aircraft equipped with SATCOM.

#### **5.2.1 GPS ANTENNA**

The WAAS/GPS receiver is only compatible with the UPSAT A-33 (590-1104) or A-34 (590-1112) antennas, or those with equivalent specifications. Refer to section 1.3.10.1 for specifications.

### **5.3 AIRCRAFT RADIO STATION LICENSE**

An aircraft radio station license is not required when operating in U.S. airspace, but may be required when operating internationally.



**TSO PENDING**

## 6 PERIODIC MAINTENANCE

### 6.1 EQUIPMENT CALIBRATION

No scheduled servicing tasks are required on the Apollo CNX80. The Apollo CNX80 design requires **no** internal manual adjustments.

### 6.2 VOR CHECKS

Even though the CNX80 is designed to utilize the most state-of-the-art DSP technology and maintain a very high accuracy and repeatability record, it still must undergo the VOR accuracy check required for IFR flight. Refer to CFR 14 paragraph 91.171. Every 30 days verify the limits of the permissible indicated bearing error.

The last VOR check information may be entered into the CNX80 via the Nav VOR Mode then on the Test Log Menu page.

### 6.3 CLEANING

The front bezel, keypad, and display can be cleaned with a soft cotton cloth dampened with clean water. DO NOT use any chemical cleaning agents. Care should be taken to avoid scratching the surface of the display.

### 6.4 BATTERY REPLACEMENT

The CNX80 includes an internal battery that will last about 10 years. The battery is used for internal RAM memory and GPS system information. Regular planned replacement is not necessary. The CNX80 will display a "low battery" message when replacement is required. Once the low battery message is displayed, the battery should be replaced within 1 to 2 months.

If the battery is not replaced and becomes totally discharged, the CNX80 will remain fully operational, but the GPS signal acquisition time will be increased. This acquisition time can be reduced by entering a new seed position each time the unit is powered on. There is no loss of function or accuracy of the CNX80 with a dead battery.

The battery is not user replaceable. To replace the battery, contact the UPS Aviation Technologies repair station or factory authorized repair station.

### 6.5 DISPLAY BACKLIGHT

The display backlight is rated by the manufacturer as having a usable life of 20,000 hours. This life may be more or less than the rated time depending on the operating conditions of the CNX80. Over time, the backlight will dim and the display will not perform as well in direct sunlight conditions. The user must determine by observation when the display brightness is not suitable for its intended use. Contact UPS Aviation Technologies repair station or factory authorized repair station when the backlight requires service.

**NOTES**

---

## APPENDIX A - CERTIFICATION DATA

### A.1 ENVIRONMENTAL QUALIFICATION

The Apollo CNX80 has been tested to the following environmental categories per procedures defined in RTCA/DO-160D. Tests were conducted from September 2002 to April 2003 using the original 1997 revision of DO-160D and specification defined in PD3107.

Environmental Qualification Form		
Nomenclature: CNX80 Part No.: 430-6100-8xx-xxx TSO No.: C34e, C36e, C37d, C38d, C40c, C113, C128, C146a	Manufacturer: UPS Aviation Technologies 2345 Turner Road SE Salem, Oregon 97302	
Conditions	Section	Description of Conducted Tests
Temperature and Altitude	4	Equipment tested to Category C1 & A1 Operating temp: -20°C to +55°C Short time high temp: to +70°C Ground survival temp: -55°C to +85°C Altitude: 35,000 feet Decompression: 55,000 feet [1] Overpressure (non-operating) No external cooling required provided internal fans are unobstructed and operating. [2]
Temperature Variation	5	Equipment tested to Category C, 2°C/min
Humidity	6	Equipment tested to Category A, standard humidity environment
Operational Shocks and Crash Safety	7	Equipment tested for both operational and crash safety shocks to Category B Type 5R Equipment operated normally after crash shocks. (20 Gs at 11 msec (impulse) and 3 sec (sustained))
Vibration	8	Equipment tested without shock mounts to Category S (Curves B, M) and Category U (curves F, F1)
Explosion Proofness	9	Equipment identified as Category X, no test required
Waterproofness	10	Equipment identified as Category X, no test required
Fluids Susceptibility	11	Equipment identified as Category X, no test required
Sand and Dust	12	Equipment identified as Category X, no test required
Fungus Resistance	13	Equipment identified as Category X, no test required
Salt Spray	14	Equipment identified as Category X, no test required
Magnetic Effect	15	Equipment is Class Z (Dc is at 0.185 meters)
Power Input	16	Equipment tested to Category A & B (14 and 28 VDC system)
Voltage Spike	17	Equipment tested to Category A
Audio Frequency Conducted Susceptibility - Power Inputs	18	Equipment tested to Categories A & B
Induced Signal Susceptibility	19	Equipment tested to Category C
Radio Frequency Susceptibility (Radiated and Conducted)	20	Equipment tested to Category VV- (Category V Conducted, Category V Radiated. No Pulsed test performed.)
Emission of Radio Frequency Energy	21	Equipment tested to Category M
Lightning Induced Transient Susceptibility	22	Equipment identified as Category A3 B2
Lightning Direct Effects	23	Equipment identified as Category X, no test required
Icing	24	Equipment identified as Category X, no test required
Electrostatic Discharge (ESD)	25	Equipment tested to Category A

**Remarks:**

- [1] Operation at 55,000 feet verified for 30 minutes following decompression
- [2] Also passed Category P In Flight Loss of Cooling (180 min at +30 °C) with internal fans not operating.
- Passed the Thermal Shock test (+55C to -20C in < 20 sec) required by TSO C113 (per AS8034 paragraph 5.23).
- Passed the Operating Overpressure test (170 kPa) required by TSO C113 (per AS8034 paragraph 5.2.5).
- Passed GPS L1 Radiated Susceptibility test (20 mV/meter) required by TSO C146a (per DO-229C para 2.4.1.2.3).

**TSO PENDING**

## A.2 CNX80 STC DATA

Refer to UPSAT document 560-0988-00 for data regarding CNX80 STC authorization. This document contains information on the following items:

- Supplementary Type Certificate (STC)
- STC Permission
- STC Master Data List
- Airplane Flight Manual (AFM) Supplement
- Instructions for Continued Airworthiness (ICA)

## APPENDIX B - SERIAL INTERFACE SPECIFICATIONS

This appendix includes the RS232 serial port interface specifications.

The RS-232 serial interface configurations supported by the CNX80 are described below. Instructions for configuring the serial port are included in the checkout procedure in section 3.2.1.1. Serial output connections should be limited to a maximum of three external units.

### B.1 SERIAL INPUT SPECIFICATIONS

Available settings for the serial inputs are listed in Figure 3-2. Not all settings are available on each serial input port – refer to section 3.2.1.1 to determine which settings are available on a given port.

Table B- 1 - RS-232 Serial Input (RX) Selections		
RX	Comment	Reference
NONE	No input connected.	N/A
MAPMX	Proprietary interface between CNX80 and MX20 v5.0 or later. This interface will support auto chart selection, flight plans, zoom scale matching, altimeter correction, and ILS and VOR navigation information. (MUST BE USED WITH MAPMX SELECTED ON SAME OUTPUT PORT)	N/A
CNX80	Proprietary interface to second CNX80 for cross-talking data (MUST BE USED WITH CNX80 SELECTED ON SAME OUTPUT PORT)	N/A
ALTENC	Altitude encoder data.	B.1.1
FADC	Fuel/Air Data Computer data.	B.1.2
SL30	Tuned Nav station data. Refer to SL30 installation manual.	560-0404-xx
SL70	SL70/SL70R mode control and altitude data. Refer to SL70 installation manual.	560-0402-xx
IRDA	Not currently supported.	N/A

#### B.1.1 Altitude Encoder/Converter Input

The format of the altitude input is as follows. Definition of the input message is included in Table B- 2. Several sample messages are illustrated in Figure B- 1.


Baud rate: ..... 1200/9600  
Data bits: ..... 8  
Stop bits: ..... 1  
Parity: ..... none  
Expected input rate: ..... approx. 1 second  
Message length: ..... 17 characters

**Table B- 2 - Altitude Input Data**

<b>Byte</b>	<b>Data Format</b>	<b>Description</b>
1	"#"	ASCII "#" (023h)
2	"A"	ASCII "A" (041h)
3	"L"	ASCII "L" (04Ch)
4	" "	ASCII space (020h)
5	"+" or "-"	Altitude sign: ASCII "+" or "-" (02Bh or 02Dh)
6-10	ddddd	Altitude in feet, right justified with leading zeros
11	"T"	ASCII "T" (054h)
12	"+" or "-"	Temperature sign: ASCII "+" or "-" (02Bh or 02Dh)
13-14	dd	Internal altimeter temperature
15-16	dd	Checksum of bytes 1 through 14, computed in hex, output in ASCII format (i.e., "FA" hex)
17	<CR>	ASCII carriage return (0Dh)

The altitude input can decode several status or error codes. These codes would be in place of the altitude data in characters 5 - 10 as follows.

- "-09980" .....Heater not ready: expected during encoder warm-up or if there is a loss of signal from the encoder.
- "-09981" .....Possible hardware problem: expected from encoder indicating a temperature greater than 55°C or if data is invalid.
- "-09982" .....Altitude out of range: expected from the encoder indicating that the altitude is outside specified range of the encoder.

**Figure B- 1 - Altitude Data Input**

## B.1.2 Fuel/Air Data Computer Input

The fuel/air data input is used to input fuel flow and airdata computer information from the fuel/air data computer. Both the Shadin “S” format and Shadin “Z” format data are automatically accepted.

### B.1.2.1 “S” Data Format

The format of the fuel/air data computer input is as follows, which conforms to the Shadin “S” format serial message. Definition of the input message data that the CNX80 uses is included in Table B- 3. A sample input message is illustrated in Figure B- 2.

Baud rate: ..... 9600  
 Data bits: ..... 8  
 Stop bits: ..... 1  
 Parity: ..... none  
 Expected input rate: ..... approx. 1 second  
 Message length: ..... variable (512 character max.)

The serial input message string is expected in the following format.

<STX><message><message> ... <message><checksum><ETX>  
 <STX> ..... ASCII “start of text” character (STX = 02h)  
 <message> ..... starts with an ASCII “S”, then an ID character, followed by the message data, a carriage return (CR = 0Dh), and a line feed (LF = 0Ah) See the following table. s = a sign indicator (-,+E,W). d = a decimal digit (0-9)  
 <checksum> ..... the message checksum, same format as message  
 <ETX> ..... ASCII “end of text” character (ETX = 03h)

**Table B- 3 - Fuel/Air Data Message Data (S Format)**

Item Desig	Message Format	Message Mnemonic	Field Width	Message Description
SA	ddd	IAS	7	Indicated Air Speed in knots
SB	ddd	TAS	7	True Air Speed in knots
SC	ddd	MACH	7	Mach Speed in thousandths
SD	sdddd	PALT	9	Pressure Altitude in tens of feet, +/- sea level
SE	sdddd	DALT	9	Density Altitude in tens of feet, +/- sea level
SF	sdd	OAT	7	Outside Air Temp - or “Total”, in degrees Celsius
SG	sdd	TAT	7	True Air Temp - or “Static”, in degrees Celsius
SH	ddd	WDIR	7	Wind Direction, 0 to 359 degrees from true north
SI	ddd	WSPD	7	Wind Speed in knots
SJ	sdd	TURN	7	Rate of Turn in +/- degrees/second, + is right, - is left
SK	sddd	VSPD	8	Vertical speed in tens of feet/minute
SL	ddd	HEAD	7	Heading, 0 to 359 degrees from true north
SM	dddd	RFF	8	Right Engine Fuel Flow in tenths of gallons/hour
SN	dddddd	RFU	9	Right Engine Fuel Used in tenths of gallons
SO	dddd	LFF	8	Left Engine Fuel Flow in tenths of gallons/hour
SP	ddddd	LFU	9	Left Engine Fuel Used in tenths of gallons
SQ	ddd	ERR	7	Error Log / Reason Indicator: 001 = temp sensor error; 000 = no errors

**Table B- 3 - Fuel/Air Data Message Data (S Format)**

<b>Item Desig</b>	<b>Message Format</b>	<b>Message Mnemonic</b>	<b>Field Width</b>	<b>Message Description</b>
SR	ddddd	REM	10	Fuel remaining (0-9999.9 in gallons)
S*	ddd	CKSUM	7	Checksum of all characters preceding this record. The checksum is a one byte checksum (discarding carries) including all characters from the initial STX up to and including the line feed preceding the checksum message.

**Example Fuel / Airdata Input Data**

<STX>SA223	223 knots indicated air speed
SB230	230 knots true air speed
SC101	0.101 mach
SD+3200	32,000 feet pressure altitude
SE+3312	33,120 feet density altitude
SF+05	+5°C outside air temp
SG-03	-3°C true air temp
SH010	wind direction at 10° (relative to true north)
SI015	wind speed at 15 knots
SJ+03	+3° / second right turn
SK-050	-50 feet / second vertical air speed
SL359	359° heading (relative to true north)
SM0123	12.3 gallons / hour - right engine fuel flow
SN0300	30.0 gallons used - right engine
SO0131	13.1 gallons / hour - left engine fuel flow
SP0310	31.0 gallons used - left engine
SQ000	no errors
SR01227	122.7 gallons remaining
S*123	Checksum (example only, not actual)
<ETX>	end of message string

**Figure B- 2 - Fuel / Airdata Data Input (S Format)****B.1.2.2 “Z” Data Format**

The format of the fuel/air data computer input is as follows, which conforms to the Shadin “Z” format serial message. Definition of the input message data that the CNX80 uses is included in Table B- 4.

Baud rate: ..... 9600  
 Data bits: ..... 8  
 Stop bits: ..... 1  
 Parity: ..... none  
 Expected input rate: ..... approx. 1 second  
 Message length: ..... variable (512 character max.)

The serial input message string is expected in the following format.

<STX><message><message> ... <message><checksum><ETX>  
 <STX> ..... ASCII “start of text” character (STX = 02h)  
 <message> ..... starts with an ASCII “Z”, then an ID character, followed  
                   by the message data, a carriage return (CR = 0Dh), and a  
                   line feed (LF = 0Ah) See the following table.  
 <checksum> ..... the message checksum, same format as message  
 <ETX> ..... ASCII “end of text” character (ETX = 03h)

**Table B- 4 - Fuel/Air Data Message Data (Z Format)**

Item Desig	Message Format	Message Mnemonic	Field Width	Message Description
ZA	ddd	IAS	7	Indicated Air Speed in knots
ZB	ddd	TAS	7	True Air Speed in knots
ZC	ddd	MACH	7	Mach Speed in thousandths
ZD	sdddd	PALT	9	Pressure Altitude in tens of feet, +/- sea level
ZE	sdddd	DALT	9	Density Altitude in tens of feet, +/- sea level
ZF	sdd	OAT	9	Outside Air Temp - or “Total”, in degrees Celsius
ZG	sdd	TAT	7	True Air Temp - or “Static”, in degrees Celsius
ZH	ddd	WDIR	7	Wind Direction, 0 to 359 degrees from true north
ZI	ddd	WSPD	7	Wind Speed in knots
ZJ	sdd	TURN	7	Rate of Turn in +/- degrees/second, + is right, - is left
ZK	sddd	VSPD	8	Vertical speed in tens of feet/minute
ZL	ddd	HEAD	7	Heading, 0 to 359 degrees from true north
ZM	dddd	RFF	8	Right Engine Fuel Flow in tenths of gallons/hour
ZN	ddddd	RFU	9	Right Engine Fuel Used in tenths of gallons
ZO	ddd	LFF	7	Left Engine Fuel Flow in tenths of gallons/hour
ZP	ddddd	LFU	9	Left Engine Fuel Used in tenths of gallons
ZQ	ddd	ERR	7	Error Log / Reason Indicator: 001 = temp sensor error; 000 = no errors
ZR	ddddd	CKSM1	7	Checksum of labels A to Q (0 to 255)
ZS	ddd	GSP	7	Ground speed (0-999 knots)
ZT	ddd	TRK	7	Track (0 to 359 degrees, magnetic)
ZU	ddddd	DIS	1	Distance to Destination (0 to 999999, nm * 100)
ZV	sdd	MVAR	8	Magnetic Variation (0 to 999 degrees, deg * 10), s = E or W where E = east, W = west
ZW	ddmmhh	LAT	13	Current Latitude, s = N or S, dd = degrees, mm = minutes
ZX	sddmmhh	LON	14	Current Longitude, s = E or W, ddd = degrees, mm = minutes, hh = hundredths of minutes
ZY	ddd	CKSUM2	7	Checksum of labels S to X (0 to 255)

## B.2 SERIAL OUTPUT SPECIFICATIONS

Available settings for the serial outputs are listed in Table B- 5. Not all settings are available on each serial output port – refer to section 3.2.1.1 to determine which settings are available on a given port.

Table B- 5 - RS-232 Serial Output (TX) Selections		
TX	Comment	Reference
NONE	No input connected.	N/A
MAPMX	Proprietary interface between CNX80 and MX20 v5.0 or later. This interface will support auto chart selection, flightplans with the new flight legs, zoom scale matching, altimeter correction, and ILS and VOR navigation information. (MUST BE USED WITH MAPMX SELECTED ON SAME INPUT PORT)	N/A
CNX80	Proprietary interface to second CNX80 for cross-talking data (MUST BE USED WITH CNX80 SELECTED ON SAME INPUT PORT)	N/A
MAPCOM	Moving map output data, nearest waypoint data, annunciator data, flight plan waypoints and nav/com data.	B.2.1
SL70	SL70/SL70R mode control and altitude data. Refer to SL70 installation manual.	560-0402-xx
IRDA	Not currently supported.	N/A

### B.2.1 Mapcom Output

When MAPCOM is selected, the CNX will transmit moving map data, nearest waypoint data, flight plan waypoints, and nav/com data on this output. The format of the MapCom output is as follows:

Baud rate: ..... 9600  
 Data bits: ..... 8  
 Stop bits: ..... 1  
 Parity: ..... none  
 Output rate: ..... approx. 1 sec. +/- 0.5 sec.  
 Message length: ..... variable, approx. 164 to 958 bytes

#### B.2.1.1 Moving Map Data

Definitions of the Moving Map output data are included in Table B- 6 and Table B- 7. A sample output message is included in .

The serial output messages are in the following format.

```
<STX><id><data><it><id><data><it>...<id><data><it><ETX>

<STX> ..... ASCII “start of text” character (1 byte, 02h)
<id> ..... item designator (1 byte, from following table)
<data> ..... item data (format listed in following table)
<it> ..... item terminator (1 byte, 0Dh)
<ETX> ..... ASCII “end of text” character (1 byte, 03h)
```

**Table B- 6 - Moving Map ASCII Navigation Data**

<b>ID</b>	<b>Data Format</b>	<b>Length</b>	<b>Description</b>
A	sddmmhh	9	Present latitude s = sign: N for north, S for south dd = degrees mm = minutes hh = hundredths of minutes
B	sdddmmhh	10	Present longitude s = sign: E for east, W for west ddd = degrees mm = minutes hh = hundredths of minutes
C	ddd	3	Track (magnetic): ddd = degrees
D	ddd	3	Ground speed: ddd = knots
E	dddddd	5	Distance to active waypoint: dddddd = nm x 10
G	sdddd	5	Cross track error: s = sign: R for right, L for left of course dddd = distance off course, hundredths of nm
I	dddd	4	Desired track (magnetic): dddd = degrees x 10
K	ddd[dd]	3 to 5	Active waypoint identifier: ddd[dd] = ASCII waypoint identifier
L	dddd	4	Bearing to active waypoint (magnetic): dddd = degrees x 10
Q	sddd	4	Magnetic variation: s = sign: E for east, W for west ddd = degrees x 10
T	---A----	9	Warnings: The 4th character will be an "A" when the navigation data is flagged, otherwise, all characters will be dashed. All other navigation data will be dashed when it is flagged.
a	eamph	8	<b>Annunciator Flags:</b> e = <b>Approach Enabled</b> { '-' (off)    'O' (on) } a = <b>Approach Active</b> { '-' (off)    'O' (on)    'B' (blink) } m = <b>Message</b> { '-' (off)    'O' (on)    'B' (blink) } p = <b>Parallel Track</b> { '-' (off)    'O' (on) } h = <b>Hold</b> { '-' (off)    'O' (on)    'B' (blink) } t = <b>From/To</b> { '-' (off)    'T' (To)    'F' (From) }
c	vDddd	7	<b>CDI:</b> v = <b>Nav Flag</b> { '-' Flagged    'v' Valid } D = <b>Needle</b> { 'C' Center    'L' Left    'R' Right } ddd = <b>Deflection Value</b> ASCII (000 – 120)
l (lower case L)	dddddd	6	Distance to Destination: dddddd = nm * 10

**Table B- 6 - Moving Map ASCII Navigation Data**

<b>ID</b>	<b>Data Format</b>	<b>Length</b>	<b>Description</b>
p	sdddd	7	s = ± dddd = {0000 - 5999} Pressure Altitude (-1500 to +5999 tens of feet +/- sea level). Field is dashed when invalid “----”.
v	vDddd	7	<b>VDI:</b> v = <b>VDI Flag</b> { ‘-’ Flagged    ‘v’ Valid } D = Needle { ‘C’ Center    ‘U’ Up    ‘D’ Down } ddd = <b>Deflection Value</b> ASCII (000 – 120)
h	sddd	4	<b>Horizontal Command Signal:</b> s=sign: L = bank left. R = bank right. X = invalid data. ddd = degrees * 10

**Table B- 7 - Moving Map Binary Route Data**

<b>Byte</b>	<b>Data Format</b>	<b>Description</b>
1	w	Item designator
2-3	dd	Current waypoint number in ASCII (01h to 20h)
4	xiannnnn	Sequence number x = undefined i = 1 if last waypoint a = 1 if active waypoint nnnnn = unsigned binary waypoint number
5-9	ddddd	ASCII waypoint identifier
10 11 12	sddddddd xxmmmmmm xhhhhhhh	Waypoint latitude - packed, unsigned binary s = sign: 0 for north, 1 for south ddddd = degrees mmmmmm = minutes hhhhhhh = hundredths of minutes x = undefined
13 14 15 16	sxxxxxxx ddddd = degrees xxmmmmmm xhhhhhhh	Waypoint longitude s = sign: 0 for east, 1 for west ddddd = degrees mmmmmm = minutes hhhhhhh = hundredths of minutes x = undefined
17 18	nnnnnnnn nnnnnnnn	Magnetic variation at waypoint LS byte (msbit...lsbit) MS byte (msbit...lsbit) Two's complement binary in sixteenths of degrees, easterly variation is positive.
19	<CR>	ASCII carriage return (0Dh)

### B.2.1.2 Binary Nearest List Data

The nearest waypoint lists are sent one waypoint per data transmission set. The lists are sent in the following order:

- LFAC
- VOR
- NDB
- INT
- User

There is a maximum of twenty waypoints per type. The waypoints are a maximum of 600 nm from the current position. The waypoints are order by distance from current position nearest to farthest. The maximum time to send all lists is 100 seconds. Each list is updated just prior to the first waypoint in the list being sent. If a list is empty a shorter record will be sent with the List Item Number set to 0xFF.

**Table B- 8 - Nearest Waypoint List Data**

Byte	Format	Description
1	Z	<b>'Z' Item Designator</b>
2	sddddddd	<b>List Item Number:</b> Packed, unsigned binary values s = 1 End of list, 0 all other ddddd = 1 – 20 list waypoint index sdddddd = 0xFF List Type is EMPTY ( <b>BYTE 4 terminate Item</b> )
3	t	<b>Waypoint Type:</b> t = {a (airport)    v (VOR)    n (NDB)    i (INT)    u (USER)}
4	Cr	<b>'\r' Item Terminator &lt;0x0d&gt; (ONLY IF BYTE 2 = OxFF)</b>
4-8	ddddd	<b>ASCII Waypoint Identifier</b>
9 10 11	sddddddd xxmmmmmm xhhhhh	<b>Latitude of waypoint.</b> Packed, unsigned binary values for degrees, minutes and hundredths of minutes. s = 0 North latitude, 1 South latitude x = undefined ddddd = Latitude degrees mmmmmm = Latitude minutes hhhhh = Latitude hundredths of minutes
12 13 14 15	sxxxxxx dddddddd xxmmmmmm xhhhhh	<b>Longitude of waypoint.</b> Packed, unsigned binary values for degrees, minutes and hundredths of minutes. s = 0 East longitude, 1 West longitude x = undefined ddddd = Longitude degrees mmmmmm = Longitude minutes hhhhh = Longitude hundredths of minutes
16	Cr	<b>'\r' Item Terminator &lt;0x0d&gt;</b>

### B.2.1.3 Flight Plan Waypoint Type Data

The following data is only transmitted when preceded by flight plan data. There is one character per flight plan waypoint transmitted.

**Table B- 9 - Flight Plan Waypoint Type**

<b>Id</b>	<b>Item Format</b>	<b>Len</b>	<b>Description</b>
t	nnn...	1-21	n = { a (airport)    v (VOR)    n (NDB)    i (intersection)    u (user)    p (parallel track)    d (direct to)    F (FAF)    E (DME)    I (IAF)    H (MAHP)    M (MAP)    A (IFAF)    P (undefined approach waypoint type) }

### Example Moving Map Data Output

AN 34 1570	34°15.70' latitude
BW 118 4390	118°43.90' longitude
C306	306° track angle
D210	210 knots
E02682	268.2nm to waypoint
GR0006	0.6nm right of course
I3059	305.9° desired track
KSFO	SFO waypoint ident
L3058	305.8° bearing to waypoint
QE140	14.0° east magnetic variation
T-----	No alarms, data not flagged
<binary data>	From Table B- 7
a-O--F	Approach Enabled Off, Active Off, Message On, Parallel Track Off, Hold Off, and From/To is FROM
cvR001	CDI Valid, Needle Right, Deflection 001°
p+0008	Pressure Altitude, +80 ft
vC000	VDI Valid, Needle Centered, Deflection is 000°
<binary data>	From Table B- 7
tda	Flight Plan Waypoint Type data, direct-to, airport type

**Figure B- 3 - Moving Map Data Output**

**B.2.1.4 NavComm Data**

The definition of the NavComm portion of the MapCom data output is as follows. This data output is compatible with the SL30 or SL40 for sending frequency data to the comm or nav unit.

The comm data is output using the following format.

```
$PMRRC<msg_id><msg_data><checksum><cr>
$PMRRV<msg_id><msg_data><checksum><cr>
```

The checksum is computed by an 8 bit addition of the msg\_id and msg\_data characters, ignoring carry if any. The resulting 8 bit checksum is converted to two ASCII characters by taking the upper and lower nibbles, adding 30h to each, and placing the most significant character first in the data message.

**B.2.1.4.1 Airport Ident Output**

This message is used to output the selected airport ident.

**Message Format**

```
$PMRRC04iiii<checksum><cr>
```

04 ..... message id  
t ..... list type, outputs a 1  
iiii..... ident, four character ASCII

**Example Message**

```
$PMRRC041SLE<space>99<cr>
```

Output ident of “SLE” for the following frequency information.

**B.2.1.4.2 Frequency Data Output**

This message is used to output the airport frequency information for the previously output ident.

**Message Format**

```
$PMRRC05tfmk<checksum><cr>
```

05	message id	8 = CTF, common traffic advisory frequency
t	list type, input 1	9 = DEP, departure
f	frequency type: 0 = TWR, tower frequency 1 = GND, ground frequency 2 = ATS, for ATIS 3 = ATF, air traffic frequency 4 = APP, for approach 5 = ARR, for arrival 6 = AWS, automatic weather station 7 = CLR, clearance/delivery	: (3Ah) = FSS, flight service station ; (3Bh) = RFS, for remote flight service station < (3Ch) = UNI, for unicom = (3Dh) = MF, mandatory frequency > (3Eh) = CTR (Center) ? (3Fh) = undefined, for other frequency types
mk	frequency: m = desired frequency in MHz in hexadecimal, where m = desired frequency - 30h , with the desired frequency in the range of 118 to 136 MHz, or 162 MHz.	
	k = desired frequency in kHz where k = (desired frequency / 25 kHz) + 30h, with the desired frequency in the range of 000 to 975 kHz in 25 kHz steps, or 0 to 39.	

**Example Message**

\$PMRRC0511IT64<cr>

The above example message outputs a ground frequency type, 121.900 MHz.

**B.2.1.4.3 Remote VOR List**

The following two commands work together in allowing the CNX80 to provide a list of VOR frequencies to a remote device (such as the SL30). The CNX80 will send a sequence of Remote VOR Input commands (message identifier 20). When all of the VOR Input commands have been sent, the CNX80 will send a Remote VOR List Trailer command (message identifier 21) to terminate the list. The transmitted list should not be considered complete by remote device until it receives the trailer message. The remote device should maintain a single remote VOR list, so each list transmitted will replace any previous list. There may be up to twenty entries in the remote VOR list.

**B.2.1.4.3.1 Remote VOR Output**

This output is used to provide VOR frequency data that is used for the remote recall function.

The data consists of five characters for the VOR station identifier followed by two characters defining the VOR frequency.

**Message format:**

- |      |   |
|------|---|
| “V”  | Message Class. This is a VHF NAV message.   |
| “20” | Message Identifier.   |
| vvvv | VOR station identifier. Note that if the station identifier is less than four characters, then the trailing characters will be filled with spaces. Station Identifiers are restricted to using ASCII characters 0-9 and A-Z.  |
| mk   | Frequency: m = MHz, where m = desired MHz frequency – 30h, with the desired frequency ranging from 108 to 117, or 3Ch to 45h; k = kHz, where k = (desired kHz offset / 25 kHz) + 30h, with desired frequency range of 000 to 975 kHz in 50 kHz steps, or the even numbers from 30h to 56h. Note that the field will be checked to ensure that it is in range and a valid VOR frequency. Frequencies used for localizers, which are in the range of 108.10 to 111.95 MHz, will not be accepted in this message type. |

**Example message:**

\$PMRRV20UBG<Sp>E@<chksm><CR><LF>

VOR station identifier is “UBG ”, VOR frequency is 117.400 MHz.

**B.2.1.4.3.2 Remote VOR List Trailer**

This output command marks the end of a VOR list sent by the CNX80.

**Message format:**

- |      |   |
|------|---|
| “V”  | Message Class. This is a VHF NAV message. |
| “21” | Message Identifier                        |

**Example message:**

\$PMRRV21<chksm><CR><LF>

Indicates the start of a remote VOR list.

**B.2.1.4.4 Remote Localizer List**

The following two commands work together in allowing the CNX80 to provide a list of localizer frequencies associated with an airport to a remote device (such as the SL30). The CNX80 will first send the Remote Localizer List Header command (message identifier 22), followed by a sequence of Remote Localizer Input commands (message identifier 23). The remote device should maintain a single remote localizer list, so each new list received will replace any previous list. Subsequent receptions of localizer lists for the same airport may be ignored. There may be up to twenty entries in the remote Localizer list.

**B.2.1.4.4.1 Remote Localizer List Header**

This output command marks the beginning of a Localizer list sent by the CNX80. It specifies the five character airport identifier associated with the localizer frequencies in the list.

**Message format:**

“V” ..... Message Class. This is a VHF NAV message.  
 “22” ..... Message Identifier.  
 aaaa ..... Airport identifier. Note that if the airport identifier is less than four characters, then the trailing characters will be filled with spaces. Airport Identifiers are restricted to using ASCII characters 0-9 and A-Z.

**Example message:**

\$PMRRV22SLE<Sp><checksum><CR><LF>

Indicates the start of a remote localizer list associated with the airport “SLE ”.

**B.2.1.4.5 Remote Localizer Input**

This output is used to provide Localizer frequency data that is used for the remote recall function.

The data consists of three characters to identify the runway associated with the localizer, followed by two characters defining the frequency.

**Message format:**

“V” ..... Message Class. This is a VHF NAV message.  
“23” ..... Message Identifier.  
iiii ..... Station or Runway identifier. This field will provide an identifier for the localizer which can be either the actual station identifier or a string indicating the runway associated with the localizer. The station identifier can be up to four characters long. A runway identifier will typically be two numbers that indicate the runway direction followed by the character “R”, “C”, or “L” to differentiate between parallel runways (right, center, and left). Note that if either type of identifier is less than four characters, then the trailing characters will be filled in with spaces. Identifiers are restricted to using ASCII characters 0-9 and A-Z.  
mk..... Frequency: m = MHz, where m = MHz frequency – 30h, with the desired frequency ranging from 108 to 111 MHz, or 3Ch to 3Fh; k = (desired kHz offset / 25 kHz) + 30h, where the desired frequency ranges from 000 to 950 kHz, or the even numbers from 30h to 56h. Note that the field will be checked to ensure that it is in range and a valid localizer frequency. Frequencies used for VORs, which can also be found in the range of 108.10 to 111.95 MHz, will not be accepted in this message type.

**Example message:**

\$PMRRV2331<Sp><Sp>><<chksm><CR><LF>

Identifier is “31 ”, indicating a runway, and the localizer frequency is 110.300 MHz.

**B.2.1.4.6 Distance/Speed/Time Message**

If an SL30 is connected to the CNX80, the CNX80 will sent the following message to the SL30.

\$PMRRV41xxxxyyzzz<CHECKSUM><CR><LF>  
xxxx is the distance to the station in 0.1nm units  
yyy is the ground speed in knots  
zzz is the time to the station in minutes

This message is used to output the range, ground speed, and ETA decoded from an external RNAV sensor (DME or GPS).

**Message format:**

“V” ..... Message class. This is a VHF NAV message.  
“41” ..... Message identifier.  
rrrr ..... Range from DME station in 1/10<sup>th</sup> of a nautical mile units. The first two digits are the 10s and 1s place of the range, and the last digit is the 1/10<sup>th</sup>s place. This field may range in value from 0.0 NM (“0000”) to 999.9 NM (“9999”). If the distance from the DME station is greater than 999.9NM, the value should be encoded as “---”.  
sss ..... Ground speed with respect to DME station in knots. This field may range in value from 0 knots (“000”) to 999 knots (“999”). If the ground speed with respect to the DME station is greater than 999 knots, the value should be encoded as “---”.  
hmm..... Time to station in hours and minutes. This field may range in value from 0 hours and 0 minutes (“000”) to 9 hours and 59 minutes (“959”). If the time to the station is greater than 9 hours and 59 minutes, the value should be encoded as “---”.

**Example message:**

\$PMRRV410983055147<chksm><CR><LF>

Range from DME station is 98.3 NM, ground speed with respect to station is 55 knots, and the estimated time to the station is 1 hour and 47 minutes.

## APPENDIX C - EQUIPMENT COMPATIBILITY

### C.1 ALTITUDE SOURCES

The following altitude sources are compatible with the CNX80. Other altitude data sources may be used provided they meet the serial specifications defined in B.1.1 or provide the ARINC 429 labels defined in 2.8.10.2.1.

Manufacturer	Model	Data Format	Notes
Trans-Cal	SSD120	RS232	High resolution (10 ft) encoder
ICARUS	3000U	RS232	Low resolution (100 ft) serializer
Sandia Aerospace	SAE5-35	RS232	High resolution (10 ft) encoder
UPSAT	SL70/ SL70R	RS232	If the SL70 is provided with gray code altitude from any standard encoder, the SL70 will transmit altitude data (100 ft resolution) to the CNX80. For the SL70, altitude data is provided to serial port 6 configured for SL70.
B & D Instruments	90004	ARINC 429	Low-speed

### C.2 FUEL/AIR DATA COMPUTERS

The following fuel/air data computers are compatible with the CNX80. Other altitude data sources may be used provided they meet the serial specifications defined in B.1.2.

Manufacturer	Model	Data Format	Notes
Shadin	F/ADC-200 F/ADC-2000 DigiData	RS232	[1]
Shadin	Digiflo-L Miniflo-L Microflo-L	RS232	Fuel data only
JP Instruments	FS-450	RS232	Fuel data only
JP Instruments	EDM-700/800	RS232	Fuel Flow option (Fuel data only)

[1] If it is desired to have the F/ADC calculate wind data, ground speed and track angle must be provided to the FADC using a CNX80 MAPCOM RS232 output. If the MAPCOM data is not supplied to the FADC, the CNX80 will calculate wind data using other data supplied by the FADC.

### C.3 HEADING SOURCES

The following heading sources are compatible with the CNX80. Other heading sources may be used provided they meet the provide the ARINC 429 labels defined in section 2.8.10.2.1 or provide standard XYZ synchro data.

Manufacturer	Model	Interface	Notes
Litef	LCR-92/93	ARINC 429	High-speed
Litton	LTN-92	ARINC 429	High-speed
Century Flight Systems	1D755	Synchro	Bootstrap output from HSI
Sandel Avionics	SN3308	ARINC 429	Low-speed
Bendix/King	KCS55/KI525A	Synchro	Bootstrap output

## C.4 ALTIMETERS FOR BARO CORRECTION

The following altimeters are compatible with the CNX80. Other altimeters may be used to provide baro correction to the CNX80 provided they have a potentiometer with a minimum resistance of 5 kΩ.

Manufacturer	Model	Notes
Bendix/King	KEA-130A KEA-346	
Kollsman	44929-935 24929-519 thru 532	
Aerosonic	10420-11968E	
United Instruments	5506-S(0)3(-)	

## C.5 AUTOPILOTS

The following autopilots are compatible with the CNX80. Other autopilots may be used with the CNX80 provided that they have a Nav mode and accept analog deviation data and flags meeting the specifications defined in section 1.3.9.1.1.

Manufacturer	Model	Interface	Notes
S-TEC	System 20/30/40/50/60-1/60-2/60 PSS/65	Analog deviation	
S-TEC	System 55X	Analog deviation, ARINC 429 GPSS	
S-TEC	ST-901	ARINC 429 GPSS	GPSS Roll Steering Converter
Century	I / II / III / IV 21 / 31 / 41 2000 Triden	Analog Deviation	
Bendix/King	KAP 100/150 KFC 200/225/300/325 KCP 320	Analog Deviation	

## C.6 ELECTRONIC HSI'S

The following EHSI's are compatible with the CNX80. Other EHSI's or navigation displays may be used with the CNX80 provided that they accept serial data in the format defined in B.2.1 or ARINC 429 data as defined in 2.8.10.2.2.

Manufacturer	Model	Interface	Notes
Sandel Avionics	SN3308	Analog deviation and RS232	Low-speed

## **APPENDIX D - INTERCONNECT DIAGRAMS**

**NOTES**

---

# ISO PLANNING

## Appendix D - Interconnect Diagrams




Figure D- 1 - Main Power and Antenna Interconnect Diagram

## **TSO PENDING**

*This page intentionally left blank.*



**CNX80**

MID-CONTINENT		BENDIX/KING		ROCKWELL COLLINS		CENTURY					
MD200-302/303	MD200-306/307	KI 202	KI 206	KI 207	KI 525A	331A-6P	331A-9G	PN-101	IND-351D	NSD 360A	NSD 1000
P1	P1	P2021	P2061	P2071	P1	P1	P1	P2	P1	P1	CD132
P1	P1	P1	P2	P1	P1	P1	P1	P2	P1	P1	CD132
OBS_H {R HI}	1	1	2	2	2	-	-	X	W	DD	OBS RESOLVER (H/A)
OBS_C {R LO}	25	-	-	-	-	a	v	FF	FF	-	OBS RESOLVER (C)
OBS_D {S1}	7	3	3	L	L	-	-	Y	Z	A	OBS RESOLVER (D)
OBS_E {S3}	26	5	5	P	P	-	-	a	a	AA	OBS RESOLVER (E)
OBS_F {S4}	16	4	4	T	T	-	-	b	Y	BB	OBS RESOLVER (F)
OBS_G {S2}	34	6	6	W	W	-	-	e	X	CC	OBS RESOLVER (G)
MAIN CDI + VALID	10	7	7	N	N	N	K	f	-	-	NAV+ FLAG
MAIN CDI - VALID	29	8	8	F	F	F	F	g	-	-	NAV- FLAG
MAIN CDI SUPERFLG	27	-	-	-	-	-	-	-	-	-	NAV SUPERFLAG
MAIN GS+ VALID	28	-	15	-	H	H	J	FF	-	-	NAV SUPERFLAG LO
MAIN GS SUPERFLG	32	-	16	-	J	J	J	GG	-	-	-
MAIN CDI +FROM	12	-	-	-	-	-	-	-	-	-	+TO FLAG
MAIN GS + UP	30	-	-	9	S	S	T	-	-	-	+FROM FLAG
MAIN GS + DOWN	31	-	-	10	e	e	e	-	-	-	
MAIN CDI + L	14	-	-	13	-	-	-	-	-	-	
MAIN CDI + R	13	-	-	14	-	-	-	-	-	-	
BACK COURSE OUT	15	-	-	11	n	m	m	-	-	-	+UP
GPS IND OUT	17	-	-	12	j	j	j	-	-	-	+DOWN
NAV IND OUT	18	-	-	18	i	j	j	-	-	-	CD+ L
MAIN CDI SELECT	8	-	-	19	l	k	l	-	-	-	CD+ R
BACK COURSE OUT	15	-	-	20	m	m	m	-	-	-	BACK COURSE ANNC
GPS IND OUT	17	-	-	21	n	n	n	-	-	-	GPS ANNC
NAV IND OUT	18	-	-	22	o	o	o	-	-	-	NAV ANNC
MAIN CDI SELECT	8	-	-	23	p	p	p	-	-	-	-
BACK COURSE OUT	15	-	-	24	q	q	q	-	-	-	-
GPS IND OUT	17	-	-	25	r	r	r	-	-	-	-
NAV IND OUT	18	-	-	26	s	s	s	-	-	-	-

**OPTIONAL ANNUNCIATOR LIGHT CONNECTIONS**

CNX80		MAIN COURSE DEVIATION INDICATOR	
BACK COURSE OUT	15	BC LIGHT ① (AMBER)	REMOTE CDI SELECT BUTTON (OPTIONAL)
GPS IND OUT	17	GPS LIGHT ⑤ (WHITE)	LAMP VOLTAGE FROM DIMMER CIRCUIT
NAV IND OUT	18	NAV LIGHT ⑥ (GREEN)	-

**NOTES:**

- ALL WIRES 24 AWG OR LARGER UNLESS OTHERWISE SPECIFIED.
- AT CNX80 CONNECT SHIELD GROUNDS TO THE REAR OF THE MOUNTING FRAME ON THE CONNECTOR PLATE -- THE SHIELD LEADS MUST BE LESS THAN 3.0". CONNECT OTHER SHIELD GROUNDS TO AIRCRAFT CHASSIS WITH AS SHORT A CONDUCTOR AS PRACTICAL.
- THIS CDI DOES NOT PROVIDE BACK COURSE, GPS AND NAV ANNOUNCEMENTS. OPTIONAL ANNUNCIATORS MAY BE INSTALLED AS SHOWN IN THE "OPTIONAL ANNUNCIATOR LIGHT CONNECTIONS".
- A MOMENTARY SWITCH MAY BE USED TO REMOTELY TOGGLE THE CNX80 PRIMARY CDI OUTPUT BETWEEN GPS AND VHF NAV.
- THE CDI SELECT SWITCH MAY BE COMBINED WITH THE GPS IND AND NAV IND OUTPUTS IN A SINGLE SWITCH/ANNUNCIATOR.
- OTHER EQUIVALENT PARTS MAY BE INTERFACED TO THE CNX80. SEE APPROPRIATE INSTALLATION MANUALS FOR THAT EQUIPMENT.


**UPS Aviation Technologies**  
234-Turner Road S.E., Salem, OR 97302  
Phone: 503-881-8101 http://www.upsat.com

**CNX80 INSTALLATION DRAWING**

**MAIN COURSE DEVIATION INDICATOR**

**Figure D- 2 - Main Course Deviation Indicator Interconnect Diagram**

*This page intentionally left blank.*



<b>Rev</b>	<b>Date</b>	<b>Description</b>
-	03/05/03	Initial Release

1. ALL WIRES 24 AWG OR LARGER UNLESS OTHERWISE SPECIFIED.
  2. CONNECT SHIELD GROUNDS TO AIRCRAFT CHASSIS WITH AS SHORT A CONDUCTOR AS PRACTICAL.
  3. THE AUX CDI OUTPUT IS ALWAYS BASED UPON GPS DATA. THE COMPOSITE OUTPUT IS ALWAYS BASED UPON VOR DATA.
  4. OTHER EQUIVALENT PARTS MAY BE INTERFACED TO THE CNX80. SEE APPROPRIATE INSTALLATION MANUALS FOR THAT INFORMATION.

**UPS Aviation Technologies**

2345 Turner Road S.E., Salem, OR 97302  
Phone: 503.887-8101 <http://www.upsat.com>


**CNX80 INSTALLATION DRAWING**

AUX (GPS) CDI / VOR COMPOSITE


**Figure D- 3 - Auxiliary CDI Interconnect Diagram**

*This page intentionally left blank.*


### TYPICAL CONNECTIONS TO ALTIMETER BARO POT



### TYPICAL CONNECTIONS TO RMI



### TYPICAL CONNECTIONS TO HEADING SYNCHRO



### NOTES:

1. ALL WIRES 24 AWG OR LARGER UNLESS OTHERWISE SPECIFIED.
2. AT CNX80 CONNECT SHIELD GROUNDS TO THE REAR OF THE MOUNTING FRAME ON THE CONNECTOR PLATE -- THE SHIELD LEADS MUST BE LESS THAN 3.0°. CONNECT OTHER SHIELD GROUNDS TO AIRCRAFT CHASSIS WITH AS SHORT A CONDUCTOR AS PRACTICAL.
3. NO OTHER EQUIPMENT SHOULD BE WIRED IN PARALLEL ON THE BARO POTENTIOMETER INTERFACE.
4. A DIRECTIONAL GYRO OR HSI BOOTSTRAP OUTPUT MAY BE USED TO PROVIDE SYNCHRO HEADING TO THE CNX80.
5. THE OBI SELECT INPUT TO THE CNX80 CAN BE USED TO SELECT THE SOURCE OF THE BEARING DATA SENT TO THE RMI. WHEN THIS INPUT IS OPEN, BEARING DATA IS DERIVED FROM THE GPS; WHEN GROUNDED, BEARING DATA IS DERIVED FROM THE VOR.
6. OTHER EQUIVALENT PARTS MAY BE INTERFACED TO THE CNX80. SEE APPROPRIATE INSTALLATION MANUALS FOR THAT EQUIPMENT.





Figure D- 4 - Baro Potentiometer/Synchro Heading/RMI Interconnect Diagram

*This page intentionally left blank.*


## **TSO PENDING**

# 1150 PLATINUM


## TYPICAL CONNECTIONS TO ALTITUDE ENCODER



## TYPICAL CONNECTIONS TO FUEL FLOW COMPUTER



## CONNECTION TO SL70/SL70R TRANSPOUNDER



**NOTES:**

1. ALL WIRES 24 AWG OR LARGER UNLESS OTHERWISE SPECIFIED.
2. AT CNX80, CONNECT SHIELD GROUNDS TO THE REAR OF THE MOUNTING FRAME ON THE CONNECTOR PLATE -- THE SHIELD LEADS MUST BE LESS THAN 3.0" CONNECT OTHER SHIELD GROUNDS TO AIRCRAFT CHASSIS WITH AS SHORT A CONDUCTOR AS PRACTICAL.
3. RXD5 (P5-1/41) MAY BE USED INSTEAD OF RXD8 FOR ALTITUDE ENCODER. CNX80 RX SERIAL PORT MUST BE CONFIGURED FOR ALT ENC 1200 BAUD.
4. RXD1 (P1-4/23) OR RXD5 (P5-1/41) MAY BE USED INSTEAD OF RXD2 FOR F/ADC. CNX80 RX SERIAL PORT MUST BE CONFIGURED FOR FADC 9600 BAUD. FADC TRANSMIT PORT MUST BE CONFIGURED FOR MAPCOM 9600 BAUD.
5. TXD1 (TXD2 SHOWN IN PARENTHESIS), INSTALL JUMPER BETWEEN DB9-2 AND DB9-1 TO ENABLE '10' RESOLUTION REFER TO TRANS-CAL INSTALLATION MANUAL FOR ADDITIONAL DETAILS.
6. JUMPER PINS P3-3 AND P3-8 (DB-9 CONNECTOR) TO SELECT APOLLO SERIAL ALTITUDE FORMAT.
7. TXD1 SHOWN (TXD2 SHOWN IN PARENTHESIS), PIN 4 MUST BE GROUNDED TO SELECT APOLLO SERIAL ALTITUDE FORMAT (1200 BAUD).
8. IF THE SL70/SL70R HAS GRAY CODE ALTITUDE PROVIDED TO IT, IT WILL PROVIDE ALTITUDE TO THE CNX80. THE CNX80 WILL ALSO REMOTELY CONTROL THE SL70/SL70R. CNX80 SERIAL PORT 6 (RX/TX) MUST BE CONFIGURED FOR SL70/SL70. THE SL70/SL70 SERIAL PORT CONFIGURATION MUST BE SET AS FOLLOWS:  
ALT SOURCE: GRAY  
BAUD: 9600  
EXT TX
9. OTHER EQUIVALENT PARTS MAY BE INTERFACED TO THE CNX80. SEE APPROPRIATE INSTALLATION MANUALS FOR THAT EQUIPMENT.

**UPS Aviation Technologies**  
234 Turner Road S.E., Salem, OR 97302  
Phone: 503.381.8101 | <http://www.upsat.com>

**CNX80 INSTALLATION DRAWING**

**RS232 INTERFACES**

Figure D- 5 - RS232 Serial Interfaces Interconnect Diagram

## **TSO PENDING**

*This page intentionally left blank.*

GARDEN

## *Appendix D - Interconnect Diagrams*




Figure D- 6 - CNX80 to SL10/15 Audio Panel Interconnect Diagram

## **TSO PENDING**

*This page intentionally left blank.*

# ISO PLANNING

## Appendix D - Interconnect Diagrams





Figure D- 7 - DME Tuning Interconnect Diagram


## **TSO PENDING**

*This page intentionally left blank.*







#### S-TEC ST-901 GPSS CONVERTER CONNECTION



*This page intentionally left blank.*

**CENTURY IV LOC SWITCHING CONNECTION****Figure D- 9 - Century Autopilot Interconnect Diagram**

560-0982-00 Rev --

*This page intentionally left blank.*




Figure D- 10 - Bendix/King Autopilot Interconnect Diagram

*This page intentionally left blank.*




Figure D-11 - Single CNX80 Full Stack Interconnect Diagram

*This page intentionally left blank.*





Figure D-12 - Full Stack with Dual CNX80s Interconnect Diagram

*This page intentionally left blank.*



**Figure D- 13 - CNX80 to Sandel SN3308 Nav Display Interconnect Diagram**

*This page intentionally left blank.*







**UPS Aviation Technologies**